

# Control Commands

**Model No.** **PT-DZ13K series**  
**PT-DS12K series**  
**PT-DW11K series**  
**PT-DZ10K series**



# CONTENTS

Using the Serial Terminals .....	19
1. BASIC FORMAT.....	19
2. BASIC CONTROL COMMAND .....	21
2.1. POWER ON (LAMP ON) [PON] .....	21
2.2. POWER OFF (Standby) [POF].....	21
2.3. FREEZE [OFZ].....	21
2.4. AUTO SETUP [OAS] .....	21
2.5. SHUTTER [OSH].....	22
2.6. INPUT SELECT [IIS] .....	22
2.7. TEST PATTERN [OTS].....	22
2.8. ON SCREEN [OOS].....	23
2.9. MENU KEY [OMN].....	23
2.10. ENTER KEY [OEN] .....	23
2.11. UP KEY (↑) [OCU] .....	23
2.12. DOWN KEY (↓) [OCD].....	24
2.13. LEFT KEY (←) [OCL] .....	24
2.14. RIGHT KEY (→) [OCR].....	24
2.15. DEFAULT KEY [OST].....	24
2.16. FUNCTION KEY [FC1].....	24
2.17. SYSTEM SELECTOR KEY [OSL].....	25
2.18. ASPECT KEY [VS1].....	25
2.19. NUMERIC KEY [ONK].....	25
2.20. STATUS KEY [STS].....	25
2.21. LENS FOCUS KEY[OLF].....	25
2.22. LENS SHIFT KEY[OLH] .....	26
2.23. LENS ZOOM KEY[OLZ].....	26
2.24. INSTALLATION [OIL].....	26

2.25.	COOLING CONDITION [ODR].....	26
2.26.	HIGH ALTITUDE MODE [OFM].....	27
2.27.	LAMP SELECT [LPM].....	27
2.28.	LAMP RELAY - 24H [VXX:LRYI0].....	27
2.29.	LAMP RELAY - WEEK [VXX:LRYI2].....	28
2.30.	LAMO POWER [OLP].....	28
2.31.	LAMP POWER [VXX:LPWI1].....	28
2.32.	PROJECTOR ID [RIS] .....	29
2.33.	RS232C – RESPONSE (ID ALL) [RVS].....	29
2.34.	FUNCTION BUTTON [OFC].....	29
2.35.	SIGNAL LIST – REGISTRATION [OEM].....	30
2.36.	SIGNAL LIST – DELETE [ODM] .....	30
2.37.	SUB MEMORY LIST – CHANGEOVER [OCS].....	30
2.38.	SUB MEMORY LIST – CHANGEOVER (EXTENDED) [OCS].....	30
2.39.	SUB MEMORY LIST – REGISTRATION [OES].....	31
2.40.	SUB MEMORY LIST – DELETE [ODS] .....	31
2.41.	PICTURE MODE [VPM].....	32
2.42.	COLOR [VCO] .....	32
2.43.	TINT [VTN].....	32
2.44.	COLOR TEMPERATURE [OTE].....	33
2.45.	WHITE BALANCE LOW - RED [VOR] .....	33
2.46.	WHITE BALANCE LOW - GREEN [VOG] .....	33
2.47.	WHITE BALANCE LOW - BLUE [VOB].....	34
2.48.	WHITE BALANCE HIGH - RED [VHR] .....	34
2.49.	WHITE BALANCE HIGH - GREEN [VHG] .....	34
2.50.	WHITE BALANCE HIGH - BLUE [VHB].....	35
2.51.	CONTRAST [VCN].....	35
2.52.	BRIGHTNESS [VBR].....	35
2.53.	GAMMA [VGA] .....	36
2.54.	SYSTEM DAYLIGHT VIEW [VXX:DLVIO].....	36
2.55.	SHARPNESS [VSR].....	36

2.56.	NOISE REDUCTION [VNS].....	37
2.57.	DYNAMIC IRIS [OAI].....	37
2.58.	DYNAMIC IRIS (AUTO AIRIS) [OAI:A] .....	37
2.59.	DYNAMIC IRIS (MANUAL IRIS) [OAI:M].....	38
2.60.	DYNAMIC IRIS (DYNAMIC GAMMA) [OAI:D].....	38
2.61.	DIGITAL CINEMA REALITY [OPD].....	38
2.62.	TV-SYSTEM [VSG].....	39
2.63.	SHIFT – HORIZONTAL [VTH].....	39
2.64.	SHIFT – VERTICAL [VTV].....	39
2.65.	ASPECT [VSE].....	40
2.66.	ZOOM – HORIZONTAL [OZH] .....	40
2.67.	ZOOM – VERTICAL [OZV].....	41
2.68.	ZOOM – BOTH [OZO].....	41
2.69.	ZOOM – INTERLOCKED [OZS].....	41
2.70.	ZOOM – MODE [OZT].....	42
2.71.	CLOCK PHASE [VCP].....	42
2.72.	INPUT RESOLUTION – TOTAL DOTS [VTD].....	42
2.73.	INPUT RESOLUTION – DISPLAY DOTS [VDD].....	43
2.74.	INPUT RESOLUTION – TOTAL LINES [VTL].....	43
2.75.	INPUT RESOLUTION – DISPLAY LINES [VDL].....	43
2.76.	CLAMP POSITION [VLT].....	44
2.77.	KYESTONE [OKS].....	44
2.78.	KEYSTONE – SUB KEYSTONE [OSK].....	45
2.79.	KEYSTONE – LINEARITY [VLI].....	45
2.80.	GEOMETRY [VXX:GMMIO].....	45
2.81.	GEOMETRY – KEYSTONE – LENS THROW RATIO [VXX:GMKS0].....	46
2.82.	GEOMETRY – KEYSTONE – VERTICAL BALANCE [VXX:GMKI4].....	46
2.83.	GEOMETRY – KEYSTONE – HORIZONTAL BALANCE [VXX:GMKI7] .....	47
2.84.	GEOMETRY – KEYSTONE – VERTICAL KEYSTONE [VXX:GMKS8].....	47
2.85.	GEOMETRY – KEYSTONE – HORIZONTAL KEYSTONE [VXX:GMKS9].....	48
2.86.	GEOMETRY – CURVED – LENS THROW RATIO [VXX:GMCS0].....	48

2.87.	GEOMETRY - CURVED - VERTICAL ARC [VXX:GMCI3].....	49
2.88.	GEOMETRY - CURVED - HORIZONTAL ARC [VXX:GMCI7].....	49
2.89.	GEOMETRY - CURVED - VERTICAL BALANCE [VXX:GMCI2].....	50
2.90.	GEOMETRY - CURVED - HORIZONTAL BALANCE [VXX:GMCI6].....	50
2.91.	GEOMETRY - CURVED - VERTICAL KEYSTONE [VXX:GMCS8] .....	50
2.92.	GEOMETRY - CURVED - HORIZONTAL KEYSTONE [VXX:GMCS9] .....	51
2.93.	GEOMETRY - CURVED - MAINTAIN ASPECT RATIO [VXX:GMCIA].....	51
2.94.	GEOMETRY - CORNER CORRECTION - UPPER LEFT (V) [VXX:GMFI1].....	52
2.95.	GEOMETRY - CORNER CORRECTION - UPPER RIGHT (V) [VXX:GMFI2] .....	52
2.96.	GEOMETRY - CORNER CORRECTION - LOWER LEFT (V) [VXX:GMFI3].....	52
2.97.	GEOMETRY - CORNER CORRECTION - LOWER RIGHT (V) [VXX:GMFI4].....	53
2.98.	GEOMETRY - CORNER CORRECTION - LINEARITY (V) [VXX:GMFI5].....	53
2.99.	GEOMETRY - CORNER CORRECTION - UPPER LEFT (H) [VXX:GMFI6].....	53
2.100.	GEOMETRY - CORNER CORRECTION - UPPER RIGHT (H) [VXX:GMFI7].....	54
2.101.	GEOMETRY - CORNER CORRECTION - LOWER LEFT (H) [VXX:GMFI8].....	54
2.102.	GEOMETRY - CORNER CORRECTION - LOWER RIGHT (H) [VXX:GMFI9].....	54
2.103.	GEOMETRY - CORNER CORRECTION - LINEARITY (H) [VXX:GMFIA] .....	55
2.104.	DISPLAY LANGUAGE [OLG].....	55
2.105.	SYSTEM SELECTOR [ORF].....	56
2.106.	SYSTEM SELECTOR - SDI [VSD].....	56
2.107.	BLANKING - UPPER [DBU].....	57
2.108.	BLANKING - LOWER [DBB].....	57
2.109.	BLANKING - RIGHT [DBR].....	58
2.110.	BLANKING - LEFT [DBL].....	58
2.111.	CUSTOM MASKING [VXX:MSKI1].....	59
2.112.	FRAME RESPONSE [VXX:FDYIO].....	59
2.113.	RASTER POSITION - HORIZONTAL [VRH].....	60
2.114.	RASTER POSITION - VERTICAL [VRV].....	60
2.115.	EDGE BLENDING [VXX:EDBIO].....	60
2.116.	EDGE BLENDING - UPPER ON/OFF [VGU].....	61
2.117.	EDGE BLENDING - LOWER ON/OFF [VGB].....	61

2.118. EDGE BLENDING - LEFT ON/OFF [VGL].....	61
2.119. EDGE BLENDING - RIGHT ON/OFF [VGR].....	61
2.120. EDGE BLENDING - START - UPPER [VEU].....	62
2.121. EDGE BLENDING - START - LOWER [VEB].....	62
2.122. EDGE BLENDING - START - LEFT [VEL].....	62
2.123. EDGE BLENDING - START - RIGHT [VER].....	63
2.124. EDGE BLENDING - WIDTH - UPPER [VXX:EUWIO].....	63
2.125. EDGE BLENDING - WIDTH - LOWER [VXX:EBWIO].....	63
2.126. EDGE BLENDING - WIDTH - LEFT [VXX:ELWIO].....	64
2.127. EDGE BLENDING - WIDTH - RIGHT [VXX:ERWIO].....	64
2.128. EDGE BLENDING - MARKER ON/OFF [VGM] .....	64
2.129. EDGE BLENDING - NON-OVERLAPPED BLACK LEVEL [VJI].....	65
2.130. EDGE BLENDING - NON-OVERLAPPED BLACK LEVEL - INTERLOCKED [VXX:EBII1] .....	65
2.131. EDGE BLENDING - BLACK BORDER LEVEL [VJO].....	66
2.132. EDGE BLENDING - BLACK BORDER LEVEL - INTERLOCKED [VXX:EBII2].....	66
2.133. EDGE BLENDING - BLACK BORDER WIDTH - UPPER [VJU].....	67
2.134. EDGE BLENDING - BLACK BORDER WIDTH - LOWER [VJB].....	67
2.135. EDGE BLENDING - BLACK BORDER WIDTH - LEFT [VJL] .....	67
2.136. EDGE BLENDING - BLACK BORDER WIDTH - RIGHT [VJR] .....	68
2.137. EDGE BLENDING - BLACK BORDER WIDTH - UPPER KEYSTONE AREA [VXX:EBBI4] .....	68
2.138. EDGE BLENDING - BLACK BORDER WIDTH - LOWER KEYSTONE AREA [VXX:EBBI5] .....	68
2.139. EDGE BLENDING - BLACK BORDER WIDTH - LEFT KEYSTONE AREA [VXX:EBBI6] .....	69
2.140. EDGE BLENDING - BLACK BORDER WIDTH - RIGHT KEYSTONE AREA [VXX:EBBI7] .....	69
2.141. EDGE BLENDING - OVERLAPPED BLACK LEVEL - UPPER [VXX:EBBS0].....	69
2.142. EDGE BLENDING - OVERLAPPED BLACK LEVEL - LOWER [VXX:EBBS1].....	70
2.143. EDGE BLENDING - OVERLAPPED BLACK LEVEL - LEFT [VXX:EBBS2].....	71
2.144. EDGE BLENDING - OVERLAPPED BLACK LEVEL - RIGHT [VXX:EBBS3].....	71
2.145. EDGE BLENDING - OVERLAPPED BLACK LEVEL - UPPER INTERLOCKED [VXX:EBII3] .....	72
2.146. EDGE BLENDING - OVERLAPPED BLACK LEVEL - LOWER INTERLOCKED [VXX:EBII4] .....	72
2.147. EDGE BLENDING - OVERLAPPED BLACK LEVEL - LEFT INTERLOCKED [VXX:EBII5] .....	72
2.148. EDGE BLENDING - OVERLAPPED BLACK LEVEL - RIGHT INTERLOCKED [VXX:EBII6] .....	73

2.149. SCREEN SETTING – SCREEN FORMAT [VSF] .....	73
2.150. SCREEN SETTING - SCREEN POSITION - VERTICAL [VXX:VSP10].....	73
2.151. SCREEN SETTING - SCREEN POSITION - HORIZONTAL [VXX:HSPIO].....	74
2.152. COLOR MATCHING [VXX:CMA10] .....	74
2.153. WAVEFORM MONITOR [OWM].....	75
2.154. WAVEFORM MONITOR – LINE ADJUSTMENT [VXX:WML10].....	75
2.155. AUTO SIGNAL [VXX:AAS10].....	75
2.156. AUTO SETUP – MODE [OAM].....	76
2.157. AUTO SETUP – POSITION ADJUST [VXX:APA10].....	76
2.158. AUTO SETUP – SIGNAL LEVEL ADJUST [VXX:ASL10].....	76
2.159. DVI-D IN – EDID [OED].....	77
2.160. DVI-D IN – SIGNAL LEVEL [VXX:DVI10].....	77
2.161. HDMI IN – SIGNAL LEVEL [VXX:HSL10] .....	77
2.162. SDI IN – SIGNAL LEVEL [OED] .....	78
2.163. P IN P – MODE [OPP].....	78
2.164. P IN P – MAIN WINDOW [MSI].....	78
2.165. P IN P – MAIN WINDOW – SIZE – INTERLOCKED [MSL] .....	79
2.166. P IN P – MAIN WINDOW – SIZE – VERTICAL [MSV] .....	79
2.167. P IN P – MAIN WINDOW – SIZE – HORIZONTAL [MSH] .....	79
2.168. P IN P – MAIN WINDOW – SIZE – BOTH [MSZ] .....	80
2.169. P IN P – MAIN WINDOW – POSITION – VERTICAL [MPV].....	80
2.170. P IN P – MAIN WINDOW – POSITION – HORIZONTAL [MPH].....	81
2.171. P IN P – SUB WINDOW [SIS].....	81
2.172. P IN P – SUB WINDOW – SIZE – INTERLOCKED [SSL].....	82
2.173. P IN P – SUB WINDOW – SIZE – VERTICAL [SSV].....	82
2.174. P IN P – SUB WINDOW – SIZE – HORIZONTAL [SSH] .....	82
2.175. P IN P – SUB WINDOW – SIZE – BOTH [SSZ] .....	83
2.176. P IN P – SUB WINDOW – POSITION – VERTICAL [SPV].....	83
2.177. P IN P – MAIN WINDOW – POSITION – HORIZONTAL [SPH].....	84
2.178. P IN P – SUB WINDOW – CLOCK PHASE [VXX:SCPIO].....	84
2.179. P IN P – FRAME LOCK [PFL] .....	85

2.180. P IN P – TYPE [PTP].....	85
2.181. BRIGHTNESS CONTROL – GAIN [VXX:TGAIO].....	85
2.182. BRIGHTNESS CONTROL – SETUP – MODE [VXX:BCMIO].....	86
2.183. BRIGHTNESS CONTROL – SETUP – LINK [VXX:BCLIO].....	86
2.184. BRIGHTNESS CONTROL – SETUP – APPLY [VXX:BCSIO].....	86
2.185. SCHEDULE [VXX:SCHIO].....	87
2.186. SCHEDULE – PROGRAM ASSIGN [VXX:SPGI].....	87
2.187. SCHEDULE – COMMAND SETTING [VXX:SCCS].....	88
2.188. NO SIGNAL SHUT-OFF [OAF].....	88
2.189. DATE AND TIME – DATE SETTING [TSD].....	89
2.190. DATE AND TIME – TIME SETTING [TST].....	89
2.191. ON-SCREEN DISPLAY – INPUT GUIDE [OID].....	89
2.192. ON-SCREEN DISPLAY – WARNING MESSAGE [VXX:WMDIO] .....	90
2.193. ON-SCREEN DISPLAY – OSD DESIGN [MOD].....	90
2.194. ON-SCREEN DISPLAY – OSD POSITION [ODP].....	90
2.195. ON-SCREEN DISPLAY – OSD MEMORY [VXX:OMYIO].....	91
2.196. STARTUP LOGO [MLO].....	91
2.197. BACK COLOR [OBC].....	91
2.198. AIR FILTER TYPE [MFS].....	91
2.199. STANDBY MODE [VXX:STMIO] .....	92
2.200. LENS CALIBRATION [VXX:LNSIO].....	92
2.201. LENS HOME POSITION [VXX:LNSI1].....	92
2.202. LENS SHIFT – HORIZONTAL [VXX:LNSI2].....	93
2.203. LENS SHIFT – VERTICAL [VXX:LNSI3].....	93
2.204. LENS FOUCS [VXX:LNSI4].....	94
2.205. LENS ZOOM [VXX:LNSI5].....	94
2.206. RGB IN – RGB1 INPUT SETTING [VXX:RYCI1].....	94
2.207. SDI IN – SDI LINK [VXX:SLKI1].....	95
2.208. SDI IN – BIT DEPTH [VXX:SBTI1].....	95
2.209. SDI IN – BIT DEPTH (DUAL) [VXX:SBTI3].....	96
2.210. SDI IN – 3G-SDI MAPPING [VXX:SGMI1].....	96

2.211.	3D SETTINGS – 3D SYSTEM SETTING [VXX:DSYI1].....	96
2.212.	3D SETTINGS – 3D FILTER [VXX:DFTI1].....	97
2.213.	3D SETTINGS – 3D SYNC SETTING – 3D SYNC MODE [VXX:DSNI1].....	97
2.214.	3D SETTINGS – 3D SYNC SETTING – STEREO SYNC OUTPUT DELAY [VXX:DSNI2].....	98
2.215.	3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:RGB1 RIGHT:RGB2 [VXX:DSMI1].....	98
2.216.	3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:HDMI RIGHT:DVI-D [VXX:DSMI2].....	99
2.217.	3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:SDI1 RIGHT:SDI2 [VXX:DSMI3].....	99
2.218.	3D SETTINGS – 3D INPUT FORMAT [VXX:DIFI1].....	99
2.219.	3D SETTINGS – LEFT/RIGHT SWAP [VXX:DSWI1].....	100
2.220.	3D SETTINGS – 3D COLOR MATCHING [VXX:DCMI1].....	100
2.221.	3D SETTINGS – 3D PICTURE BALANCE – CONTRAST [VXX:DBAI1].....	101
2.222.	3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH RED [VXX:DBAI2].....	101
2.223.	3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH GREEN [VXX:DBAI3].....	101
2.224.	3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH BLUE [VXX:DBAI4].....	102
2.225.	3D SETTINGS – 3D PICTURE BALANCE – BRIGHTNESS [VXX:DBAI5].....	102
2.226.	3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW RED [VXX:DBAI6].....	103
2.227.	3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW GREEN [VXX:DBAI7].....	103
2.228.	3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW BLUE [VXX:DBAI8].....	103
2.229.	3D SETTINGS – 3D PICTURE BALANCE – COLOR DBAI9].....	104
2.230.	3D SETTINGS – 3D PICTURE BALANCE - TINT [VXX:DBAIA].....	104
2.231.	3D SETTINGS – DARK TIME SETTING [VXX:DDTS1].....	105
2.232.	3D SETTINGS – 3D FRAME DELAY [VXX:DFDI1].....	105
2.233.	3D SETTINGS – 3D TEST MODE [VXX:DTSI1].....	105
2.234.	3D SETTINGS – SAFETY PRECAUTIONS MESSAGE [VXX:DMGI1].....	106
2.235.	NAME CHANGE – PICTURE MODE USER NAME [VXX:NCGS0].....	106
2.236.	NAME CHANGE – COLOR TEMPERATURE USER1 NAME [VXX:NCGS1].....	107
2.237.	NAME CHANGE – COLOR TEMPERATURE USER2 NAME [VXX:NCGS3].....	107
2.238.	NAME CHANGE – GAMMA USER1 NAME [VXX:NCGS2].....	107
2.239.	NAME CHANGE – GAMMA USER2 NAME [VXX:NCGS4].....	108
2.240.	NAME CHANGE – LENS MEMORY1 NAME [VXX:NCGS5].....	108
2.241.	NAME CHANGE – LENS MEMORY2 NAME [VXX:NCGS6] .....	109

2.242. NAME CHANGE – LENS MEMORY3 NAME [VXX:NCGS7] .....	109
2.243. NAME CHANGE – PROJECTOR NAME [VXX:NCGS8].....	109
2.244. BRIGHTNESS CONTROL SETUP – CALIBRATION TIME [VXX:BTMI1].....	110
2.245. BRIGHTNESS CONTROL SETUP – CALIBRATION MESSAGE [VXX:BMGI1].....	110
2.246. SHUTTER SETTING - FADE IN [VXX:SEFS1].....	111
2.247. SHUTTER SETTING - FADE OUT [VXX:SEFS2].....	111
2.248. SHUTTER SETTING – STARTUP [VXX:SEFI3].....	111
2.249. SHUTTER SETTING – SHUT OFF [VXX:SEFI4].....	112
2.250. CUT OFF – RED [VXX:CUTI1].....	112
2.251. CUT OFF – GREEN [VXX:CUTI2].....	112
2.252. CUT OFF - BLUE [VXX:CUTI3].....	113
2.253. RGB IN - RGB1 INPUT SETTING [VXX:RYCI1].....	113
2.254. RGB IN – RGB1 SYNC SLICE LEVEL [VXX:STR10] .....	113
2.255. RGB IN - RGB2 SYNC SLICE LEVEL [VXX:STR11].....	114
2.256. SDI IN - SDI1 SIGNAL LEVEL [VXX:SSL11].....	114
2.257. SDI IN - SDI2 SIGNAL LEVEL [VXX:SSL12].....	114
2.258. SDI IN - SDI DUAL LINK SIGNAL LEVEL [VXX:SSL13].....	115
2.259. LENS MEMORY – LENS MEMORY LOAD [VXX:LNMI1].....	115
2.260. LENS MEMORY – LENS MEMORY SAVE [VXX:LNMI2].....	115
2.261. LENS MEMORY – LENS MEMORY DELETE [VXX:LNMI3].....	116
2.262. LENS MEMORY – LENS MEMORY1 NAME DEFAULT [VXX:NCLI5] .....	116
2.263. LENS MEMORY – LENS MEMORY2 NAME DEFAULT [VXX:NCLI6] .....	116
2.264. LENS MEMORY – LENS MEMORY3 NAME DEFAULT [VXX:NCLI7] .....	117
2.265. INITIALIZE – ALL USER DATA [VXX:RSTS1] .....	117
2.266. QUERY POWER [QPW] .....	118
2.267. QUERY FREEZE [QFZ] .....	118
2.268. QUERY SHUTTER [QSH] .....	118
2.269. QUERY INPUT SELECT [QIN] .....	118
2.270. QUERY TEST PATTERN [QTS].....	119
2.271. QUERY ON SCREEN [QOS].....	119
2.272. QUERY INSTALLATION [QSP].....	119

2.273. QUERY COOLING CONDITION [QDR].....	120
2.274. QUERY AUTO COOLING CONDITION – STATUS [QVX:ADRI1].....	120
2.275. QUERY HIGH ALTITUDE MODE [QFM].....	120
2.276. QUERY PROJECTOR RUNTIME [QST].....	121
2.277. QUERY LAMP1 RUNTIME [Q\$L:1].....	121
2.278. QUERY LAMP2 RUNTIME [Q\$L:2].....	121
2.279. QUERY LAMP SELECT [QSL].....	122
2.280. QUERY LAMP CONTROL STATUS [Q\$S].....	122
2.281. QUERY LAMP STATUS [QLS].....	122
2.282. QUERY LAMP RELAY [QVX:LRYI0].....	123
2.283. QUERY LAMP RELAY - WEEK [QVX:LRYI2].....	123
2.284. QUERY LAMO POWER [QLP].....	123
2.285. QUERY LAMP POWER [QVX:LPWI1].....	124
2.286. QUERY RS232C – RESPONSE (ID ALL) [QVY].....	124
2.287. QUERY FUNCTION BUTTON [QFC].....	124
2.288. QUERY SUB MEMORY USAGE STATE [QSB].....	125
2.289. QUERY PICTURE MODE [QPM].....	125
2.290. QUERY COLOR [QVC].....	125
2.291. QUERY TINT [QVT].....	126
2.292. QUERY COLOR TEMPERATURE [QTE].....	126
2.293. QUERY WHITE BALANCE LOW - RED [QOR].....	126
2.294. QUERY WHITE BALANCE LOW - GREEN [QOG].....	127
2.295. QUERY WHITE BALANCE LOW - BLUE [QOB].....	127
2.296. QUERY WHITE BALANCE HIGH - RED [QHR].....	127
2.297. QUERY WHITE BALANCE HIGH - GREEN [QHG].....	128
2.298. QUERY WHITE BALANCE HIGH - BLUE [QHB].....	128
2.299. QUERY CONTRAST [QVR].....	128
2.300. QUERY BRIGHTNESS [QVB].....	128
2.301. QUERY GAMMA[QGA].....	129
2.302. QUERY SYSTEM DAYLIGHT VIEW [QVX:DLVIO].....	129
2.303. QUERY SHARPNESS [QVS].....	129

2.304. QUERY NOISE REDUCTION [QNS].....	130
2.305. QUERY DYNAMIC IRIS [QAI].....	130
2.306. QUERY DYNAMIC IRIS – AUTO IRIS [QAI:A].....	130
2.307. QUERY DYNAMIC IRIS – MANUAL IRIS [QAI:M].....	131
2.308. QUERY DYNAMIC IRIS – DYNAMIC GAMMA [QAI:D].....	131
2.309. QUERY DIGITAL CINEMA REALITY [QPD].....	131
2.310. QUERY TV-SYSTEM [QSG].....	131
2.311. QUERY SHIFT – HORIZONTAL [QTH] .....	132
2.312. QUERY SHIFT – VERTICAL [QTV].....	132
2.313. QUERY RASTER POSITION – HORIZONTAL [QRH].....	132
2.314. QUERY RASTER POSITION – VERTICAL [QRV].....	133
2.315. QUERY EDGE BLENDING [QVX:EDBIO].....	133
2.316. QUERY EDGE BLENDING – UPPER ON/OFF [QGU].....	133
2.317. QUERY EDGE BLENDING – LOWER ON/OFF [QGB].....	133
2.318. QUERY EDGE BLENDING – LEFT ON/OFF [QGL] .....	134
2.319. QUERY EDGE BLENDING – RIGHT ON/OFF [QGR].....	134
2.320. QUERY EDGE BLENDING – RIGHT ON/OFF [QEU].....	134
2.321. QUERY EDGE BLENDING – START – LOWER [QEB].....	134
2.322. QUERY EDGE BLENDING – START – LEFT [QEL] .....	135
2.323. QUERY EDGE BLENDING – START – RIGHT [QER].....	135
2.324. QUERY EDGE BLENDING – WIDTH – UPPER [QVX:EUWIO].....	135
2.325. QUERY EDGE BLENDING – WIDTH – LOWER [QVX:EBWIO] .....	135
2.326. QUERY EDGE BLENDING – WIDTH – LEFT [QVX:ELWIO] .....	136
2.327. QUERY EDGE BLENDING – WIDTH – RIGHT [QVX:ERWIO] .....	136
2.328. QUERY EDGE BLENDING – MARKER ON/OFF [QGM].....	136
2.329. QUERY EDGE BLENDING – NON-OVERLAPPED BLACK LEVEL [QJI].....	137
2.330. QUERY EDGE BLENDING – NON-OVERLAPPED BLACK LEVEL – INTERLOCKED [QVX:EBII1].....	137
2.331. QUERY EDGE BLENDING – BLACK BORDER LEVEL [QJO].....	137
2.332. QUERY EDGE BLENDING – BLACK BORDER LEVEL – INTERLOCKED [QVX:EBII2].....	138
2.333. QUERY EDGE BLENDING – BLACK BORDER WIDTH – UPPER [QJU] .....	138
2.334. QUERY EDGE BLENDING – BLACK BORDER WIDTH – LOWER [QJB].....	138

2.335. QUERY EDGE BLENDING – BLACK BORDER WIDTH - LEFT [QJL].....	139
2.336. QUERY EDGE BLENDING – BLACK BORDER WIDTH - RIGHT [QJR].....	139
2.337. QUERY EDGE BLENDING – BLACK BORDER WIDTH - UPPER KEYSTONE AREA [QVX:EBBI4].....	139
2.338. QUERY EDGE BLENDING – BLACK BORDER WIDTH - LOWER KEYSTONE AREA [QVX:EBBI5].....	139
2.339. QUERY EDGE BLENDING – BLACK BORDER WIDTH - LEFT KEYSTONE AREA [QVX:EBBI6].....	140
2.340. QUERY EDGE BLENDING – BLACK BORDER WIDTH - RIGHT KEYSTONE AREA [QVX:EBBI7].....	140
2.341. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – UPPER [QVX:EBBS0].....	140
2.342. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LOWER [QVX:EBBS1].....	141
2.343. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LEFT [QVX:EBBS2].....	141
2.344. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – RIGHT [QVX:EBBS3].....	142
2.345. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – UPPER INTERLOCKED [QVX:EBII3].....	142
2.346. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LOWER INTERLOCKED [QVX:EBII4].....	142
2.347. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LEFT INTERLOCKED [QVX:EBII5].....	143
2.348. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – RIGHT INTERLOCKED [QVX:EBII6].....	143
2.349. QUERY ASPECT [QSE].....	143
2.350. QUERY ZOOM – HORIZONTAL [QZH].....	144
2.351. QUERY ZOOM – VERTICAL [QZV].....	144
2.352. QUERY ZOOM – BOTH [QZO].....	144
2.353. QUERY ZOOM – INTERLOCKED [QZS].....	145
2.354. QUERY ZOOM – MODE [QZT].....	145
2.355. QUERY CLOCK PHASE [QCP].....	145
2.356. QUERY INPUT RESOLUTION – TOTAL DOTS [QTD].....	146
2.357. QUERY INPUT RESOLUTION – DISPLAY DOTS [QDD].....	146
2.358. QUERY INPUT RESOLUTION – TOTAL LINES [QTL].....	146
2.359. QUERY INPUT RESOLUTION – DISPLAY LINES [QDL].....	147
2.360. QUERY BLANKING - UPPER [QLU].....	147
2.361. QUERY BLANKING - LOWER [QLB].....	147
2.362. QUERY BLANKING - RIGHT [QLR].....	148
2.363. QUERY BLANKING - LEFT [QLL].....	148
2.364. QUERY FRAME RESPONSE [QVX:FDYIO].....	149
2.365. QUERY EDGE BLENDING [QVX:EDBIO].....	149

2.366. QUERY COLOR MATCHING [QVX:CMAI0].....	149
2.367. QUERY CLAMP POSITION [QLT].....	150
2.368. QUERY KYESTONE [QKS].....	150
2.369. QUERY KEYSTONE - SUB KEYSTONE [QSK].....	150
2.370. QUERY KEYSTONE - LINEARITY [QLI] .....	151
2.371. QUERY GEOMETRY [QVX:GMMI0].....	151
2.372. QUERY GEOMETRY - KEYSTONE - LENS THROW RATIO [QVX:GMKS0].....	151
2.373. QUERY GEOMETRY - KEYSTONE - VERTICAL BALANCE [QVX:GMKI4].....	152
2.374. QUERY GEOMETRY - KEYSTONE - HORIZONTAL BALANCE [QVX:GMKI7].....	152
2.375. QUERY GEOMETRY - KEYSTONE - VERTICAL KEYSTONE [QVX:GMKS8].....	153
2.376. QUERY GEOMETRY - KEYSTONE - HORIZONTAL KEYSTONE [QVX:GMKS9].....	153
2.377. QUERY GEOMETRY - CURVED - LENS THROW RATIO [QVX:GMCS0].....	153
2.378. QUERY GEOMETRY - CURVED - VERTICAL ARC [QVX:GMCI3].....	154
2.379. QUERY GEOMETRY - CURVED - HORIZONTAL ARC [QVX:GMCI7].....	154
2.380. QUERY GEOMETRY - CURVED - VERTICAL BALANCE [QVX:GMCI2].....	155
2.381. QUERY GEOMETRY - CURVED - HORIZONTAL BALANCE [QVX:GMCI6].....	155
2.382. QUERY GEOMETRY - CURVED - VERTICAL KEYSTONE [QVX:GMCS8].....	155
2.383. QUERY GEOMETRY - CURVED - HORIZONTAL KEYSTONE [QVX:GMCS9].....	156
2.384. QUERY GEOMETRY - CURVED - MAINTAIN ASPECT RATIO [QVX:GMCIA].....	156
2.385. QUERY GEOMETRY - CORNER CORRECTION - UPPER LEFT (V) [QVX:GMFI1].....	157
2.386. QUERY GEOMETRY - CORNER CORRECTION - UPPER RIGHT (V) [QVX:GMFI2].....	157
2.387. QUERY GEOMETRY - CORNER CORRECTION - LOWER LEFT (V) [QVX:GMFI3].....	157
2.388. QUERY GEOMETRY - CORNER CORRECTION - LOWER RIGHT (V) [QVX:GMFI4].....	158
2.389. QUERY GEOMETRY - CORNER CORRECTION - LINEARITY (V) [QVX:GMFI5].....	158
2.390. QUERY GEOMETRY - CORNER CORRECTION - UPPER LEFT (H) [QVX:GMFI6].....	158
2.391. QUERY GEOMETRY - CORNER CORRECTION - UPPER RIGHT (H) [QVX:GMFI7].....	159
2.392. QUERY GEOMETRY - CORNER CORRECTION - LOWER LEFT (H) [QVX:GMFI8].....	159
2.393. QUERY GEOMETRY - CORNER CORRECTION - LOWER RIGHT (H) [QVX:GMFI9] .....	160
2.394. QUERY GEOMETRY - CORNER CORRECTION - LINEARITY (H) [QVX:GMFIA].....	160
2.395. QUERY DISPLAY LANGUAGE [QLG].....	160
2.396. QUERY SCREEN SETTING - SCREEN FORMAT [QSF].....	161

2.397. QUERY SCREEN SETTING - SCREEN POSITION – VERTICAL [QVX:VSPIO].....	161
2.398. QUERY SCREEN SETTING - SCREEN POSITION - HORIZONTAL [QVX:HSPIO].....	161
2.399. QUERY TEMPERATURE [QTM].....	162
2.400. QUERY DATE AND TIME - DATE [QGD].....	162
2.401. QUERY DATE AND TIME - TIME [QGT].....	162
2.402. QUERY PROJECTOR TYPE [QID].....	163
2.403. QUERY SYSTEM SELECTOR [QRF].....	163
2.404. QUERY SYSTEM SELECTOR – SDI [QSD].....	163
2.405. QUERY WAVEFORM MONITOR [QWM] .....	164
2.406. QUERY WAVEFORM MONITOR – LINE ADJUSTMENT [QVX:WMLIO].....	164
2.407. QUERY AUTO SIGNAL [QVX:AASIO].....	165
2.408. QUERY AUTO SETUP – MODE [QAM] .....	165
2.409. QUERY AUTO SETUP – POSITION ADJUST [QVX:APAIO].....	165
2.410. QUERY AUTO SETUP – SIGNAL LEVEL ADJUST [QVX:ASLIO].....	166
2.411. QUERY DVI-D IN – EDID [QED] .....	166
2.412. QUERY DVI-D IN – SIGNAL LEVEL [QVX:DVIIO].....	166
2.413. QUERY HDMI IN – SIGNAL LEVEL [QVX:HSLIO].....	166
2.414. QUERY SDI IN – SIGNAL LEVEL [QED:SDI-LEVEL].....	167
2.415. QUERY P IN P – MODE [QPP] .....	167
2.416. QUERY P IN P – MAIN WINDOW [QIM].....	167
2.417. QUERY P IN P – MAIN WINDOW – SIZE [QSM].....	168
2.418. QUERY P IN P – MAIN WINDOW – POSITION [QPA].....	168
2.419. QUERY P IN P – SUB WINDOW [QIS].....	169
2.420. QUERY P IN P – SUB WINDOW – SIZE [QSS].....	169
2.421. QUERY P IN P – SUB WINDOW – POSITION [QPS].....	170
2.422. QUERY P IN P – SUB WINDOW – CLOCK PHASE [QVX:SCPIO].....	171
2.423. QUERY P IN P – FRAME LOCK [QPF].....	171
2.424. QUERY P IN P – TYPE [QPT].....	172
2.425. QUERY BRIGHTNESS CONTROL – GAIN [QVX:TGAIO].....	172
2.426. QUERY BRIGHTNESS CONTROL - SETUP - MODE [QVX:BCMIO].....	172
2.427. QUERY BRIGHTNESS CONTROL - SETUP - LINK [QVX:BCLIO].....	173

2.428. QUERY SCHEDULE [QVX:SCHI0].....	173
2.429. QUERY SCHEDULE – PROGRAM ASSIGN [QVX:SPGI].....	173
2.430. QUERY SCHEDULE – COMMAND SETTING [QVX:SCCS] .....	174
2.431. QUERY NO SIGNAL SHUT-OFF [QAF] .....	174
2.432. QUERY ON-SCREEN DISPLAY – INPUT GUIDE [QDI].....	175
2.433. QUERY ON-SCREEN DISPLAY – WARNING MESSAGE [QVX:WMDI0].....	175
2.434. QUERY ON-SCREEN DISPLAY – OSD DESIGN [QOD].....	175
2.435. QUERY ON-SCREEN DISPLAY – OSD POSITION [QDP].....	176
2.436. QUERY ON-SCREEN DISPLAY – OSD MEMORY [QVX:OMYI0].....	176
2.437. QUERY STARTUP LOGO [QLO].....	176
2.438. QUERY BACK COLOR [QBC].....	176
2.439. QUERY SERIAL NUMBER [QSN].....	177
2.440. QUERY LAMP UNIT MODEL No. [QVX:LMNS0].....	177
2.441. QUERY AIR FILTER UNIT MODEL No. [QVX:FMNS0] .....	177
2.442. QUERY AIR FILTER TYPE [QFI].....	178
2.443. QUERY STANDBY MODE [QVX:STMIO].....	178
2.444. QUERY SDI IN – SDI LINK [QVX:SLKI1].....	178
2.445. QUERY SDI IN – BIT DEPTH [QVX:SBTI1].....	179
2.446. QUERY SDI IN – BIT DEPTH (DUAL) [QVX:SBTI3] .....	179
2.447. QUERY SDI IN – 3G-SDI MAPPING [QVX:SGMI1].....	179
2.448. QUERY 3D SETTINGS – 3D SYSTEM SETTING [QVX:DSYI1] .....	180
2.449. QUERY 3D SETTINGS – 3D FILTER [QVX:DFTI1].....	180
2.450. QUERY 3D SETTINGS – 3D SYNC SETTING – 3D SYNC MODE [QVX:DSNI1].....	181
2.451. QUERY 3D SETTINGS – 3D SYNC SETTING – STEREO SYNC OUTPUT DELAY [QVX:DSNI2].....	181
2.452. QUERY 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:RGB1 RIGHT:RGB2 [QVX:DSMI1].....	182
2.453. QUERY 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:HDMI RIGHT:DVI-D [QVX:DSMI2] .....	182
2.454. QUERY 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:SDI1 RIGHT:SDI2 [QVX:DSMI3] .....	182
2.455. QUERY 3D SETTINGS – 3D INPUT FORMAT [QVX:DIFI1] .....	183
2.456. QUERY 3D SETTINGS – LEFT/RIGHT SWAP [QVX:DSWI1].....	183
2.457. QUERY 3D SETTINGS – 3D COLOR MATCHING [QVX:DCMI1].....	183
2.458. QUERY 3D SETTINGS – 3D PICTURE BALANCE – CONTRAST [QVX:DBAI1].....	184

2.459. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH RED [QVX:DBAI2].....	184
2.460. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH GREEN [QVX:DBAI3].....	184
2.461. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH BLUE [QVX:DBAI4].....	185
2.462. QUERY 3D SETTINGS – 3D PICTURE BALANCE – BRIGHTNESS [QVX:DBAI5].....	185
2.463. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW RED [QVX:DBAI6].....	186
2.464. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW GREEN [QVX:DBAI7].....	186
2.465. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW BLUE [QVX:DBAI8].....	186
2.466. QUERY 3D SETTINGS – 3D PICTURE BALANCE – COLOR [QVX:DBAI9].....	187
2.467. QUERY 3D SETTINGS – 3D PICTURE BALANCE - TINT [QVX:DBA1A].....	187
2.468. QUERY 3D SETTINGS – DARK TIME SETTING [QVX:DTS1].....	188
2.469. QUERY 3D SETTINGS – 3D FRAME DELAY [QVX:DFDI1].....	188
2.470. QUERY 3D SETTINGS – 3D TEST MODE [QVX:DTS1].....	188
2.471. QUERY 3D SETTINGS – SAFETY PRECAUTIONS MESSAGE [QVX:DMGI1].....	189
2.472. QUERY CUT OFF – RED [QVX:CUTI1].....	189
2.473. QUERY CUT OFF – GREEN [QVX:CUTI2] .....	189
2.474. QUERY CUT OFF - BLUE [QVX:CUTI3] .....	190
2.475. QUERY RGB IN - RGB1 INPUT SETTING [QVX:RYCI1].....	190
2.476. QUERY RGB IN – RGB1 SYNC SLICE LEVEL [QVX:STRI0].....	190
2.477. QUERY RGB IN - RGB2 SYNC SLICE LEVEL [QVX:STRI1].....	191
2.478. QUERY SDI IN - SDI1 SIGNAL LEVEL [QVX:SSLI1].....	191
2.479. QUERY SDI IN - SDI2 SIGNAL LEVEL [QVX:SSLI2].....	191
2.480. QUERY SDI IN - SDI DUAL LINK SIGNAL LEVEL [QVX:SSLI3].....	192
2.481. QUERY BRIGHTNESS SETUP – CALIBRATION TIME [QVX:BTMI1].....	192
2.482. QUERY BRIGHTNESS SETUP – CALIBRATION MESSAGE [QVX:BMGI1].....	192
2.483. QUERY SHUTTER SETTING - FADE IN [[QVX:SEFS1].....	193
2.484. QUERY SHUTTER SETTING - FADE OUT [QVX:SEFS2].....	193
2.485. QUERY SHUTTER SETTING – STARTUP [QVX:SEFI3].....	193
2.486. QUERY SHUTTER SETTING – SHUT OFF [QVX:SEFI4].....	194
2.487. QUERY DATE AND TIME – NTP SYNCHRONIZATION [QVX:NTPIO] .....	194
2.488. QUERY NAME – PICTURE MODE USER NAME [QVX:NCGS0].....	194
2.489. QUERY NAME – COLOR TEMPERATURE USER1 NAME [QVX:NCGS1].....	195

2.490. QUERY NAME – COLOR TEMPERATURE USER2 NAME [QVX:NCGS3].....	195
2.491. QUERY NAME – GAMMA USER1 NAME [QVX:NCGS2] .....	195
2.492. QUERY NAME – GAMMA USER2 NAME [QVX:NCGS4] .....	196
2.493. QUERY NAME – PROJECTOR NAME [QVX:NCGS8].....	196
2.494. QUERY MASKING – MODE [QVX:MSKI1] .....	197
2.495. QUERY UNIFORMITY – FLEXIBLE CORRECTION [QVX:UFMI1].....	197
2.496. QUERY - SECURITY SETTING [QVX:SPWI1].....	197
2.497. QUERY – FAN VOLTAGE [QVX:FNVI] .....	198
2.498. QUERY SOFTWARE VERSION – MAIN MICROPROCESSOR [QVX:SVRS0].....	198
2.499. QUERY SOFTWARE VERSION - NETWORK MICROPROCESSOR [QVX:SVRS1].....	199
2.500. QUERY SOFTWARE VERSION - SUB MICROPROCESSOR [QVX:SVRS2].....	199
<b>3. Extended Control Command.....</b>	<b>200</b>
3.1. LENS CONTROL.....	200
3.2. SELF CHECK INFORMATION.....	201

## Using the Serial Terminals

### 1. BASIC FORMAT

Transmission from the computer starts with STX, then the ID, command, parameter, and ETX are sent in this order.  
Add parameters according to the details of control.

Basic control command (without parameter)

Start (STX)	ID	Separator (semicolon)	Command	End (ETX)
1 byte	4 bytes	1 byte	3 bytes	1 byte

Basic control command (with parameters)

Start (STX)	ID	Separator (semicolon)	Command	Separator (colon)	Parameters	End (ETX)
1 byte	4 bytes	1 byte	3 bytes	1 byte	Undefined length	1 byte

Basic control command (with subcommand)

Start (STX)	ID	Separator (semicolon)	Command	Separator (colon)		
1 byte	4 bytes	1 byte	3 bytes	1 byte		
Subcommand		Operation	Sign	Parameters		End (ETX)
5 bytes		1 byte	1 byte	5 bytes		1 byte

#### ● Operation

Specifies the method of processing the value specified by parameters.

Code	Description
=	Sets the value specified by the parameter.
_ (underbar)	Adds the value specified by the parameter to the current value.

#### ● Sign

Specifies positive or negative of the value specified by parameters.

Code	Description
+	The value specified by the parameter is a positive value or 0 (zero).
-	The value specified by the parameter is a negative value.

#### ● Parameters

Specify the setting or adjustment value by right justification (0 is not suppressed).

For example, when the setting value is "1", set it as "00001".

## ID of the basic control command

ID	4 bytes String	ID	4 bytes String	ID	4 bytes String	ID	4 bytes String
ID ALL	ADZZ	ID23	AD23	ID46	AD46	Group E	AD0E
ID1	AD01	ID24	AD24	ID47	AD47	Group F	AD0F
ID2	AD02	ID25	AD25	ID48	AD48	Group G	AD0G
ID3	AD03	ID26	AD26	ID49	AD49	Group H	AD0H
ID4	AD04	ID27	AD27	ID50	AD50	Group I	AD0I
ID5	AD05	ID28	AD28	ID51	AD51	Group J	AD0J
ID6	AD06	ID29	AD29	ID52	AD52	Group K	AD0K
ID7	AD07	ID30	AD30	ID53	AD53	Group L	AD0L
ID8	AD08	ID31	AD31	ID54	AD54	Group M	AD0M
ID9	AD09	ID32	AD32	ID55	AD55	Group N	AD0N
ID10	AD10	ID33	AD33	ID56	AD56	Group O	AD0O
ID11	AD11	ID34	AD34	ID57	AD57	Group P	AD0P
ID12	AD12	ID35	AD35	ID58	AD58	Group Q	AD0Q
ID13	AD13	ID36	AD36	ID59	AD59	Group R	AD0R
ID14	AD14	ID37	AD37	ID60	AD60	Group S	AD0S
ID15	AD15	ID38	AD38	ID61	AD61	Group T	AD0T
ID16	AD16	ID39	AD39	ID62	AD62	Group U	AD0U
ID17	AD17	ID40	AD40	ID63	AD63	Group V	AD0V
ID18	AD18	ID41	AD41	ID64	AD64	Group W	AD0W
ID19	AD19	ID42	AD42	Group A	AD0A	Group X	AD0X
ID20	AD20	ID43	AD43	Group B	AD0B	Group Y	AD0Y
ID21	AD21	ID44	AD44	Group C	AD0C	Group Z	AD0Z
ID22	AD22	ID45	AD45	Group D	AD0D		

## Response (Callback) of the basic control command

In the period when the command can be accepted

Differs according to each command

In the period when commands cannot be accepted

Hexadecimal	02h	45h	52h	34h	30h	31h	03h
Character		E	R	4	0	1	

In case of the parameter error or REMOTE2 effective

Hexadecimal	02h	45h	52h	34h	30h	32h	03h
Character		E	R	4	0	2	

## Attention:

- If a command is transmitted after the light source starts illuminating, there may be a delay in response or the command may not be executed. Try sending or receiving any command after 60 seconds.
- When transmitting multiple commands, be sure to wait until 0.5 seconds has elapsed after receiving the response from the projector before sending the next command.  
When transmitting a command which does not need a parameter, a colon (:) is not necessary.
- It might take time by the time the response returns because the command is processed in the projector.  
Set the time-out to 10 seconds or longer.

## Note:

- If a command is sent with a specified ID, a response will be sent to the computer only in the following cases.  
It matches the projector ID  
The projector's [PROJECTOR ID] is [ALL]  
If Group (A-Z) of the sent ID coincides with GROUP in RS232C settings of this projector and RESPONSE(ID GROUP) in RS232C settings of this projector is ON.

## 2. BASIC CONTROL COMMAND

### 2.1. POWER ON (LAMP ON) [PON]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	4Fh	4Eh	03h
Character		A	D	Z	Z	;	P	O	N	

●Response (Callback)

In the period when the command can be accepted (This command in power-on condition is included)

Hexadecimal	02h	50h	4Fh	4Eh	03h
Character		P	O	N	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	△	○	×

●Notes:

- When you check whether to have succeeded in power-on, confirm it by QPW (Query Power) command after receiving the callback of PON command.
- REMOTE2 is given to priority. In the case of a different command from a setup of REMOTE2, ER401 is returned.

### 2.2. POWER OFF (Standby) [POF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	4Fh	46h	03h
Character		A	D	Z	Z	;	P	O	F	

●Response (Callback)

In the period when the command can be accepted (This command in power-off condition is included)

Hexadecimal	02h	50h	4Fh	46h	03h
Character		P	O	F	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	△	○	×

●Notes:

- When you check whether to have succeeded in power-off, confirm it by QPW (Query Power) command after receiving the callback of PON command.
- REMOTE2 is given to priority. In the case of a different command from a setup of REMOTE2, ER401 is returned.

### 2.3. FREEZE [OFZ]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	46h	5Ah	3Ah	*1	03h
Character		A	D	Z	Z	;	O	F	Z	:	*2	

●Parameters(\*1,\*2)

	Freeze OFF	Freeze ON
Hexadecimal	30h	31h
Character	0	1

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	5Ah	3Ah	*1	03h
Character		O	F	Z	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	×	○	○	○	○	×

### 2.4. AUTO SETUP [OAS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	53h	03h
Character		A	D	Z	Z	;	O	A	S	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	53h	03h
Character		O	A	S	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	×	○	×	○	○	×

●Notes:

- The signal of non-compliant, returns the ER401.

## 2.5. SHUTTER [OSH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	48h	3Ah	*1	03h
Character		A	D	Z	Z	;	O	S	H	:	*2	

●Parameters(\*1,\*2)

	SHUTTER OFF	SHUTTER ON
Hexadecimal	30h	31h
Character	0	1

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	48h	3Ah	*1	03h
Character		O	S	H	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	△	○	×

●Notes:

- REMOTE2 IS GIVEN TO PRIORITY. IN THE CASE OF A DIFFERENT COMMAND FROM A SETUP OF REMOTE2, ER401 IS RETURNED..

## 2.6. INPUT SELECT [IIS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	49h	49h	53h	3Ah
Character		A	D	Z	Z	;	I	I	S	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	RGB1			RGB2			Video		
Hexadecimal	52h	47h	31h	52h	47h	32h	56h	49h	44h
Character	R	G	1	R	G	2	V	I	D
	DVI			HDMI			SDI1		
Hexadecimal	44h	56h	49h	48h	44h	31h	53h	44h	31h
Character	D	V	I	H	D	1	S	D	1
	SDI2								
Hexadecimal	53h	44h	32h						
Character	S	D	2						

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	49h	49h	53h	3Ah	*1	*3	*5	03h
Character		I	I	S	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	△	○	×

●Notes:

- REMOTE2 is given to priority. Calls back Er402 if the input select of REMOTE2 is available.
- If PT-DZ13K/PT-DS12K, parameters SD1/SD2 is available. If PT-DZ10K, parameters SD1 is available.
- In other case, ER401 is returned.

## 2.7. TEST PATTERN [OTS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	54h	53h	3Ah
Character		A	D	Z	Z	;	O	T	S	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

●Parameters(\*1,\*2,\*3,\*4)

	OFF		White		Black		Flag		Reversed Flag	
Hexadecimal	30h	30h	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	0	0	1	0	2	0	3	0	4
	Window		Reversed Window		Focus		Color bar (vertical)		Lamp	
Hexadecimal	30h	35h	30h	36h	30h	37h	30h	38h	30h	39h
Character	0	5	0	6	0	7	0	8	0	9
	Red		Green		Blue		10%luminance (White)		5%luminance (White)	
Hexadecimal	32h	32h	32h	33h	32h	34h	32h	35h	32h	36h
Character	2	2	2	3	2	4	2	5	2	6
	Cyan		Magenta		Yellow		Color bar (Side)			
Hexadecimal	32h	38h	32h	39h	33h	30h	35h	31h		
Character	2	8	2	9	3	0	5	1		
	3D-1									
Hexadecimal	38h		30h			38h		31h		
Character	8		0			8		1		

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	54h	53h	3Ah	*1	*3	03h
Character		0	T	S	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.8. ON SCREEN [OOS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Fh	53h	3Ah	*1	03h
Character		A	D	Z	Z	;	0	0	S	:	*2	

●Parameters(\*1,\*2)

	OSD OFF	OSD ON
Hexadecimal	30h	31h
Character	0	1

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Fh	53h	3Ah	*1	03h
Character		0	0	S	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

●Note:

- If the logo is being displayed is invalid.

## 2.9. MENU KEY [OMN]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Dh	4Eh	03h
Character		A	D	Z	Z	;	0	M	N	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Dh	4Eh	03h
Character		0	M	N	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## 2.10. ENTER KEY [OEN]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	4Eh	03h
Character		A	D	Z	Z	;	0	E	N	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	4Eh	03h
Character		0	E	N	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	×

## 2.11. UP KEY (↑) [OCU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	55h	03h
Character		A	D	Z	Z	;	0	C	U	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	55h	03h
Character		0	C	U	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	×

## 2.12. DOWN KEY (↓) [OCD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	44h	03h
Character		A	D	Z	Z	;	O	C	D	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	44h	03h
Character		O	C	D	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	×

## 2.13. LEFT KEY (←) [OCL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	4Ch	03h
Character		A	D	Z	Z	;	O	C	L	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	4Ch	03h
Character		O	C	L	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	×

## 2.14. RIGHT KEY (→) [OCR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	52h	03h
Character		A	D	Z	Z	;	O	C	R	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	52h	03h
Character		O	C	R	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	×

## 2.15. DEFAULT KEY [OST]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	54h	03h
Character		A	D	Z	Z	;	O	S	T	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	54h	03h
Character		O	S	T	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.16. FUNCTION KEY [FC1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	46h	43h	31h	03h
Character		A	D	Z	Z	;	F	C	1	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	46h	43h	31h	03h
Character		F	C	1	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

●Notes:

- Acceptability is applied corresponding to the function assigned in the FUNCTION key.

## 2.17. SYSTEM SELECTOR KEY [OSL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	4Ch	03h
Character		A	D	Z	Z	;	O	S	L	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	4Ch	03h
Character		O	S	L	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.18. ASPECT KEY [VS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	31h	03h
Character		A	D	Z	Z	;	V	S	1	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	31h	03h
Character		V	S	1	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.19. NUMERIC KEY [ONK]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Eh	4Bh	3Ah	*1	03h
Character		A	D	Z	Z	;	O	N	K	:	*2	

●Parameters(\*1,\*2)

	0 KEY	1 KEY	2 KEY	3 KEY	4 KEY	5 KEY	6 KEY	7 KEY	8 KEY	9 KEY
Hexadecimal	30h	31h	32h	33h	34h	35h	36h	37h	38h	39h
Character	0	1	2	3	4	5	6	7	8	9

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Eh	4Bh	3Ah	*1	03h
Character		O	N	K	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	×

## 2.20. STATUS KEY [STS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	54h	53h	03h
Character		A	D	Z	Z	;	S	T	S	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	54h	53h	03h
Character		S	T	S	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.21. LENS FOCUS KEY[OLF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Ch	46h	03h
Character		A	D	Z	Z	;	O	L	F	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	46h	03h
Character		O	L	F	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.22. LENS SHIFT KEY[OLH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Ch	48h	03h
Character		A	D	Z	Z	;	O	L	H	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	48h	03h
Character		O	L	H	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.23. LENS ZOOM KEY[OLZ]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Ch	5Ah	03h
Character		A	D	Z	Z	;	O	L	Z	

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	5Ah	03h
Character		O	L	Z	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.24. INSTALLATION [OIL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	49h	4Ch	3Ah	*1	03h
Character		A	D	Z	Z	;	O	I	L	:	*2	

●Parameters(\*1,\*2)

	FRONT/FLOOR	REAR/FLOOR	FRONT/CEILING	REAR/CEILING
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	49h	4Ch	3Ah	*1	03h
Character		O	I	L	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.25. COOLING CONDITION [ODR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	44h	52h	3Ah	*1	03h
Character		A	D	Z	Z	;	O	D	R	:	*2	

●Parameters(\*1,\*2)

	FLOOR	CEILING	VERTICAL UP	VERTICAL DOWN
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3
	AUTO			
Hexadecimal	39h			
Character	9			

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	44h	52h	3Ah	*1	03h
Character		O	D	R	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.26. HIGH ALTITUDE MODE [OFM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	46h	4Dh	3Ah	*1	03h
Character	A	D	Z	Z	;	O	F	M	:	*	2	

Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	4Dh	3Ah	*1	03h
Character	O	F	M	:	*	2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	○	○	×	○	○	×	○	×

## 2.27. LAMP SELECT [LPM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Ch	50h	4Dh	3Ah	*1	03h
Character	A	D	Z	Z	;	L	P	M	:	*	2	

●Parameters(\*1,\*2,\*3,\*4)

	DUAL	SINGLE	LAMP1	LAMP2
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Ch	50h	4Dh	3Ah	*1	*3	03h
Character	L	P	M	:	*	2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

●Notes:

- During the operation of switching lamp, it return the ER401.
- "SINGLE", are short usage time lamps will automatically selected.

## 2.28. LAMP RELAY – 24H [VXX:LRY10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	
Hexadecimal	4Ch	52h	59h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	L	R	Y	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					00:01					00:02				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	23:58					23:59					00:00				
Hexadecimal	30h	32h	33h	35h	38h	30h	32h	33h	35h	39h	30h	32h	34h	30h	30h
Character	0	2	3	5	8	0	2	3	5	9	0	2	4	0	0

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	52h	59h	49h	30h
Character	V	X	X	:	L	R	Y	I	0	
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	○	○	×	○	○	×	○	×

## 2.29. LAMP RELAY – WEEK [VXX:LRYI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	
Hexadecimal	4Ch	52h	59h	49h	32h	3Dh	2Bh	*1	*3	*5
Character	L	R	Y	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					EVERY DAY					SUN				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	MON					TUE					WED				
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
	0	0	0	0	3	0	0	0	0	4	0	0	0	0	5
Character	THU					FRI					SAT				
	30h	30h	30h	30h	36h	30h	30h	30h	30h	37h	30h	30h	30h	30h	38h
Character	0	0	0	0	6	0	0	0	0	7	0	0	0	0	8

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	52h	59h	49h	32h
Character	V	X	X	:	L	R	Y	I	2	
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.30. LAMO POWER [OLP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Ch	50h	3Ah	*1	03h
Character	A	D	Z	Z	;	V	L	P	:	*	2	

Parameters(\*1,\*2)

	HIGH		MIDDLE		ECO			
	Hexadecimal	30h	31h	38h	Character	0	1	8

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	50h	3Ah	*1	03h
Character	0	L	P	:	*	2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	○	○	○	×	○	○	○	×

## 2.31. LAMP POWER [VXX:LPWI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	
Hexadecimal	4Ch	50h	57h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	L	P	W	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	ECO					HIGH					MIDLE				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
	Character	0	0	0	0	0	0	0	0	1	0	0	0	0	2

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	50h	57h	49h	31h
Character	V	X	X	:	L	P	W	I	1	
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	○	○	○	×	○	○	○	×

## 2.32. PROJECTOR ID [RIS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	52h	49h	53h	3Ah
Character		A	D	Z	Z	;	R	I	S	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

●Parameters(\*1,\*2,\*3,\*4)

	0(ALL)		1		2	
Hexadecimal	30h	30h	30h	31h	30h	32h
Character	0	0	0	1	0	2
	62		63		64	
Hexadecimal	36h	32h	36h	33h	36h	34h
Character	6	2	6	3	6	4

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	52h	49h	53h	3Ah	*1	*3	03h
Character		R	I	S	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.33. RS232C – RESPONSE (ID ALL) [RVS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	52h	56h	53h	3Ah	*1	03h
Character		A	D	Z	Z	;	R	V	S	:	*2	

●Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	52h	56h	53h	3Ah	*1	03h
Character		R	V	S	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	×

## 2.34. FUNCTION BUTTON [OFC]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	46h	43h	3Ah	*1	03h
Character		A	D	Z	Z	;	O	F	C	:	*2	

●Parameters(\*1,\*2)

	DISABLE	SYSTEM SELECTOR	SYSTEM DAYLIGHT VIEW	SUB MEMORY
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3
	FREEZE	P IN P	WAVEFORM MONITOR	LENS MEMORY LOAD
Hexadecimal	34h	35h	36h	37h
Character	4	5	6	7
	LEFT/RIGHT SWAP			
Hexadecimal	38h			
Character	8			

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	43h	3Ah	*1	03h
Character		0	F	C	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	△	△	△	△	△	△	×

●Notes:

- DZ10K returns the ER402 at "LEFT/RIGHT SWAP".
- Acceptability is applied corresponding to the function assigned in the FUNCTION key.

### 2.35. SIGNAL LIST – REGISTRATION [OEM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	4Dh	03h
Character		A	D	Z	Z	;	O	E	M	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	4Dh	03h
Character		O	E	M	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

### 2.36. SIGNAL LIST – DELETE [ODM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	44h	4Dh	3Ah
Character		A	D	Z	Z	;	O	D	M	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

● Parameters(\*1,\*2,\*3,\*4)

	A1		A2		A7		A8	
Hexadecimal	41h	31h	41h	32h	41h	37h	41h	38h
Character	A	1	A	2	A	7	A	8
	L1		L2		L7		L8	
Hexadecimal	40Ch	31h	40Ch	32h	40Ch	37h	40Ch	38h
Character	L	1	L	2	L	7	L	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	44h	4Dh	3Ah	*1	*3	03h
Character		O	D	M	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

### 2.37. SUB MEMORY LIST – CHANGEOVER [OCS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	53h	3Ah
Character		A	D	Z	Z	;	O	C	S	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

● Parameters(\*1,\*2,\*3,\*4)

"nn" of the sub memory number (mm-nn)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	93		94		95		96	
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	53h	3Ah	*1	*3	03h
Character		O	C	S	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

### 2.38. SUB MEMORY LIST – CHANGEOVER (EXTENDED) [OCS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	43h	53h	3Ah
Character		A	D	Z	Z	;	O	C	S	:
Hexadecimal	*1	*3	2Dh	*5	*7	03h				
Character	*2	*4	-	*6	*8					

● Parameters

" mm " of the sub memory number (mm-nn), (\*1,\*2,\*3,\*4)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	92		93		94		95	
Hexadecimal	39h	32h	39h	33h	39h	34h	39h	35h
Character	9	2	9	3	9	4	9	5

"nn" of the sub memory number (mm-nn); (\*5,\*6,\*7,\*8)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
93		94		95		96		
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	53h	3Ah	*1	*3	2Dh
Character	0	C	S	:		*2	*4	-
Hexadecimal	*5	*7	03h					
Character	*6	*8						

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.39. SUB MEMORY LIST – REGISTRATION [OES]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	53h	03h
Character	A	D	Z	Z	;	O	E	S		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	53h	03h
Character	0	E	S		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.40. SUB MEMORY LIST – DELETE [ODS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	44h	53h	3Ah
Character	A	D	Z	Z	;	O	D	S	:	
Hexadecimal	*1	*3	2Dh	*5	*7	03h				
Character	*2	*4	-	*6	*8					

● Parameters

" mm " of the sub memory number (mm-nn), (\*1,\*2,\*3,\*4)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
92		93		94		95		
Hexadecimal	39h	32h	39h	33h	39h	34h	39h	35h
Character	9	2	9	3	9	4	9	5

"nn" of the sub memory number (mm-nn); (\*5,\*6,\*7,\*8)

	01		02		03		04	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
93		94		95		96		
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	44h	53h	3Ah	*1	*3	2Dh
Character		0	D	S	:	*2	*4	-
Hexadecimal	*5	*7	03h					
Character	*6	*8						

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.41. PICTURE MODE [VPM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	50h	4Dh	3Ah
Character		A	D	Z	Z	;	V	P	M	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	NATURAL			STANDARD			DYNAMIC			
	Hexadecimal	4Eh	41h	54h	53h	54h	44h	44h	59h	4Eh
Character	N	A	T	S	T	D	D	Y	N	
	CINEMA			GRAPHIC			DICOM SIM.			
Hexadecimal	43h	49h	4Eh	47h	52h	41h	44h	49h	43h	
	Character	C	I	N	G	R	A	I	C	
USER										
Hexadecimal	55h	53h	52h							
Character	U	S	R							

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	50h	4Dh	3Ah	*1	*3	*5	03h
Character		V	P	M	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.42. COLOR [VCO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	43h	4Fh	3Ah
Character		A	D	Z	Z	;	V	C	O	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29		
	Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h
Character	0	0	1	0	0	2	0	0	3
	+29			+30			+31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	4Fh	3Ah	*1	*3	*5	03h
Character		V	C	O	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.43. TINT [VTN]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	4Eh	3Ah
Character		A	D	Z	Z	;	V	T	N	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

●Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29		
	Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h
Character	0	0	1	0	0	2	0	0	3
	+29			+30			+31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

●Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	4Eh	3Ah	*1	*3	*5	03h
Character		V	T	N	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.44. COLOR TEMPERATURE [OTE]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	54h	45h	3Ah
Character		A	D	Z	Z	;	O	T	E	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6, \*7, \*8)

DEFAULT / USER1 / USER2

	DEFAULT		USER1		USER2	
Hexadecimal	31h	30h	30h	34h	30h	39h
Character	1	0	0	4	0	9

When setting COLOR TEMPERATURE

	3200K				3300K			
Hexadecimal	33h	32h	30h	30h	33h	33h	30h	30h
Character	3	2	0	0	3	3	0	0
	9200K				9300K			
Hexadecimal	39h	32h	30h	30h	39h	33h	30h	30h
Character	9	2	0	0	9	3	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	54h	45h	3Ah	*1	*3	*5	*7	03h
Character		O	T	E	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.45. WHITE BALANCE LOW – RED [VOR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Fh	52h	3Ah
Character		A	D	Z	Z	;	V	O	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Fh	52h	3Ah	*1	*3	*5	03h
Character		V	O	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.46. WHITE BALANCE LOW – GREEN [VOG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Fh	47h	3Ah
Character		A	D	Z	Z	;	V	O	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	125			126			127		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Fh	47h	3Ah	*1	*3	*5	03h
Character		V	O	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

#### 2.47. WHITE BALANCE LOW – BLUE [VOB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Fh	42h	3Ah
Character		A	D	Z	Z	;	V	O	B	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125			
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h	
Character	0	0	1	0	0	2	0	0	3	
	125			126			127			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h	
Character	2	5	3	2	5	4	2	5	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Fh	42h	3Ah	*1	*3	*5	03h
Character		V	O	B	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

#### 2.48. WHITE BALANCE HIGH – RED [VHR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	48h	52h	3Ah
Character		A	D	Z	Z	;	V	H	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2			
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h	
Character	0	0	0	0	0	1	0	0	2	
	253			254			255			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h	
Character	2	5	3	2	5	4	2	5	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	52h	3Ah	*1	*3	*5	03h
Character		V	H	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

#### 2.49. WHITE BALANCE HIGH – GREEN [VHG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	48h	47h	3Ah
Character		A	D	Z	Z	;	V	H	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2			
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h	
Character	0	0	0	0	0	1	0	0	2	
	253			254			255			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h	
Character	2	5	3	2	5	4	2	5	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	47h	3Ah	*1	*3	*5	03h
Character		V	H	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.50. WHITE BALANCE HIGH - BLUE [VHB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	48h	42h	3Ah
Character		A	D	Z	Z	;	V	H	B	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2			
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h	
Character	0	0	0	0	0	1	0	0	2	
	253			254			255			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h	
Character	2	5	3	2	5	4	2	5	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	48h	42h	3Ah	*1	*3	*5	03h
Character		V	H	B	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.51. CONTRAST [VCN]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	43h	4Eh	3Ah
Character		A	D	Z	Z	;	V	C	N	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29			
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h	
Character	0	0	1	0	0	2	0	0	3	
	+29			+30			+31			
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h	
Character	0	6	1	0	6	2	0	6	3	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	4Eh	3Ah	*1	*3	*5	03h
Character		V	C	N	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.52. BRIGHTNESS [VBR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	42h	52h	3Ah
Character		A	D	Z	Z	;	V	B	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29			
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h	
Character	0	0	1	0	0	2	0	0	3	
	+29			+30			+31			
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h	
Character	0	6	1	0	6	2	0	6	3	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	42h	52h	3Ah	*1	*3	*5	03h
Character		V	B	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.53. GAMMA [VGA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	47h	41h	3Ah
Character		A	D	Z	Z	;	V	G	A	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	1.0			1.8			2.0		
Hexadecimal	31h	2Eh	30h	31h	2Eh	38h	32h	2Eh	30h
Character	1	.	0	1	.	8	2	.	0
	2.1			2.2			2.3		
Hexadecimal	32h	2Eh	31h	32h	2Eh	32h	32h	2Eh	33h
Character	2	.	1	2	.	2	2	.	3
	2.4			2.5			2.6		
Hexadecimal	32h	2Eh	34h	32h	2Eh	35h	32h	2Eh	36h
Character	2	.	4	2	.	5	2	.	6
	2.7			2.8			USER1		
Hexadecimal	32h	2Eh	37h	32h	2Eh	38h	55h	53h	31h
Character	2	.	7	2	.	8	U	S	1
	USER2			DICOM SIM.			DEFAULT		
Hexadecimal	55h	53h	32h	44h	49h	43h	44h	45h	46h
Character	U	S	2	D	I	C	D	E	F

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	47h	41h	3Ah	*1	*3	*5	03h
Character		V	G	A	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.54. SYSTEM DAYLIGHT VIEW [VXX:DLV10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	4Ch	56h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	D	L	V	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					1					2				
Hexadecimal	30h	31h	30h	30h	30h	30h	32h								
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	3														
Hexadecimal	30h	30h	30h	30h	33h										
Character	0	0	0	0	3										

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4C	56h	49h	30h
Character		V	X	X	:	D	L	V	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.55. SHARPNESS [VSR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	52h	3Ah
Character		A	D	Z	Z	;	V	S	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal	30h	31h	33h	30h	31h	34h	30h	31h	35h
Character	0	1	3	0	1	4	0	1	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	52h	3Ah	*1	*3	*5	03h
Character		V	S	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.56. NOISE REDUCTION [VNS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Eh	53h	3Ah
Character		A	D	Z	Z	:	V	N	S	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Eh	53h	3Ah	*1	03h
Character		V	N	S	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.57. DYNAMIC IRIS [OAI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	:	O	A	I	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	1	2	3	USER
Hexadecimal	30h	31h	32h	33h	34h
Character	0	1	2	3	4

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	*1	03h
Character		O	A	I	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.58. DYNAMIC IRIS (AUTO AIRIS) [OAI:A]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	:	O	A	I	:
Hexadecimal	41h	*1	*3	*5	03h					
Character	A	*2	*4	*6						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF	1	2
Hexadecimal	30h	30h	30h
Character	0	0	0
	253	254	255
Hexadecimal	32h	35h	33h
Character	2	5	3
	2	5	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	41h	*1	*3	*5	03h
Character		O	A	I	:	A	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.59. DYNAMIC IRIS (MANUAL IRIS) [OAI:M]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	4Dh	*1	*3	*5	03h					
Character	M	*2	*4	*6						

### ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF			1			2			
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h	
Character	0	0	0	0	0	1	0	0	2	
	253			254			255			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h	
Character	2	5	3	2	5	4	2	5	5	

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	4Dh	*1	*3	*5	03h
Character		O	A	I	:	M	*2	*4	*6	

### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.60. DYNAMIC IRIS (DYNAMIC GAMMA) [OAI:D]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	49h	3Ah
Character		A	D	Z	Z	;	O	A	I	:
Hexadecimal	44h	*1	03h							
Character	D	*2								

### ● Parameters(\*1,\*2)

	OFF	1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	49h	3Ah	44h	*1	03h
Character		O	A	I	:	D	*2	

### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.61. DIGITAL CINEMA REALITY [OPD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	50h	44h	3Ah
Character		A	D	Z	Z	;	O	P	D	:
Hexadecimal	*1	03h								
Character	*2									

### ● Parameters(\*1,\*2)

	AUTO	OFF	30p/25p FIXED
Hexadecimal	30h	31h	32h
Character	0	1	2

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	50h	44h	3Ah	*1	03h
Character		O	P	D	:	*2	

### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.62. TV-SYSTEM [VSG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	47h	3Ah
Character		A	D	Z	Z	;	V	S	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

Hexadecimal	AUTO						NTSC		
	41h	54h	31h	41h	54h	32h	4Eh	54h	53h
Character	A	T	1	A	T	2	N	T	S
NTSC4.43						PAL			
Character	N	4	4	P	A	L	P	A	M
PAL-N						SECAM			
Character	P	A	N	S	E	C	P	6	0
PAL60						PAL-M			
Character	50h	41h	4Eh	53h	45h	43h	50h	36h	30h
Character	P	A	N	S	E	C	P	6	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	47h	3Ah	*1	*3	*5	03h
Character		V	S	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.63. SHIFT - HORIZONTAL [VTH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	48h	3Ah
Character		A	D	Z	Z	;	V	T	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

Hexadecimal	0				1				2			
	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	1	0	0	0	2
4093				4094				4095				
Character	4	0	9	3	4	0	9	4	4	0	9	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	48h	3Ah	*1	*3	*5	*7	03h
Character		V	T	H	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

● Notes:

- Due to the input resolution setting / input signal, the maximum value will change.
- Minimum value : 0, Maximum value : (total dots) - 1.

## 2.64. SHIFT - VERTICAL [VTV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	56h	3Ah
Character		A	D	Z	Z	;	V	T	V	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

Hexadecimal	0				1				2			
	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	1	0	0	0	2
4092				4093				4094				
Character	4	0	9	2	4	0	9	3	4	0	9	4

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	56h	3Ah	*1	*3	*5	*7	03h
Character		V	T	V	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

● Notes:

- Due to the input resolution setting / input signal, the maximum value will change.
- Minimum value : 0, Maximum value : (total lines) – 1.

## 2.65. ASPECT [VSE]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	45h	3Ah
Character		A	D	Z	Z	;	V	S	E	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

● Parameters(\*1,\*2,\*3,\*4)

• Input terminal : VIDEO0, Input signal: NTSC

	VID AUTO	4:3	16:9	THROUGH	HV FIT
Hexadecimal	30h	31h	32h	35h	36h
Character	0	1	2	5	6
	H FIT	V FIT			
Hexadecimal	39h	31h	30h		
Character	9	1	0		

• Input terminal / signal : RGB1(RGB/YpbPr)/RGB2(480i,480p)

	AUTO	4:3	16:9	THROUGH	HV FIT
Hexadecimal	30h	31h	32h	35h	36h
Character	0	1	2	5	6
	H FIT	V FIT			
Hexadecimal	39h	31h	30h		
Character	9	1	0		

• Input terminal / signal : Other than those above

	DEFAULT	4:3	16:9	THROUGH	HV FIT
Hexadecimal	30h	31h	32h	35h	36h
Character	0	1	2	5	6
	H FIT	V FIT			
Hexadecimal	39h	31h	30h		
Character	9	1	0		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	45h	3Ah	*1	*3	03h
Character		V	S	E	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.66. ZOOM - HORIZONTAL [OZH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	48h	3Ah
Character		A	D	Z	Z	;	O	Z	H	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	48h	3Ah	*1	*3	*5	03h
Character		O	Z	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	×	○	○	×

## 2.67. ZOOM - VERTICAL [OZV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	56h	3Ah
Character		A	D	Z	Z	;	O	Z	V	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	50			51			52			
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h	
Character	0	5	0	0	5	1	0	5	2	
	997			998			999			
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h	
Character	9	9	7	9	9	8	9	9	9	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	56h	3Ah	*1	*3	*5	03h
Character		O	Z	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	×	○	○	×

## 2.68. ZOOM - BOTH [OZO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	4Fh	3Ah
Character		A	D	Z	Z	;	O	Z	O	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	50			51			52			
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h	
Character	0	5	0	0	5	1	0	5	2	
	997			998			999			
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h	
Character	9	9	7	9	9	8	9	9	9	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	4Fh	3Ah	*1	*3	*5	03h
Character		O	Z	O	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	×	○	○	×

## 2.69. ZOOM - INTERLOCKED [OZS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	53h	3Ah
Character		A	D	Z	Z	;	O	Z	S	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	53h	3Ah	*1	03h
Character		O	Z	S	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	×	○	○	×

## 2.70. ZOOM - MODE [OZT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	5Ah	54h	3Ah
Character		A	D	Z	Z	;	O	Z	T	:
Hexadecimal	*1	03h								
Character	*2									

- Parameters(\*1,\*2)

	INTERNAL	FULL
Hexadecimal	30h	31h
Character	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	5Ah	54h	3Ah	*1	03h
Character		O	Z	T	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	×	○	○	×

- Note:

- When [ASPECT] is not set to [DEFAULT], ER401 returned.

## 2.71. CLOCK PHASE [VCP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	43h	50h	3Ah
Character		A	D	Z	Z	;	V	C	P	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0	1	2
Hexadecimal	30h	30h	30h
Character	0	0	0
	29	30	31
Hexadecimal	30h	32h	39h
Character	0	2	9
	0	3	0
	30h	33h	30h
	3	0	0
	30h	33h	31h
	3	1	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	43h	50h	3Ah	*1	*3	*5	03h
Character		V	C	P	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	×	○	○	×

- Note:

- Acceptability is possible only if it is selected or RGB2 or RGB1. Otherwise, it returns the ER401.

## 2.72. INPUT RESOLUTION - TOTAL DOTS [VTD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	44h	3Ah
Character		A	D	Z	Z	;	V	T	D	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	330				331			
Hexadecimal	30h	33h	33h	30h	30h	33h	33h	31h
Character	0	3	3	0	0	3	3	1
	4094				4095			
Hexadecimal	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	4	4	0	9	5

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	44h	3Ah	*1	*3	*5	*7	03h
Character		V	T	D	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

- Notes:

- An adjustable range changes with input signals/ input resolution.
- When specify a value of less than total dots+30, returns the ER402.
- Can be adjusted only when a signal is input to the [RGB 1 IN] terminal or the [RGB 2 IN] terminal, and HV Sync VIDEO.

## 2.73. INPUT RESOLUTION - DISPLAY DOTS [VDD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	44h	44h	3Ah
Character		A	D	Z	Z	;	V	D	D	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	300				301				
Hexadecimal	30h	33h	30h	30h	30h	33h	30h	31h	
Character	0	3	0	0	0	3	0	1	
	4064				4065				
Hexadecimal	34h	30h	36h	34h	34h	30h	36h	35h	
Character	4	0	6	4	4	0	6	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	44h	44h	3Ah	*1	*3	*5	*7	03h
Character		V	D	D	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

Enabled in the case of RGB1/RGB2

● Notes:

- An adjustable range changes with input signals/ input resolution.
- When specify a value of less than total dots-30, returns the ER402.

## 2.74. INPUT RESOLUTION - TOTAL LINES [VTL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	54h	4Ch	3Ah
Character		A	D	Z	Z	;	V	T	L	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	155				156				
Hexadecimal	30h	31h	35h	35h	30h	31h	35h	36h	
Character	0	1	5	5	0	1	5	6	
	2046				2047				
Hexadecimal	24h	30h	34h	36h	32h	30h	34h	37h	
Character	2	0	4	6	2	0	4	7	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	54h	4Ch	3Ah	*1	*3	*5	*7	03h
Character		V	T	L	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

Enabled in the case of RGB1/RGB2

● Notes:

- An adjustable range changes with input signals/ input resolution.
- When specify a value of less than DISPLAY LINES+10, returns the ER402.

## 2.75. INPUT RESOLUTION - DISPLAY LINES [VDL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	44h	4Ch	3Ah
Character		A	D	Z	Z	;	V	D	L	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	150				151				
Hexadecimal	30h	31h	35h	30h	30h	31h	35h	31h	
Character	0	1	5	0	0	1	5	1	
	2036				2037				
Hexadecimal	32h	30h	33h	36h	32h	30h	33h	37h	
Character	2	0	3	6	2	0	3	7	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	44h	4Ch	3Ah	*1	*3	*5	*7	03h
Character		V	D	L	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

Enabled in the case of RGB1/RGB2

● Notes:

- An adjustable range changes with input signals/ input resolution.
- When specify a value of less than DISPLAY LINES-10, returns the ER402.

## 2.76. CLAMP POSITION [VLT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ch	54h	3Ah
Character		A	D	Z	Z	:	V	L	T	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	1			2		
Hexadecimal	30h	30h	31h	30h	30h	32h
Character	0	0	1	0	0	2
	254			255		
Hexadecimal	32h	35h	34h	32h	35h	35h
Character	2	5	4	2	5	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ch	54h	3Ah	*1	*3	*5	03h
Character		V	L	T	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	×	○	×	○	○	×

● Note:

- It is available only when RGB1 or RGB2 is selected. In other case returns the ER401.

## 2.77. KYESTONE [OKS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Bh	53h	3Ah
Character		A	D	Z	Z	:	O	K	S	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	+125			+126			+127		
Hexadecimal	32h	35h	32h	32h	35h	33h	32h	35h	34h
Character	2	5	2	2	5	3	2	5	4

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Bh	53h	3Ah	*1	*3	*5	03h
Character		O	K	S	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- Other than DW11K model, ER401 is returned.

## 2.78. KEYSTONE – SUB KEYSTONE [OSK]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	53h	4Bh	3Ah
Character		A	D	Z	Z	;	O	S	K	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-63			-62			-61		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	+61			+62			+63		
Hexadecimal	31h	32h	34h	31h	32h	35h	31h	32h	36h
Character	1	2	4	1	2	5	1	2	6

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	4Bh	3Ah	*1	*3	*5	03h
Character		O	S	K	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- Other than DW11K model, ER401 is returned.
- When [KEYSTONE] is set to "0", return the ER401.
- According to [KEYSTONE] settings, there is a case that dose not operate even if the [SUB KEYSTONE] value is changed.

## 2.79. KEYSTONE – LINEARITY [VLI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ch	49h	3Ah
Character		A	D	Z	Z	;	V	L	I	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	+125			+126			+127		
Hexadecimal	32h	35h	32h	32h	35h	33h	32h	35h	34h
Character	2	5	2	2	5	3	2	5	4

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ch	49h	3Ah	*1	*3	*5	03h
Character		V	L	I	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- Other than DW11K model, ER401 is returned. When [KEYSTONE] is set to "0", return the ER401.
- According to [KEYSTONE] settings, there is a case that dose not operate even if the [LINEARITY] value is changed.

## 2.80. GEOMETRY [VXX:GMMIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Dh	49h	30h	3Dh	2Bh	*1	*3	*5
Character	G	M	M	I	0	=	+	*2	*4	*6

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					KEYSTONE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	CURVED					PC-1				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
	PC-2					PC-3				
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5
	CORNER-CORRECTION									
Hexadecimal	30h	30h	30h	31h	30h					
Character	0	0	0	1	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Dh	49h	30h
Character		V	X	X	:	G	M	M	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- Other than DW11K model, ER401 is returned.

## 2.81. GEOMETRY - KEYSTONE - LENS THROW RATIO [VXX:GMKS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	53h	30h	3Dh	2Bh	*1	*3	*5
Character	G	M	K	S	0	=	+	*2	*4	*6
Hexadecimal	*7	03h								
Character	*8									

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0.7				0.8				
	Hexadecimal	30h	30h	2Eh	37h	30h	30h	2Eh	38h
Character	0	0	.	.	7	0	0	.	8
	16.4				16.5				
Hexadecimal	31h	36h	2Eh	34h	31h	36h	2Eh	35h	
Character	1	6	.	4	1	6	.	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	53h	30h
Character		V	X	X	:	G	M	K	S	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	03h			
Character	=	+	*2	*4	*6	*8				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K model, ER401 is returned.
- Character that can be specified, only numbers and period.
- Will be set to 0.7 to 16.5 in 0.1 increments.

## 2.82. GEOMETRY - KEYSTONE - VERTICAL BALANCE [VXX:GMKI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	34h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	4	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-60						-59					
	Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h
Character	—	0	0	0	6	0	—	0	0	0	5	9
	+59						+60					
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	36h	30h
Character	+	0	0	0	5	9	+	0	0	0	6	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	34h
Character		V	X	X	:	G	M	K	I	4
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- DW11K model, ER401 is returned.

## 2.83. GEOMETRY - KEYSTONE - HORIZONTAL BALANCE [VXX:GMKI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	49h	37h	3Dh	*1	*3	*5	*7
Character	G	M	K	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11		03h						
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-30						-29				
Hexadecimal	2Dh	30h	30h	30h	33h	30h	2Dh	30h	30h	30h	39h
Character	—	0	0	0	3	0	—	0	0	0	2
	+29						+30				
Hexadecimal	2Bh	30h	30h	30h	32h	39h	2Bh	30h	30h	30h	30h
Character	+	0	0	0	2	9	+	0	0	0	3

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	49h	37h
Character		V	X	X	:	G	M	K	I	7
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Note:

· DW11K model, ER401 is returned.

## 2.84. GEOMETRY - KEYSTONE - VERTICAL KEYSTONE [VXX:GMKS8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	53h	38h	3Dh	*1	*3	*5	*7
Character	G	M	K	S	8	=	*2	*4	*6	*8
Hexadecimal	*9	03h								
Character	*10									

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-40.0					-38.8				
Hexadecimal	2Dh	34h	30h	2Eh	30h	2Dh	33h	38h	2Eh	38h
Character	—	4	0	.	0	—	3	8	.	8
	-9.8					+00.0				
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	—	0	9	.	8	+	0	0	.	0
	+38.8					+40.0				
Hexadecimal	2Bh	33h	38h	2Eh	38h	2Bh	34h	30h	2Eh	30h
Character	+	3	8	.	8	+	4	0	.	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	53h	38h
Character		V	X	X	:	G	M	K	S	8
Hexadecimal	3Dh	*1	*3	*5	*7	*9	03h			
Character	=	*2	*4	*6	*8	*10				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Notes:

· DW11K model, ER401 is returned.

· Character that can be specified, only numbers and period.

· Will be set to -40.0 to +40.0 in 0.2 increments. After activation : -45.0 to +45.0 / 0.2 step.

## 2.85. GEOMETRY - KEYSTONE - HORIZONTAL KEYSTONE [VXX:GMKS9]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	4Bh	53h	39h	3Dh	*1	*3	*5	*7
Character	G	M	K	S	9	=	*2	*4	*6	*8
Hexadecimal	*9	03h								
Character	*10									

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-15.0					-14.8				
Hexadecimal	2Dh	31h	35h	2Eh	30h	2Dh	31h	34h	2Eh	38h
Character	-	1	5	.	0	-	1	4	.	8
	-9.8					+00.0				
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	-	0	9	.	8	+	0	0	.	0
	+14.8					+15.0				
Hexadecimal	2Bh	31h	34h	2Eh	38h	2Bh	31h	35h	2Eh	30h
Character	+	1	4	.	8	+	1	5	.	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	4Bh	53h	39h
Character		V	X	X	:	G	M	K	S	9
Hexadecimal	3Dh	*1	*3	*5	*7	*9	03h			
Character	=	*2	*4	*6	*8	*10				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K model, ER401 is returned.
- Character that can be specified, only numbers and period.
- Will be set to -15.0 to +15.0 in 0.2 increments. After activation : -40.0 to +40.0 / 0.2 step.

## 2.86. GEOMETRY - CURVED - LENS THROW RATIO [VXX:GMCS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	53h	30h	3Dh	2Bh	*1	*3	*5
Character	G	M	C	S	0	=	+	*2	*4	*6
Hexadecimal	*7	03h								
Character	*8									

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0.7				0.8			
Hexadecimal	30h	30h	2Eh	37h	30h	30h	2Eh	38h
Character	0	0	.	7	0	0	.	8
	16.4				16.5			
Hexadecimal	31h	36h	2Eh	34h	31h	36h	2Eh	35h
Character	1	6	.	4	1	6	.	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	53h	30h
Character		V	X	X	:	G	M	C	S	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	03h			
Character	=	+	*2	*4	*6	*8				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K model, ER401 is returned.
- Character that can be specified, only numbers and period.
- Will be set to 0.7 to 16.5 in 0.1 increments.

## 2.87. GEOMETRY - CURVED - VERTICAL ARC [VXX:GMCI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	33h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	3	=	*2	*4	*6	*8
Hexadecimal	*9	*11		03h						
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

Hexadecimal	-50						-49				
	2Dh	30h	30h	30h	35h	30h	2Dh	30h	30h	30h	34h
	Character	—	0	0	0	5	0	—	0	0	4
Hexadecimal	+49						+50				
	2Bh	30h	30h	30h	34h	39h	2Bh	30h	30h	30h	35h
	Character	+	0	0	0	4	9	+	0	0	5

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	33h
Character		V	X	X	:	G	M	C	I	3
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Notes:

- DW11K model, ER401 is returned.
- Will be set to -50 to +50, After activation : -100 to +100.

## 2.88. GEOMETRY - CURVED - HORIZONTAL ARC [VXX:GMCI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	37h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11		03h						
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

Hexadecimal	-50						-49				
	2Dh	30h	30h	30h	35h	30h	2Dh	30h	30h	30h	34h
	Character	—	0	0	0	5	0	—	0	0	4
Hexadecimal	+49						+50				
	2Bh	30h	30h	30h	34h	39h	2Bh	30h	30h	30h	35h
	Character	+	0	0	0	4	9	+	0	0	5

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	37h
Character		V	X	X	:	G	M	C	I	7
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Notes:

- DW11K model, ER401 is returned.
- Will be set to -50 to +50, After activation : -100 to +100.

## 2.89. GEOMETRY - CURVED - VERTICAL BALANCE [VXX:GMCI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	32h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	2	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-60						-59				
Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h
Character	—	0	0	0	6	0	—	0	0	0	5
	+59						+60				
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	36h
Character	+	0	0	0	5	9	+	0	0	0	6

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	32h
Character		V	X	X	:	G	M	C	I	2
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- DW11K model, ER401 is returned.

## 2.90. GEOMETRY - CURVED - HORIZONTAL BALANCE [VXX:GMCI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	36h	3Dh	*1	*3	*5	*7
Character	G	M	C	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-30						-29				
Hexadecimal	2Dh	30h	30h	30h	33h	30h	2Dh	30h	30h	30h	32h
Character	—	0	0	0	3	0	—	0	0	0	2
	+29						+30				
Hexadecimal	2Bh	30h	30h	30h	32h	39h	2Bh	30h	30h	30h	33h
Character	+	0	0	0	2	9	+	0	0	0	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	36h
Character		V	X	X	:	G	M	C	I	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- DW11K model, ER401 is returned.

## 2.91. GEOMETRY - CURVED - VERTICAL KEYSTONE [VXX:GMCS8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	47h
Character		A	D	Z	Z	;	V	X	X	:	G
Hexadecimal	4Dh	43h	53h	38h	3Dh	*1	*3	*5	*7	*9	03h
Character	M	C	S	8	=	*2	*4	*6	*8	*10	

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-40.0					-38.8				
Hexadecimal	2Dh	34h	30h	2Eh	30h	2Dh	33h	38h	2Eh	38h
Character	—	4	0	.	0	—	3	8	.	8
	-9.8					+00.0				
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	—	0	9	.	8	+	0	0	.	0
	+38.8					+40.0				
Hexadecimal	2Bh	33h	38h	2Eh	38h	2Bh	34h	30h	2Eh	30h
Character	+	3	8	.	8	+	4	0	.	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	53h	38h
Character		V	X	X	:	G	M	C	S	8
Hexadecimal	3Dh	*1	*3	*5	*7	*9	03h			
Character	=	*2	*4	*6	*8	*10				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K model, ER401 is returned.
- Character that can be specified, only numbers and period.
- Will be set to -40.0 to +40.0 in 0.2 increments. After activation : -45.0 to +45.0 / 0.2 step.

## 2.92. GEOMETRY - CURVED - HORIZONTAL KEYSTONE [VXX:GMCS9]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	47h
Character		A	D	Z	Z	:	V	X	X	:	G
Hexadecimal	4Dh	43h	53h	39h	3Dh	*1	*3	*5	*7	*9	03h
Character	M	C	S	9	=	*2	*4	*6	*8	*10	

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-15.0					-14.8				
Hexadecimal	2Dh	31h	35h	2Eh	30h	2Dh	31h	34h	2Eh	38h
Character	-	1	5	.	0	-	1	4	.	8
	-9.8					+0.0				
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	-	0	9	.	8	+	0	0	.	0
	+14.8					+15.0				
Hexadecimal	2Bh	33h	38h	2Eh	38h	2Bh	31h	35h	2Eh	30h
Character	+	1	4	.	8	+	1	5	.	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	53h	39h
Character		V	X	X	:	G	M	C	S	9
Hexadecimal	3Dh	*1	*3	*5	*7	*9	03h			
Character	=	*2	*4	*6	*8	*10				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K model, ER401 is returned.
- Character that can be specified, only numbers and period.
- Will be set to -15.0 to +15.0 in 0.2 increments. After activation : -40.0 to +40.0 / 0.2 step.

## 2.93. GEOMETRY - CURVED - MAINTAIN ASPECT RATIO [VXX:GMCIA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	43h	49h	41h	3Dh	2Bh	*1	*3	*5
Character	G	M	C	I	A	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	43h	49h	41h
Character		V	X	X	:	G	M	C	I	A
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- DW11K model, ER401 is returned.

## 2.94. GEOMETRY - CORNER CORRECTION - UPPER LEFT (V) [VXX:GMFI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	31h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	1	=	*2	*4	*6	*8
Hexadecimal	*9	*11		03h						
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

				+0						+300	
Hexadecimal	2Bh	30h	30h	30h	30h	2Bh	30h	30h	33h	30h	30h
Character	+	0	0	0	0	+	0	0	3	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	31h
Character		V	X	X	:	G	M	F	I	1
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Note:

- DW11K model, ER401 is returned.

## 2.95. GEOMETRY - CORNER CORRECTION - UPPER RIGHT (V) [VXX:GMFI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	32h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	2	=	*2	*4	*6	*8
Hexadecimal	*9	*11		03h						
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

				+0						+300	
Hexadecimal	2Bh	30h	30h	30h	30h	2Bh	30h	30h	33h	30h	30h
Character	+	0	0	0	0	+	0	0	3	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	31h
Character		V	X	X	:	G	M	F	I	2
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Note:

- DW11K model, ER401 is returned.

## 2.96. GEOMETRY - CORNER CORRECTION - LOWER LEFT (V) [VXX:GMFI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	33h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	3	=	*2	*4	*6	*8
Hexadecimal	*9	*11		03h						
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

				-300						+0
Hexadecimal	2Dh	30h	30h	30h	30h	2Bh	30h	30h	30h	30h
Character	—	0	0	0	0	+	0	0	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	33h
Character		V	X	X	:	G	M	F	I	3
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Note:
  - DW11K model, ER401 is returned.

## 2.97. GEOMETRY - CORNER CORRECTION - LOWER RIGHT (V) [VXX:GMFI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	34h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	4	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-300						+0				
Hexadecimal	2Dh	30h	30h	33h	30h	30h	2Bh	30h	30h	30h	30h
Character	—	0	0	3	0	0	+	0	0	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	34h
Character		V	X	X	:	G	M	F	I	4
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Note:

• DW11K model, ER401 is returned.

## 2.98. GEOMETRY - CORNER CORRECTION - LINEARITY (V) [VXX:GMFI5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	35h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	5	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-127						+128				
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Bh	30h	30h	31h	32h
Character	—	0	0	1	2	7	+	0	0	1	2

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	35h
Character		V	X	X	:	G	M	F	I	5
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Note:

• DW11K model, ER401 is returned.

## 2.99. GEOMETRY - CORNER CORRECTION - UPPER LEFT (H) [VXX:GMFI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	36h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	+0						+480				
Hexadecimal	2Bh	30h	30h	30h	30h	30h	2Bh	30h	30h	34h	38h
Character	+	0	0	0	0	0	+	0	0	4	8

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	36h
Character		V	X	X	:	G	M	F	I	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## ● Note:

- DW11K model, ER401 is returned.

## 2.100. GEOMETRY - CORNER CORRECTION - UPPER RIGHT (H) [VXX:GMFI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	37h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-480						+0				
Hexadecimal	2Dh	30h	30h	34h	38h	30h	2Bh	30h	30h	30h	30h
Character	—	0	0	4	8	0	+	0	0	0	0

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	37h
Character		V	X	X	:	G	M	F	I	7
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## ● Note:

- DW11K model, ER401 is returned.

## 2.101. GEOMETRY - CORNER CORRECTION - LOWER LEFT (H) [VXX:GMFI8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	38h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	8	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	+0						+480				
Hexadecimal	2Bh	30h	30h	30h	30h	30h	2Bh	30h	30h	34h	38h
Character	+	0	0	0	0	0	+	0	0	4	8

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	38h
Character		V	X	X	:	G	M	F	I	8
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## ● Note:

- DW11K model, ER401 is returned.

## 2.102. GEOMETRY - CORNER CORRECTION - LOWER RIGHT (H) [VXX:GMFI9]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	39h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	9	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-480						+0				
Hexadecimal	2Dh	30h	30h	34h	38h	30h	2Bh	30h	30h	30h	30h
Character	—	0	0	4	8	0	+	0	0	0	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	39h
Character		V	X	X	:	G	M	F	I	9
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- DW11K model, ER401 is returned.

## 2.103. GEOMETRY - CORNER CORRECTION - LINEARITY (H) [VXX:GMFIA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	47h	4Dh	46h	49h	38h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	8	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-127						+127				
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Bh	30h	30h	31h	32h
Character	—	0	0	1	2	7	+	0	0	1	2

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	47h	4Dh	46h	49h	41h
Character		V	X	X	:	G	M	F	I	A
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Note:

- DW11K model, ER401 is returned.

## 2.104. DISPLAY LANGUAGE [OLG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	4Ch	47h	3Ah
Character		A	D	Z	Z	:	O	L	G	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	English			German			French			
	Hexadecimal	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
Character	E	N	G	D	E	U	F	R	A	
	Spanish			Italian			Portuguese			
	Hexadecimal	45h	53h	50h	49h	54h	4Ch	50h	4Fh	52h
Character	E	S	P	I	T	L	P	O	R	
	Japanese			Chinese			Russian			
	Hexadecimal	4Ah	50h	4Eh	43h	48h	49h	52h	55h	53h
Character	J	P	N	C	H	I	R	U	S	
	Korean									
	Hexadecimal	4Bh	4Fh	52h						
Character	K	O	R							

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	47h	3Ah	*1	*3	*5	03h
Character		O	L	G	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.105. SYSTEM SELECTOR [ORF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	52h	46h	3Ah
Character		A	D	Z	Z	;	O	R	F	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

· RGB(VGA/480P)

	VGA60	480P( YC <sub>B</sub> C <sub>R</sub> )	480pRGB
Hexadecimal	30h	31h	33h
Character	0	1	3

· RGB(Other)/DVI

	RGB	YP <sub>B</sub> P <sub>R</sub>
Hexadecimal	30h	31h
Character	0	1

· HDMI

	RGB	YP <sub>B</sub> P <sub>R</sub>	AUTO
Hexadecimal	30h	31h	32h
Character	0	1	2

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	52h	46h	3Ah	*1	03h
Character		O	R	F	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.106. SYSTEM SELECTOR – SDI [VSD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	44h	3Ah
Character		A	D	Z	Z	;	V	S	D	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

● Parameters(\*1,\*2,\*3,\*4)

SDI1(SINGLE LINK)

	AUTO	480i	576i
Hexadecimal	30h	31h	33h
Character	0	1	3
	1080/60i	1035/60i	720/60p
Hexadecimal	34h	35h	36h
Character	4	5	6
	1080/24p	1080/50i	1080/30p
Hexadecimal	37h	38h	39h
Character	7	8	9
	1080/25p	1080/24sF	720/50p
Hexadecimal	31h	30h	31h
Character	1	0	1
	1080/50p YpbPr	1080/60p YpbPr	1080/24p RGB
Hexadecimal	31h	35h	32h
Character	1	5	2
	1080/24sF RGB	1080/25p RGB	1080/30p RGB
Hexadecimal	32h	32h	32h
Character	2	2	3
	1080/50i RGB	1080/60i RGB	
Hexadecimal	32h	35h	32h
Character	2	5	6

SDI2(SINGLE LINK)

	AUTO	480i	576i
Hexadecimal	30h	31h	33h
Character	0	1	3
	1080/60i	1035/60i	720/60p
Hexadecimal	34h	35h	36h
Character	4	5	6
	1080/24p	1080/50i	1080/30p
Hexadecimal	37h	38h	39h
Character	7	8	9
	1080/25p	1080/24sF	720/50p
Hexadecimal	31h	30h	31h
Character	1	0	1

DUAL LINK

	AUTO		1080/24p RGB					
Hexadecimal	30h		32h		31h			
Character	0		2		1			
	1080/24sF RGB		1080/25p RGB		1080/30p RGB			
Hexadecimal	32h	32h	32h	33h	32h	34h		
Character	2	2	2	3	2	4		
	1080/50i RGB		1080/60i RGB		2K/24p RGB			
Hexadecimal	32h	35h	32h	36h	33h	31h		
Character	2	5	2	6	3	1		
	2K/24sF RGB		2K/24p XYZ		2K/24sF XYZ			
Hexadecimal	33h	32h	34h	31h	34h	32h		
Character	3	2	4	1	4	2		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	44h	3Ah	*1	*3	03h
Character		V	S	D	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

2.107. BLANKING – UPPER [DBU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	55h	3Ah
Character		A	D	Z	Z	;	D	B	U	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0	1	2
Hexadecimal	30h	30h	30h
Character	0	0	0

PT-DZ13K/DZ10K

	597	598	599
Hexadecimal	35h	39h	37h
Character	5	9	7

PT-DS12K

	522	523	524
Hexadecimal	35h	32h	32h
Character	5	2	2

PT-DW11K

	381	382	383
Hexadecimal	33h	38h	31h
Character	3	8	1

● Note:

- From the input signal and aspect, zoom setting conditions, the maximum value will change.

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	55h	3Ah	*1	*3	*5	03h
Character		D	B	U	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

2.108. BLANKING – LOWER [DBB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	42h	3Ah
Character		A	D	Z	Z	;	D	B	B	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0	1	2
Hexadecimal	30h	30h	30h
Character	0	0	0

PT-DZ13K/DZ10K

	597	598	599
Hexadecimal	35h	39h	37h
Character	5	9	7

PT-DS12K

	522	523	524
Hexadecimal	35h	32h	32h
Character	5	2	2

### PT-DW11K

	381			382			383		
Hexadecimal	33h	38h	31h	33h	38h	31h	33h	38h	31h
Character	3	8	1	3	8	1	3	8	1

● Note:

- From the input signal and aspect, zoom setting conditions, the maximum value will change.

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	42h	3Ah	*1	*3	*5	03h
Character		D	B	B	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

### 2.109. BLANKING – RIGHT [DBR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	52h	3Ah
Character		A	D	Z	Z	;	D	B	R	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

PT-DZ13K/DZ10K

	957			958			959		
Hexadecimal	39h	35h	37h	39h	35h	38h	39h	35h	39h
Character	9	5	7	9	5	8	9	5	9

PT-DS12K

	697			698			699		
Hexadecimal	36h	39h	37h	36h	39h	38h	36h	39h	39h
Character	6	9	7	6	9	8	6	9	9

PT-DW11K

	680			681			682		
Hexadecimal	36h	38h	30h	36h	38h	31h	36h	38h	32h
Character	6	8	0	6	8	1	6	8	2

● Note:

- From the input signal and aspect, zoom setting conditions, the maximum value will change.

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	52h	3Ah	*1	*3	*5	03h
Character		D	B	R	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

### 2.110. BLANKING – LEFT [DBL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	44h	42h	4Ch	3Ah
Character		A	D	Z	Z	;	D	B	L	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

PT-DZ13K/DZ10K の場合

	957			958			959		
Hexadecimal	39h	35h	37h	39h	35h	37h	39h	35h	37h
Character	9	5	7	9	5	7	9	5	7

PT-DS12K の場合

	697			698			699		
Hexadecimal	36h	39h	37h	36h	39h	37h	36h	39h	37h
Character	6	9	7	6	9	7	6	9	7

PT-DW11K の場合

	680			681			682		
Hexadecimal	36h	38h	30h	36h	38h	30h	36h	38h	30h
Character	6	8	0	6	8	0	6	8	0

● Notes:

- From the input signal and aspect, zoom setting conditions, the maximum value will change.

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	4Ch	3Ah	*1	*3	*5	03h
Character	A	D	Z	L	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

## 2.111. CUSTOM MASKING [VXX:MSK1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	4Dh	53h	4Bh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	M	S	K	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					PC-1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	PC-2					PC-3				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Dh	53h	4Bh	49h	31h
Character		V	X	X	:	M	S	K	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

● Notes:

- DW11K is returned ER401.
- Returns the ER401 if it is not activation.

## 2.112. FRAME RESPONSE [VXX:FDY10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	:	V	X	X	:	
Hexadecimal	46h	44h	59h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	F	D	Y	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					FAST					FIXED				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	35h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	46h	44h	59h	49h	30h
Character		V	X	X	:	F	D	Y	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	×	×

## 2.113. RASTER POSITION – HORIZONTAL [VRH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	52h	48h	3Ah
Character		A	D	Z	Z	;	V	R	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	-2048				-2047			
Hexadecimal	32h	39h	35h	32h	32h	39h	35h	33h
Character	2	9	5	2	2	9	5	3
	+2046				+2047			
Hexadecimal	37h	30h	34h	36h	37h	30h	34h	37h
Character	7	0	4	6	7	0	4	7

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	52h	48h	3Ah	*1	*3	*5	03h
Character		V	R	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

- Notes:

From the input signal and aspect, zoom setting conditions, the maximum value will change.

## 2.114. RASTER POSITION – VERTICAL [VRV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	52h	56h	3Ah
Character		A	D	Z	Z	;	V	R	V	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	-2048				-2047			
Hexadecimal	32h	39h	35h	32h	32h	39h	35h	33h
Character	2	9	5	2	2	9	5	3
	+2046				+2047			
Hexadecimal	37h	30h	34h	36h	37h	30h	34h	37h
Character	7	0	4	6	7	0	4	7

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	52h	56h	3Ah	*1	*3	*5	03h
Character		V	R	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	×	○	×	○	○	○	×

- Notes:

From the input signal and aspect, zoom setting conditions, the maximum value will change.

## 2.115. EDGE BLENDING [VXX:EDB10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	44h	42h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	E	D	B	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				USER			
Hexadecimal	30h	31h	30h	30h	30h	32h							
Character	0	0	0	0	0	0	0	0	1	0	0	0	2

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	44h	42h	49h	30h
Character		V	X	X	:	E	D	B	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.116. EDGE BLENDING – UPPER ON/OFF [VGU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	47h	55h	3Ah
Character		A	D	Z	Z	;	V	G	U	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	47h	55h	3Ah	*1	03h
Character		V	G	U	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

## 2.117. EDGE BLENDING – LOWER ON/OFF [VGB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	47h	42h	3Ah
Character		A	D	Z	Z	;	V	G	B	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	47h	42h	3Ah	*1	03h
Character		V	G	B	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

## 2.118. EDGE BLENDING – LEFT ON/OFF [VGL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	47h	4Ch	3Ah
Character		A	D	Z	Z	;	V	G	L	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	47h	4Ch	3Ah	*1	03h
Character		V	G	L	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

## 2.119. EDGE BLENDING – RIGHT ON/OFF [VGR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	47h	52h	3Ah
Character		A	D	Z	Z	;	V	G	R	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	47h	52h	3Ah	*1	03h
Character		V	G	R	:	*2	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.120. EDGE BLENDING – START – UPPER [VEU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	45h	55h	3Ah
Character		A	D	Z	Z	;	V	E	U	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

## ● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1199
Hexadecimal	30h	30h
Character	0	0
Hexadecimal	30h	30h
Character	1	1
Hexadecimal	39h	39h
Character	9	9

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	45h	55h	3Ah	*1	*3	*5	*7	03h
Character		V	E	U	:	*2	*4	*6	*8	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## ● Notes:

- From the input signal and input resolution , width setting conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

## 2.121. EDGE BLENDING – START – LOWER [VEB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	45h	42h	3Ah
Character		A	D	Z	Z	;	V	E	B	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

## ● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1199
Hexadecimal	30h	30h
Character	0	0
Hexadecimal	30h	30h
Character	1	1
Hexadecimal	39h	39h
Character	9	9

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	45h	42h	3Ah	*1	*3	*5	*7	03h
Character		V	E	B	:	*2	*4	*6	*8	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## ● Notes:

- From the input signal and input resolution , width setting conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

## 2.122. EDGE BLENDING – START – LEFT [VEL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	45h	4Ch	3Ah
Character		A	D	Z	Z	;	V	E	L	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

## ● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	30h
Character	0	0
Hexadecimal	30h	30h
Character	1	9
Hexadecimal	31h	39h
Character	9	1
Hexadecimal	31h	39h
Character	1	9

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	45h	4Ch	3Ah	*1	*3	*5	*7	03h
Character		V	E	L	:	*2	*4	*6	*8	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## ● Notes:

- From the input signal and input resolution , width setting conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of horizontal resolution -1.

## 2.123. EDGE BLENDING – START – RIGHT [VER]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	45h	52h	3Ah
Character		A	D	Z	Z	;	V	E	R	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	45h	52h	3Ah	*1	*3	*5	*7	03h
Character		V	E	R	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- From the input signal and input resolution , width setting conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of horizontal resolution -1.

## 2.124. EDGE BLENDING – WIDTH – UPPER [VXX:EUW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	55h	57h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	E	U	W	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0	1199
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	55h	57h	49h	30h
Character		V	X	X	:	E	U	W	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- From the input signal, input resolution and starting position conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

## 2.125. EDGE BLENDING – WIDTH – LOWER [VXX:EBW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	42h	57h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	E	B	W	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0	1199
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	57h	49h	30h
Character		V	X	X	:	E	B	W	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- From the input signal, input resolution and starting position conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

## 2.126. EDGE BLENDING – WIDTH – LEFT [VXX:ELW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	4Ch	57h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	E	L	W	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1919				
Hexadecimal	30h	30h	30h	30h	30h	30h	31h	39h	31h	39h
Character	0	0	0	0	0	0	1	9	1	9

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	4Ch	57h	49h	30h
Character		V	X	X	:	E	L	W	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

- From the input signal, input resolution and starting position conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

## 2.127. EDGE BLENDING – WIDTH – RIGHT [VXX:ERW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	52h	57h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	E	R	W	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1919				
Hexadecimal	30h	30h	30h	30h	30h	30h	31h	39h	31h	39h
Character	0	0	0	0	0	0	1	9	1	9

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	52h	57h	49h	30h
Character		V	X	X	:	E	R	W	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

- From the input signal, input resolution and starting position conditions, the maximum value will change.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

## 2.128. EDGE BLENDING – MARKER ON/OFF [VGM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	47h	4Dh	3Ah
Character		A	D	Z	Z	;	V	G	M	:
Hexadecimal	*1	03h								
Character	*2									

- Parameters(\*1,\*2)

	OFF			ON		
Hexadecimal	30h			31h		
Character	0			1		

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	47h	4Dh	3Ah	*1	03h
Character		V	G	M	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.129. EDGE BLENDING – NON-OVERLAPPED BLACK LEVEL [VJI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ah	49h	3Ah
Character		A	D	Z	Z	:	V	J	I	:
Hexadecimal	*1	*3	*5	2Ch	*7	*9	*11	2Ch	*13	*15
Character	*2	*4	*6	,	*8	*10	*12	,	*14	*16
Hexadecimal	*17	2Ch	*19	*21	*23	03h				
Character	*18	,	*20	*22	*24					

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0	255
Hexadecimal	30h	30h
Character	0	0

	0	255
Hexadecimal	32h	35h
Character	2	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0	255
Hexadecimal	30h	30h
Character	0	0

	0	255
Hexadecimal	32h	35h
Character	2	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0	255
Hexadecimal	30h	30h
Character	0	0

	0	255
Hexadecimal	32h	35h
Character	2	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0	255
Hexadecimal	30h	30h
Character	0	0

	0	255
Hexadecimal	32h	35h
Character	2	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ah	49h	3Ah	*1	*3	*5
Character		V	J	I	:	*2	*4	*6
Hexadecimal	2Ch	*7	*9	*11	2Ch	*13	*15	*17
Character	,	*8	*10	*12	,	,*14	*16	*18
Hexadecimal	2Ch	*19	*21	*23				
Character	,	*20	*22	*24				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.130. EDGE BLENDING – NON-OVERLAPPED BLACK LEVEL – INTERLOCKED [VXX:EBII1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	45h	42h	49h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	E	B	I	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	49h	49h	31h
Character		V	X	X	:	E	B	I	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.131. EDGE BLENDING – BLACK BORDER LEVEL [VJO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ah	4Fh	3Ah
Character		A	D	Z	Z	;	V	J	O	:
Hexadecimal	*1	*3	*5	2Ch	*7	*9	*11	2Ch	*13	*15
Character	*2	*4	*6	,	*8	*10	*12	,	*14	*16
Hexadecimal	*17	2Ch	*19	*21	*23	03h				
Character	*18	,	*20	*22	*24					

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6): White

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

- Parameters(\*7,\*8,\*9,\*10, \*11, \*12): Red

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

- Parameters(\*13,\*14,\*15,\*16, \*17, \*18): Green

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

- Parameters(\*19,\*20,\*21,\*22, \*23, \*24): Blue

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ah	4Fh	3Ah	*1	*3	*5
Character		V	J	0	:	*2	*4	*6
Hexadecimal	2Ch	*7	*9	*11	2Ch	*13	*15	*17
Character	,	*8	*10	*12	,	,*14	*16	*18
Hexadecimal	2Ch	*19	*21	*23				
Character	,	*20	*22	*24				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.132. EDGE BLENDING – BLACK BORDER LEVEL – INTERLOCKED [VXX:EBII2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	42h	49h	49h	32h	3Dh	2Bh	*1	*3	*5
Character	E	B	I	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	49h	49h	32h
Character		V	X	X	:	E	B	I	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

### 2.133. EDGE BLENDING – BLACK BORDER WIDTH – UPPER [VJU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ah	55h	3Ah
Character		A	D	Z	Z	;	V	J	U	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1199
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ah	55h	3Ah	*1	*3	*5	*7	03h
Character		V	J	U	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

- The maximum setting value will change by other setting conditions.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

### 2.134. EDGE BLENDING – BLACK BORDER WIDTH – LOWER [VJB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ah	42h	3Ah
Character		A	D	Z	Z	;	V	J	B	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1199
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ah	42h	3Ah	*1	*3	*5	*7	03h
Character		V	J	B	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

- The maximum setting value will change by other setting conditions.
- The minimum value is 0, and the maximum value be specified in a range of vertical resolution -1.

### 2.135. EDGE BLENDING – BLACK BORDER WIDTH – LEFT [VJL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ah	4Ch	3Ah
Character		A	D	Z	Z	;	V	J	L	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ah	4Ch	3Ah	*1	*3	*5	*7	03h
Character		V	J	L	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

- The maximum setting value will change by other setting conditions.
- The minimum value is 0, and the maximum value be specified in a range of horizontal resolution -1.

## 2.136. EDGE BLENDING – BLACK BORDER WIDTH – RIGHT [VJR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	4Ah	52h	3Ah
Character		A	D	Z	Z	;	V	J	R	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	30h
Character	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	4Ah	52h	3Ah	*1	*3	*5	*7	03h
Character		V	J	R	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- The maximum setting value will change by other setting conditions.
- The minimum value is 0, and the maximum value be specified in a range of horizontal resolution -1.

## 2.137. EDGE BLENDING – BLACK BORDER WIDTH – UPPER KEYSTONE AREA [VXX:EBBI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	42h	42h	49h	34h	3Dh	*1	*3	*5	*7
Character	E	B	B	I	4	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1199	+1199
Hexadecimal	2Dh	30h
Character	-	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	49h	34h
Character		V	X	X	:	E	B	B	I	4
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- The maximum setting value will change by BLACK BORDER WIDTH setting conditions.
- The minimum value is (BLACK BORDER WIDTH UPPER) ×(-1), and maximum value is (BLACK BORDER WIDTH UPPER)×1.

## 2.138. EDGE BLENDING – BLACK BORDER WIDTH – LOWER KEYSTONE AREA [VXX:EBBI5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	42h	42h	49h	35h	3Dh	*1	*3	*5	*7
Character	E	B	B	I	5	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1199	+1199
Hexadecimal	2Dh	30h
Character	-	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	49h	35h
Character		V	X	X	:	E	B	B	I	5
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- The maximum setting value will change by BLACK BORDER WIDTH setting conditions.
- The minimum value is (BLACK BORDER WIDTH LOWER) ×(-1), and maximum value is (BLACK BORDER WIDTH LOWER)×1.

### 2.139. EDGE BLENDING – BLACK BORDER WIDTH – LEFT KEYSTONE AREA [VXX:EBBI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	
Hexadecimal	45h	42h	42h	49h	36h	3Dh	*1	*3	*5	*7
Character	E	B	B	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1919						+1919				
Hexadecimal	2Dh	30h	31h	39h	31h	39h	2Bh	30h	30h	30h	31h
Character	-	0	1	9	1	9	+	0	1	9	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	49h	36h
Character	V	X	X	:	E	B	B	I	6	
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- The maximum setting value will change by BLACK BORDER WIDTH setting conditions.
- The minimum value is (BLACK BORDER WIDTH LEFT) ×(-1), and maximum value is (BLACK BORDER WIDTH LEFT)×1.

### 2.140. EDGE BLENDING – BLACK BORDER WIDTH – RIGHT KEYSTONE AREA [VXX:EBBI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	
Hexadecimal	45h	42h	42h	49h	37h	3Dh	*1	*3	*5	*7
Character	E	B	B	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1919						+1919					
Hexadecimal	2Dh	30h	31h	39h	31h	39h	2Bh	30h	31h	39h	31h	39h
Character	-	0	1	9	1	9	+	0	1	9	1	9

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	49h	37h
Character	V	X	X	:	E	B	B	I	7	
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	○	○	x	○	○	○	x

- Notes:

- The maximum setting value will change by BLACK BORDER WIDTH setting conditions.
- The minimum value is (BLACK BORDER WIDTH RIGHT) ×(-1), and maximum value is (BLACK BORDER WIDTH RIGHT)×1.

### 2.141. EDGE BLENDING – OVERLAPPED BLACK LEVEL – UPPER [VXX:EBBS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	
Hexadecimal	45h	42h	42h	53h	30h	3Dh	*1	*3	*5	2Ch
Character	E	B	B	S	0	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22
Hexadecimal	*23	03h								
Character	*24									

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	53h	30h
Character	V	X	X	:	E	B	B	S	0	:
Hexadecimal	3Dh	*1	*3	*5	2Ch	*7	*9	*11	2Ch	*13
Character	=	*2	*4	*6	.	*8	*10	*12	,	*14
Hexadecimal	*15	*17	2Ch	*19	*21	*23	03h			
Character	*16	*18	,	*20	*22	*24				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.142. EDGE BLENDING – OVERLAPPED BLACK LEVEL – LOWER [VXX:EBBS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	;	V	X	X	:	:
Hexadecimal	45h	42h	42h	53h	31h	3Dh	*1	*3	*5	2Ch
Character	E	B	B	S	1	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22
Hexadecimal	*23	03h								
Character	*24									

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	53h	31h
Character	V	X	X	:	E	B	B	S	1	:
Hexadecimal	3Dh	*1	*3	*5	2Ch	*7	*9	*11	2Ch	*13
Character	=	*2	*4	*6	.	*8	*10	*12	,	*14
Hexadecimal	*15	*17	2Ch	*19	*21	*23	03h			
Character	*16	*18	,	*20	*22	*24				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.143. EDGE BLENDING – OVERLAPPED BLACK LEVEL – LEFT [VXX:EBBS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	42h	42h	53h	32h	3Dh	*1	*3	*5	2Ch
Character	E	B	B	S	2	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22
Hexadecimal	*23	03h								
Character	*24									

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	53h	32h
Character		V	X	X	:	E	B	B	S	2
Hexadecimal	3Dh	*1	*3	*5	2Ch	*7	*9	*11	2Ch	*13
Character	=	*2	*4	*6	,	*8	*10	*12	,	*14
Hexadecimal	*15	*17	2Ch	*19	*21	*23	03h			
Character	*16	*18	,	*20	*22	*24				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.144. EDGE BLENDING – OVERLAPPED BLACK LEVEL – RIGHT [VXX:EBBS3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	45h	42h	42h	53h	33h	3Dh	*1	*3	*5	2Ch
Character	E	B	B	S	3	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22
Hexadecimal	*23	03h								
Character	*24									

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	42h	53h	33h
Character		V	X	X	:	E	B	B	S	3
Hexadecimal	3Dh	*1	*3	*5	2Ch	*7	*9	*11	2Ch	*13
Character	=	*2	*4	*6	.	*8	*10	*12	,	*14
Hexadecimal	*15	*17	2Ch	*19	*21	*23	03h			
Character	*16	*18	,	*20	*22	*24				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.145. EDGE BLENDING – OVERLAPPED BLACK LEVEL – UPPER INTERLOCKED [VXX:EBII3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	45h	42h	49h	49h	33h	3Dh	2Bh	*1	*3	*5
Character	E	B	I	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	49h	49h	33h
Character		V	X	X	:	E	B	I	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.146. EDGE BLENDING – OVERLAPPED BLACK LEVEL – LOWER INTERLOCKED [VXX:EBII4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	45h	42h	49h	49h	34h	3Dh	2Bh	*1	*3	*5
Character	E	B	I	I	4	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	49h	49h	34h
Character		V	X	X	:	E	B	I	I	4
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.147. EDGE BLENDING – OVERLAPPED BLACK LEVEL – LEFT INTERLOCKED [VXX:EBII5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	45h	42h	49h	49h	35h	3Dh	2Bh	*1	*3	*5
Character	E	B	I	I	5	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	49h	49h	35h
Character		V	X	X	:	E	B	I	I	5
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.148. EDGE BLENDING – OVERLAPPED BLACK LEVEL – RIGHT INTERLOCKED [VXX:EBI|6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	45h	42h	49h	49h	36h	3Dh	2Bh	*1	*3	*5
Character	E	B	I	I	6	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	45h	42h	49h	49h	36h
Character		V	X	X	:	E	B	I	I	6
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.149. SCREEN SETTING – SCREEN FORMAT [VSF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	53h	46h	3Ah
Character		A	D	Z	Z	:	V	S	F	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	16:10 *1	16:9	4:3
Hexadecimal	30h	31h	32h
Character	0	1	2

\*1: DS12K is returned ER401.

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	5h	46h	3Ah	*1	03h
Character		V	S	F	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Note:

-DW11K is returned ER401..

## 2.150. SCREEN SETTING – SCREEN POSITION – VERTICAL [VXX:VSPIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	56h	53h	50h	49h	30h	3Dh	*1	*3	*5	*7
Character	V	S	P	I	0	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

PT-DZ13K/DZ10K, SCREEN FORMAT 16:9

	-60						-59				
Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h
Character	—	0	0	0	6	0	—	0	0	0	5
											9
											60
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	36h
Character	+	0	0	0	5	9	+	0	0	0	6
											0

PT-DS12K, SCREEN FORMAT 16:9

	-132						-131					
Hexadecimal	2Dh	30h	30h	31h	33h	32h	2Dh	30h	30h	31h	33h	31h
Character	—	0	0	1	3	2	—	0	0	1	3	1
	130						131					
Hexadecimal	2Bh	30h	30h	31h	33h	30h	2Bh	30h	30h	31h	33h	31h
Character	+	0	0	1	3	0	+	0	0	1	3	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	56h	53h	50h	49h	30h
Character	V	X	X	:	V	S	P	I	0	
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- DW11K is returned ER401..
- DZ13K/DZ10K, when screen format is 4:3 or 16:10, ER401 is returned.
- DS12K, when screen format is 4:3, ER401 is returned.

### 2.151. SCREEN SETTING – SCREEN POSITION – HORIZONTAL [VXX:HSP10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	:	V	X	X	:	
Hexadecimal	48h	53h	50h	49h	30h	3Dh	*1	*3	*5	*7
Character	H	S	P	I	0	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

#### PT-DZ13K/DZ10K, SCREEN FORMAT 4:3

	-160						-159					
Hexadecimal	2Dh	30h	30h	31h	36h	30h	2Dh	30h	30h	31h	35h	39h
Character	—	0	0	1	6	0	—	0	0	1	5	9
	159						160					
Hexadecimal	2Bh	30h	30h	31h	35h	39h	2Bh	30h	30h	31h	36h	30h
Character	+	0	0	1	5	9	+	0	0	1	6	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	48h	53h	50h	49h	30h
Character	V	X	X	:	H	S	P	I	0	
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- DW11K is returned ER401..
- DZ13K/DZ10K, when screen format is 4:3 or 16:10, ER401 is returned.
- DS12K, when screen format is 4:3, ER401 is returned.

### 2.152. COLOR MATCHING [VXX:CMA10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character	A	D	Z	Z	:	V	X	X	:	
Hexadecimal	44h	4Dh	41h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	C	M	A	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					3COLORS					7COLORS				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	32h	
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	2	
	709MODE					MEASURED									
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h					
Character	0	0	0	0	3	0	0	0	0	4					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Dh	41h	49h	30h
Character		V	X	X	:	C	M	A	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.153. WAVEFORM MONITOR [OWM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	57h	4Dh	3Ah
Character		A	D	Z	Z	:	O	W	M	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	Select line (luminance)	Select line (red)	Select line (green)	Select line (blue)
Hexadecimal	30h	35h	36h	37h	38h
Character	0	5	6	7	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	57h	4Dh	3Ah	*1	03h
Character		O	W	M	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	×	×

## 2.154. WAVEFORM MONITOR - LINE ADJUSTMENT [VXX:WMLIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	57h	4Dh
Character		A	D	Z	Z	:	V	X	X	:	W	M
Hexadecimal	4Ch	49h	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h	
Character	L	I	0	=	+	*2	*4	*6	*8	*10		

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
<hr/>										
Character	0	0	0	0	0	0	0	0	0	1
	1198					1199				
Hexadecimal	30h	31h	31h	39h	38h	30h	31h	31h	39h	39h
Character	0	1	1	9	8	0	1	1	9	9

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	57h	4Dh	4Ch	49h	30h
Character		V	X	X	:	W	M	L	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	×	×

## 2.155. AUTO SIGNAL [VXX:AASIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	41h	41h	53h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	A	A	S	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	41h	41h	53h	49h	30h
Character		V	X	X	:	A	A	S	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.156. AUTO SETUP - MODE [OAM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	4Dh	3Ah
Character		A	D	Z	Z	;	O	A	M	:
Hexadecimal	*1	03h								
Character	*2									

## ● Parameters(\*1,\*2)

	USER	DEFAULT	WIDE
Hexadecimal	30h	31h	32h
Character	0	1	2

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	4Dh	3Ah	*1	03h
Character		O	A	M	:	*2	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.157. AUTO SETUP - POSITION ADJUST [VXX:APA10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	41h	50h	41h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	A	P	A	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	41h	50h	41h	49h	30h
Character		V	X	X	:	A	P	A	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.158. AUTO SETUP - SIGNAL LEVEL ADJUST [VXX:ASL10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	41h	53h	4Ch	49h	30h	3Dh	2Bh	*1	*3	*5
Character	A	S	L	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	41h	53h	4Ch	49h	30h
Character		V	X	X	:	A	S	L	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.159. DVI-D IN - EDID [OED]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	44h	3Ah
Character		A	D	Z	Z	;	O	E	D	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	EDID1	EDID2(PC)	EDID3
Hexadecimal	31h	32h	33h
Character	1	2	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	44h	3Ah	*1	03h
Character		E	D	:	*	2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.160. DVI-D IN - SIGNAL LEVEL [VXX:DVIIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	56h	49h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	D	V	I	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0-255:PC					16-235					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	56h	49h	49h	30h
Character		V	X	X	:	D	V	I	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.161. HDMI IN - SIGNAL LEVEL [VXX:HSLIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	48h	53h	4Ch	49h	30h	3Dh	2Bh	*1	*3	*5
Character	H	S	L	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0-1023					64-940					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	48h	53h	4Ch	49h	30h
Character		V	X	X	:	H	S	L	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.162. SDI IN - SIGNAL LEVEL [OED]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	45h	44h	3Ah
Character		A	D	Z	Z	;	O	E	D	:
Hexadecimal	53h	44h	49h	2Dh	4Ch	45h	56h	45h	4Ch	*1
Character	S	D	I	-	L	E	V	E	L	*2

● Parameters(\*1,\*2)

Hexadecimal	64-940	4-1019
Character	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	45h	44h	3Ah	53h	44h	49h
Character		O	E	D	:	S	D	I
Hexadecimal	2Dh	4Ch	45h	56h	45h	4Ch	*1	03h
Character	-	L	E	V	E	L	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K is returned ER401.

## 2.163. P IN P – MODE [OPP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	50h	50h	3Ah
Character		A	D	Z	Z	;	O	P	P	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	USER1	USER2	USER3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	50h	50h	3Ah	*1	03h
Character		O	P	P	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.164. P IN P – MAIN WINDOW [MSI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	49h	3Ah
Character		A	D	Z	Z	;	M	S	I	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

	RGB1			RGB2			Video			
	Hexadecimal	52h	47h	31h	52h	47h	32h	56h	49h	44h
Character	R	G	1	R	G	2	V	I	D	
	DVI			HDMI			SDI1			
Hexadecimal	44h	56h	49h	48h	44h	31h	53h	44h	31h	
Character	D	V	I	H	D	1	S	D	1	
	SDI2									
Hexadecimal	53h	44h	32h							
Character	S	D	2							

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	49h	3Ah	*1	*3	*5	03h
Character		M	S	I	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- ER401 is returned when SD1/SD2 are selected by DW11K.

ER401 is returned when SD2 is selected by DZ10K.

If the combination with input of sub-window is not possible, ER402 is returned.

## 2.165. P IN P - MAIN WINDOW - SIZE - INTERLOCKED [MSL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	4Ch	3Ah
Character		A	D	Z	Z	;	M	S	L	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	4Ch	3Ah	*1	03h
Character		M	S	L	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.166. P IN P - MAIN WINDOW - SIZE - VERTICAL [MSV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	56h	3Ah
Character		A	D	Z	Z	;	M	S	V	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

	10	11	12	13
Hexadecimal	31h	30h	31h	31h
Character	1	0	1	1
	97	98	99	100
Hexadecimal	39h	37h	39h	38h
Character	9	7	9	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	56h	3Ah	*1	*3	*5	03h
Character		M	S	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.167. P IN P - MAIN WINDOW - SIZE - HORIZONTAL [MSH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	48h	3Ah
Character		A	D	Z	Z	;	M	S	H	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

	10	11	12	13
Hexadecimal	31h	30h	31h	31h
Character	1	0	1	1
	97	98	99	100
Hexadecimal	39h	37h	39h	38h
Character	9	7	9	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	48h	3Ah	*1	*3	*5	03h
Character		M	S	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.168. P IN P - MAIN WINDOW - SIZE - BOTH [MSZ]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	53h	5Ah	3Ah
Character		A	D	Z	Z	;	M	S	Z	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

	10		11		12		13	
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h
Character	1	0	1	1	1	2	1	3
	97		98		99		100	
Hexadecimal	39h	37h	39h	38h	39h	39h	31h	30h
Character	9	7	9	8	9	9	1	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	5Ah	3Ah	*1	*3	*5	03h
Character		M	S	Z	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.169. P IN P - MAIN WINDOW - POSITION – VERTICAL [MPV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	50h	56h	3Ah
Character		A	D	Z	Z	;	M	P	V	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6, \*7, \*8)

PT-DZ13K/DZ10K

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

PT-DS12K

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	5

PT-DW11K

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	50h	56h	3Ah	*1	*3	*5	*7	03h
Character		M	P	V	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.170. P IN P - MAIN WINDOW - POSITION - HORIZONTAL [MPH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	50h	48h	3Ah
Character		A	D	Z	Z	;	M	P	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2, \*3, \*4, \*5, \*6, \*7, \*8)

PT-DZ13K/DZ10K

PT-DZ13K/DZ10K	-928				-927				-926			
	Hexadecimal	2Dh	39h	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h
Character	-	9	2	8	-	9	2	7	-	9	2	6
		+926				+927				+928		
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

PT-DS12K

PT-DS12K	-668				-667				-666			
	Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
		+666				+667				+668		
Hexadecimal	2Bh	36h	36h	36h	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	6	6	+	6	6	7	+	6	6	8

PT-DW11K

PT-DW11K	-651				-650				-649			
	Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h
Character	-	6	5	1	-	6	5	0	-	6	4	9
		+649				+650				+651		
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	50h	48h	3Ah	*1	*3	*5	*7	03h
Character		M	P	H	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	o	o	x	o	o	o	x

## 2.171. P IN P - SUB WINDOW [SIS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	49h	53h	3Ah
Character		A	D	Z	Z	;	S	I	S	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

- Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

PT-DW11K	RGB1			RGB2			Video		
	Hexadecimal	52h	47h	31h	52h	47h	32h	56h	49h
Character	R	G	1	R	G	2	V	I	D
		+DVI			+HDMI			+SDI1	
Hexadecimal	44h	56h	49h	48h	44h	31h	53h	44h	31h
Character	D	V	I	H	D	1	S	D	1
		+SDI2							
Hexadecimal	53h	44h	32h						
Character	S	D	2						

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	49h	53h	3Ah	*1	*3	*5	03h
Character		S	I	S	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	o	o	x	o	o	o	x

- Notes:

- ER401 is returned when SD1/SD2 are selected by DW11K.
- ER401 is returned when SD2 is selected by DZ10K.
- If the combination with input of main-window is not possible, ER402 is returned.

## 2.172. P IN P – SUB WINDOW – SIZE – INTERLOCKED [SSL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	4Ch	3Ah
Character		A	D	Z	Z	;	S	S	L	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	4Ch	3Ah	*1	03h
Character		S	S	L	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.173. P IN P – SUB WINDOW – SIZE – VERTICAL [SSV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	56h	3Ah
Character		A	D	Z	Z	;	S	S	V	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

	10	11	12	13
Hexadecimal	31h	30h	31h	31h
Character	1	0	1	1
	97	98	99	100
Hexadecimal	39h	37h	39h	38h
Character	9	7	9	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	56h	3Ah	*1	*3	*5	03h
Character		S	S	V	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.174. P IN P – SUB WINDOW – SIZE – HORIZONTAL [SSH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	48h	3Ah
Character		A	D	Z	Z	;	S	S	H	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

● Parameters(\*1,\*2, \*3, \*4, \*5, \*6)

	10	11	12	13
Hexadecimal	31h	30h	31h	31h
Character	1	0	1	1
	97	98	99	100
Hexadecimal	39h	37h	39h	38h
Character	9	7	9	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	48h	3Ah	*1	*3	*5	03h
Character		S	S	H	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.175. P IN P – SUB WINDOW – SIZE – BOTH [SSZ]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	53h	5Ah	3Ah
Character		A	D	Z	Z	;	S	S	Z	:
Hexadecimal	*1	*3	*5	03h						
Character	*2	*4	*6							

### ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	10		11		12		13		
Hexadecimal	31h	30h	31h	31h	31h	32h	31h	33h	
Character	1	0	1	1	1	2	1	3	
	97		98		99		100		
Hexadecimal	39h	37h	39h	38h	39h	39h	31h	30h	30h
Character	9	7	9	8	9	9	1	0	0

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	5Ah	3Ah	*1	*3	*5	03h
Character		S	S	Z	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.176. P IN P – SUB WINDOW – POSITION – VERTICAL [SPV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	50h	56h	3Ah
Character		A	D	Z	Z	;	S	P	V	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

### ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

PT-DZ13K/DZ10K

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

PT-DS12K

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	5

PT-DW11K

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	50h	56h	3Ah	*1	*3	*5	*7	03h
Character		S	P	V	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.177. P IN P - MAIN WINDOW - POSITION – HORIZONTAL [SPH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	53h	50h	48h	3Ah
Character		A	D	Z	Z	;	S	P	H	:
Hexadecimal	*1	*3	*5	*7	03h					
Character	*2	*4	*6	*8						

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

PT-DZ13K/DZ10K

Hexadecimal	-928				-927				-926			
	2Dh	39h	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
		+926				+927				+928		
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
	+	9	2	6	+	9	2	7	+	9	2	8

PT-DS12K

Hexadecimal	-668				-667				-666			
	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
		+666				+667				+668		
Hexadecimal	2Bh	36h	36h	36h	2Bh	36h	36h	37h	2Bh	36h	36h	38h
	+	6	6	6	+	6	6	7	+	6	6	8

PT-DW11K

Hexadecimal	-651				-650				-649			
	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
		+649				+650				+651		
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
	+	6	4	9	+	6	5	0	+	6	5	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	50h	48h	3Ah	*1	*3	*5	*7	03h
Character		S	P	H	:	*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	o	o	x	o	o	o	x

## 2.178. P IN P - SUB WINDOW - CLOCK PHASE [VXX:SCPIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	43h	50h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	S	C	P	I	0	=	+	*2	*4	*6

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

Hexadecimal	0					1				
	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1
	30									
Hexadecimal	30h	33h	31h							
Character	0	0	0	3	0	0	0	0	3	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	43h	50h	49h	30h
Character		V	X	X	:	S	C	P	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	o	o	x	o	o	o	x

- Notes:

• In the case of no signal, ER401 is returned.

## 2.179. P IN P - FRAME LOCK [PFL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	46h	4Ch	3Ah
Character		A	D	Z	Z	;	P	F	L	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	50h	46h	4Ch	3Ah	*1	03h
Character		P	F	L	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.180. P IN P - TYPE [PTP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	50h	54h	50h	3Ah
Character		A	D	Z	Z	;	P	T	P	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	50h	54h	50h	3Ah	*1	03h
Character		P	T	P	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.181. BRIGHTNESS CONTROL - GAIN [VXX:TGAIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	54h	47h	41h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	T	G	A	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	20%					21%				
Hexadecimal	30h	30h	30h	32h	30h	30h	30h	30h	32h	31h
Character	0	0	0	2	0	0	0	0	2	1
	99%					100%				
Hexadecimal	30h	30h	30h	39h	39h	30h	30h	31h	30h	30h
Character	0	0	0	9	9	0	0	1	0	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	54h	47h	41h	49h	30h
Character		V	X	X	:	T	G	A	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.182. BRIGHTNESS CONTROL – SETUP – MODE [VXX:BCMIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	42h	43h	4Dh	49h	30h	3Dh	2Bh	*1	*3	*5
Character	B	C	M	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	1	
	PC									
Character	0	0	0	0	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	42h	43h	4Dh	49h	30h
Character		V	X	X	:	B	C	M	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.183. BRIGHTNESS CONTROL – SETUP – LINK [VXX:BCLIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	42h	43h	4Ch	49h	30h	3Dh	2Bh	*1	*3	*5
Character	B	C	L	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					GROUP A				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	1	
	GROUP B					GROUP C				
Character	0	0	0	0	2	0	0	0	0	3
	GROUP D									
Character	0	0	0	0	4					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	42h	43h	4Ch	49h	30h
Character		V	X	X	:	B	C	L	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.184. BRIGHTNESS CONTROL – SETUP – APPLY [VXX:BCSIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	42h	43h	53h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	B	C	S	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	APPLY				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	42h	43h	53h	49h	30h
Character		V	X	X	:	B	C	S	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.185. SCHEDULE [VXX:SCH10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	43h	48h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	S	C	H	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	43h	48h	49h	30h
Character		V	X	X	:	S	C	H	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.186. SCHEDULE – PROGRAM ASSIGN [VXX:SPGI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	50h	47h	49h	*1	3Dh	2Bh	*3	*5	*7
Character	S	P	G	I	*2	=	+	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2)

	Sun	Mon	Tue	Wed	Thu	Fri	Sat
Hexadecimal	30h	31h	32h	33h	34h	35h	36h
Character	0	1	2	3	4	5	6

● Parameters(\*3, \*4, \*5, \*6, \*7, \*8, \*9, \*10, \*11, \*12)

	OFF					PROGRAM 1					PROGRAM 2				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	PROGRAM 3					PROGRAM 4					PROGRAM 5				
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	3	0	0	0	0	4	0	0	0	0	5
	PROGRAM 6					PROGRAM 7									
Hexadecimal	30h	30h	30h	30h	36h	30h	30h	30h	30h	37h					
Character	0	0	0	0	6	0	0	0	0	7					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	50h	47h	49h	*1
Character		V	X	X	:	S	P	G	I	*2
Hexadecimal	3Dh	2Bh	*3	*5	*7	*9	*11	03h		
Character	=	+	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.187. SCHEDULE – COMMAND SETTING [VXX:SCCS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	43h	43h	53h	*1	3Dh	*3	*5	*7	*9
Character	S	C	C	S	*2	=	*4	*6	*8	*10
Hexadecimal	*11	*13	*15	*17	03h					
Character	*12	*14	*16	*18						

● Parameters(\*1,\*2)

	PROGRAM 1	PROGRAM 2	PROGRAM 3	PROGRAM 4
Hexadecimal	31h	32h	33h	34h
Character	1	2	3	4
	PROGRAM 5	PROGRAM 6	PROGRAM 7	
Hexadecimal	35h	36h	37h	
Character	5	6	7	

● Parameters(\*3, \*4, \*5, \*6)

	COMMAND 1		COMMAND 2		COMMAND 3		COMMAND 4	
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	COMMAND 13		COMMAND 14		COMMAND 15		COMMAND 16	
Hexadecimal	31h	33h	31h	34h	31h	35h	31h	36h
Character	1	3	1	4	1	5	1	6

● Parameters(\*7, \*8, \*9, \*10)

	COMMAND Del		STANDBY		POWER ON		SHUTTER OPEN		SHUTTER CLOSE	
Hexadecimal	30h	30h	31h	30h	31h	31h	32h	30h	32h	31h
Character	0	0	1	0	1	1	2	0	2	1
	RGB1 INPUT		RGB2 INPUT		Video INPUT		DVI-D INPUT		SDI1 INPUT	
Hexadecimal	33h	31h	33h	32h	34h	31h	35h	31h	35h	32h
Character	3	1	3	2	4	1	5	1	5	2
	HDMI INPUT		SDI2 INPUT		LAMP POWER HIGH		LAMP POWER MIDDLE		LAMP POWER ECO	
Hexadecimal	35h	33h	35h	36h	37h	30h	37h	31h	37h	32h
Character	5	3	5	6	7	0	7	1	7	2
	LAMP SELECT SINGLE		LAMP SELECT DUAL		P IN P	USER1	P IN P	USER2	P IN P	USER3
Hexadecimal	38h	31h	38h	32h	39h	31h	39h	32h	39h	33h
Character	8	1	8	2	9	1	9	2	9	3
	P IN P OFF									
Hexadecimal	39h	39h								
Character	9	9								

● Parameters(\*11, \*12, \*13, \*14, \*15, \*16, \*17, \*18)

	00:00				00:01				00:02			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	1	0	0	0	2
	23:57				23:58				23:59			
Hexadecimal	32h	33h	35h	37h	32h	33h	35h	38h	32h	33h	35h	39h
Character	2	3	5	7	2	3	5	8	2	3	5	9

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	43h	43h	53h	*1
Character		V	X	X	:	S	C	C	S	*2
Hexadecimal	3Dh	2Bh	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	+	*4	*6	*8	*10	*12	*14	*16	*18

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.188. NO SIGNAL SHUT-OFF [OAF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	41h	46h	3Ah
Character		A	D	Z	Z	;	0	A	F	:
Hexadecimal	*1	*3	03h							
Character	*2	*4								

● Parameters(\*1,\*2,\*3,\*4)

	DISABLE		10 MIN.		20 MIN.		30 MIN.		40 MIN.	
Hexadecimal	30h	30h	31h	30h	32h	30h	33h	30h	34h	30h
Character	0	0	1	0	2	0	3	0	4	0
	50 MIN.		60 MIN.		70 MIN.		80 MIN.		90 MIN.	
Hexadecimal	35h	30h	36h	30h	37h	30h	38h	30h	39h	30h
Character	5	0	6	0	7	0	8	0	9	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	41h	46h	3Ah	*1	*3	03h
Character		O	A	F	:	*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.189. DATE AND TIME – DATE SETTING [TSD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	54h	53h	44h	3Ah
Character		A	D	Z	Z	;	T	S	D	:
Hexadecimal	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*d2	*w	03h
Character										

● Parameters

\*y1～\*y4 : Year (4 digits)

\*m1～\*m2 : Month (2 digits)

\*d1～\*d2 : Day (2 digits)

\*w : Day of the week(Mon=1, Tue=2, Wed=3, Thu=4, Fri=5, Sat=6, Sun=7)

Set it by UTC ( Coordinated Universal Time)

Example: Tuesday, August 17, 2010

	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*d2	*w
Hexadecimal	32h	30h	31h	30h	30h	38h	31h	37h	32h
Character	2	0	1	0	0	8	1	7	2

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	54h	53h	44h	3Ah	*y1	*y2	
Character		T	S	D	:			
Hexadecimal	*y3	*y4	*m1	*m2	*d1	*d2	*w	03h
Character								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.190. DATE AND TIME – TIME SETTING [TST]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	54h	53h	54h	3Ah
Character		A	D	Z	Z	;	T	S	T	:
Hexadecimal	*h1	*h2	*m1	*m2	*s1	*s2	03h			
Character										

● Parameters

\*h1～\*h2 : Hour (2 digits)

\*m1～\*m2 : Minute (2 digits)

\*s1～\*s2 : Second (2 digits)

Set it by UTC ( Coordinated Universal Time)

Example: 3 seconds at p.m. 3:45

	*h1	*h2	*m1	*m2	*s1	*s2
Hexadecimal	31h	35h	34h	35h	30h	33h
Character	1	5	4	5	0	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	54h	53h	54h	3Ah		
Character		T	S	T	:		
Hexadecimal	*h1	*h2	*m1	*m2	*s1	*s2	03h
Character							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

## 2.191. ON-SCREEN DISPLAY – INPUT GUIDE [OID]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	49h	44h	3Ah
Character		A	D	Z	Z	;	0	I	D	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	49h	44h	3Ah	*1	03h
Character		O	I	D	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.192. ON-SCREEN DISPLAY – WARNING MESSAGE [VXX:WMDIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	57h	4Dh	44h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	W	M	D	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	57h	4Dh	44h	49h	30h
Character		V	X	X	:	W	M	D	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	×	○	○	○	×

## 2.193. ON-SCREEN DISPLAY – OSD DESIGN [MOD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	4Fh	44h	3Ah
Character		A	D	Z	Z	:	M	O	D	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	1 (yellow)	2 (blue)	3 (white)	4 (green)	5 (peach)	6 (brown)
Hexadecimal	30h	31h	32h	33h	34h	35h
Character	0	1	2	3	4	5

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	4Fh	44h	3Ah	*1	03h
Character		M	O	D	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.194. ON-SCREEN DISPLAY – OSD POSITION [ODP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	44h	50h	3Ah
Character		A	D	Z	Z	:	O	D	P	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	Upper left	Center left	Bottom left	Top center	Center
Hexadecimal	31h	32h	33h	34h	35h
Character	1	2	3	4	5
	Bottom center	Upper right	Center right	Bottom right	
Hexadecimal	36h	37h	38h	39h	
Character	6	7	8	9	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	44h	50h	3Ah	*1	03h
Character		O	D	P	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.195. ON-SCREEN DISPLAY – OSD MEMORY [VXX:OMYIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Fh	4Dh	59h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	O	M	Y	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Fh	4Dh	59h	49h	30h
Character		V	X	X	:	0	M	Y	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.196. STARTUP LOGO [MLO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	4Ch	4Fh	3Ah
Character		A	D	Z	Z	;	M	L	0	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	NONE		USER LOGO		DEFAULT LOGO	
	Hexadecimal	30h		31h		32h
Character	0		1		2	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	4Ch	4Fh	3Ah	*1	03h
Character		M	L	0	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.197. BACK COLOR [OBC]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Fh	42h	43h	3Ah
Character		A	D	Z	Z	;	0	B	C	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	BLUE		BLACK		USER LOGO		DEFAULT LOGO	
	Hexadecimal	30h		31h		32h		33h
Character	0		1		2		3	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	42h	43h	3Ah	*1	03h
Character		0	B	C	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.198. AIR FILTER TYPE [MFS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	4Dh	46h	53h	3Ah
Character		A	D	Z	Z	;	M	F	S	:
Hexadecimal	*1	03h								
Character	*2									

● Parameters(\*1,\*2)

	NORMAL		SPECIAL	
	Hexadecimal	33h		34h
Character	3		4	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	46h	53h	3Ah	*1	03h
Character		M	F	S	:	*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.199. STANDBY MODE [VXX:STMIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	54h	4Dh	49h	30h	3Dh	2Bh	*1	*3	*5
Character	S	T	M	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					ECO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	33h
Character	0	0	0	0	0	0	0	0	0	3

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	4Dh	49h	30h
Character		V	X	X	:	S	T	M	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	○	○	○	○	○	○	○	×

## 2.200. LENS CALIBRATION [VXX:LNSIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	4Ch	4Eh	53h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	L	N	S	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	EXECUTE				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	53h	49h	30h
Character		V	X	X	:	L	N	S	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.201. LENS HOME POSITION [VXX:LNSI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	4Ch	4Eh	53h	49h	31h	3Dh	2Dh	*1	*3	*5
Character	L	N	S	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	EXECUTE				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	53h	49h	31h
Character		V	X	X	:	L	N	S	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.202. LENS SHIFT - HORIZONTAL [VXX:LNSI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	53h	49h	32h	3Dh	2Bh	*1	*3	*5
Character	L	N	S	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	Slow : +					Slow : -				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	Normal : +					Normal : -				
Hexadecimal	30h	30h	31h	30h	30h	30h	30h	31h	30h	31h
Character	0	0	1	0	0	0	0	1	0	1
	Fast : +					Fast : -				
Hexadecimal	30h	30h	32h	30h	30h	30h	30h	32h	30h	31h
Character	0	0	2	0	0	0	0	2	0	1

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	53h	49h	32h
Character		V	X	X	:	L	N	S	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.203. LENS SHIFT - VERTICAL [VXX:LNSI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	53h	49h	33h	3Dh	2Bh	*1	*3	*5
Character	L	N	S	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	Slow : +					Slow : -				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	Normal : +					Normal : -				
Hexadecimal	30h	30h	31h	30h	30h	30h	30h	31h	30h	31h
Character	0	0	1	0	0	0	0	1	0	1
	Fast : +					Fast : -				
Hexadecimal	30h	30h	32h	30h	30h	30h	30h	32h	30h	31h
Character	0	0	2	0	0	0	0	2	0	1

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	53h	49h	33h
Character		V	X	X	:	L	N	S	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.204. LENS FOUCS [VXX:LNSI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	53h	49h	34h	3Dh	2Bh	*1	*3	*5
Character	L	N	S	I	4	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	Slow : +					Slow : -				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
Normal : +					Normal : -					
Hexadecimal	30h	30h	31h	30h	30h	30h	30h	31h	30h	31h
Character	0	0	1	0	0	0	0	1	0	1
Fast : +					Fast : -					
Hexadecimal	30h	30h	32h	30h	30h	30h	30h	32h	30h	31h
Character	0	0	2	0	0	0	0	2	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	53h	49h	34h
Character		V	X	X	:	L	N	S	I	4
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.205. LENS ZOOM [VXX:LNSI5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	53h	49h	35h	3Dh	2Bh	*1	*3	*5
Character	L	N	S	I	5	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	Slow : +					Slow : -				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
Normal : +					Normal : -					
Hexadecimal	30h	30h	31h	30h	30h	30h	30h	31h	30h	31h
Character	0	0	1	0	0	0	0	1	0	1
Fast : +					Fast : -					
Hexadecimal	30h	30h	32h	30h	30h	30h	30h	32h	30h	31h
Character	0	0	2	0	0	0	0	2	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	53h	49h	35h
Character		V	X	X	:	L	N	S	I	5
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.206. RGB IN – RGB1 INPUT SETTING [VXX:RYCI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	52h	59h	43h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	R	Y	C	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	RGB / YPBPR					Y/C				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	52h	59h	43h	49h	31h
Character		V	X	X	:	R	Y	C	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.207. SDI IN - SDI LINK [VXX:SLKI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	4Ch	4Bh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	S	L	K	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	SINGLE LINK					DUAL LINK				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	4Ch	4Bh	49h	31h
Character		V	X	X	:	S	L	K	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

·DW11K/DZ10K is returned ER401.

## 2.208. SDI IN - BIT DEPTH [VXX:SBTI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	42h	54h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	S	B	T	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					12-bit				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
10-bit										
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	42h	54h	49h	31h
Character		V	X	X	:	S	B	T	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

·DW11K is returned ER401.

## 2.209. SDI IN - BIT DEPTH (DUAL) [VXX:SBTI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	42h	54h	49h	33h	3Dh	2Bh	*1	*3	*5
Character	S	B	T	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					12-bit				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	10-bit									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	42h	54h	49h	33h
Character		V	X	X	:	S	B	T	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DW11K is returned ER401.

## 2.210. SDI IN - 3G-SDI MAPPING [VXX:SGMI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	47h	4Dh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	S	G	M	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					LEVEL A				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	LEVEL B									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	47h	4Dh	49h	31h
Character		V	X	X	:	S	G	M	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DW11K is returned ER401.

## 2.211. 3D SETTINGS - 3D SYSTEM SETTING [VXX:DSYI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	53h	59h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	S	Y	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	SINGLE					DUAL (LEFT)				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	DUAL (RIGHT)									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	53h	59h	49h	31h
Character		V	X	X	:	D	S	Y	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- DZ10K is returned ER401.
- During 3D PICTURE BALANCE adjustment, ER401 is returned.

## 2.212. 3D SETTINGS – 3D FILTER [VXX:DFTI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	46h	54h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	F	T	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					OFF				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1
	ON									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	46h	54h	49h	31h
Character		V	X	X	:	D	F	T	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- DZ10K is returned ER401.

## 2.213. 3D SETTINGS – 3D SYNC SETTING – 3D SYNC MODE [VXX:DSNI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44	53	4E	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	S	N	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					1				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1
	2					3				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
	4					5				
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5
	6					7				
Hexadecimal	30h	30h	30h	30h	36h	30h	30h	30h	30h	37h
Character	0	0	0	0	6	0	0	0	0	7
	8					9				
Hexadecimal	30h	30h	30h	30h	38h	30h	30h	30h	30h	39h
Character	0	0	0	0	8	0	0	0	0	9
	10					11				
Hexadecimal	30h	30h	30h	31h	30h	30h	30h	31h	31h	
Character	0	0	0	1	0	0	0	1	1	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44	53	4E	49h	31h
Character		V	X	X	:	D	S	N	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.214. 3D SETTINGS – 3D SYNC SETTING – STEREO SYNC OUTPUT DELAY [VXX:DSNI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44	53	4E	49h	32h	3Dh	2Bh	*1	*3	*5
Character	D	S	N	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					10				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h
Character	0	0	0	0	0	0	0	0	1	0
24990					25000					
Hexadecimal	32h	34h	39h	39h	30h	32h	35h	30h	30h	30h
Character	2	4	9	9	0	2	5	0	0	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44	53	4E	49h	32h
Character		V	X	X	:	D	S	N	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· A setup value will be to 0 ~ 25000 at 10 step.

· DZ10K is returned ER401.

## 2.215. 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:RGB1 RIGHT:RGB2 [VXX:DSMI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	53h	4Dh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	S	M	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	53h	4Dh	49h	31h
Character		V	X	X	:	D	S	M	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.216. 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:HDMI RIGHT:DVI-D [VXX:DSM12]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	53h	4Dh	49h	32h	3Dh	2Bh	*1	*3	*5
Character	D	S	M	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	53h	4Dh	49h	32h
Character		V	X	X	:	D	S	M	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.217. 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:SDI1 RIGHT:SDI2 [VXX:DSM13]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	53h	4Dh	49h	33h	3Dh	2Bh	*1	*3	*5
Character	D	S	M	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	53h	4Dh	49h	33h
Character		V	X	X	:	D	S	M	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.218. 3D SETTINGS – 3D INPUT FORMAT [VXX:DIFI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	49h	46h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	I	F	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					NATIVE (2D)				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
SIMULTANEOUS										
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
TOP AND BOTTOM										
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5
FRAME SEQUENTIAL										
Hexadecimal	30h	30h	30h	30h	34h					
Character	0	0	0	0	6					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	49h	46h	49h	31h
Character		V	X	X	:	D	I	F	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.219. 3D SETTINGS – LEFT/RIGHT SWAP [VXX:DSWI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	53h	57h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	S	W	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					SWAPPED				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	53h	57h	49h	31h
Character		V	X	X	:	D	S	W	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.220. 3D SETTINGS – 3D COLOR MATCHING [VXX:DCM11]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	43h	4Dh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	C	M	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	SHARED 2D/3D					SEPARATE 2D/3D				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	43h	4Dh	49h	31h
Character		V	X	X	:	D	C	M	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.221. 3D SETTINGS – 3D PICTURE BALANCE – CONTRAST [VXX:DBAI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	42h	41h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	B	A	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	38h	31h	
Character	0	0	0	8	0	0	0	8	1	
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	31h
Character		V	X	X	:	D	B	A	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.222. 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH RED [VXX:DBAI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	42h	41h	49h	32h	3Dh	2Bh	*1	*3	*5
Character	D	B	A	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	38h	31h	
Character	0	0	0	8	0	0	0	8	1	
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	32h
Character		V	X	X	:	D	B	A	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.223. 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH GREEN [VXX:DBAI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	42h	41h	49h	33h	3Dh	2Bh	*1	*3	*5
Character	D	B	A	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	38h	31h	
Character	0	0	0	8	0	0	0	8	1	
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	33h
Character		V	X	X	:	D	B	A	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.224. 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH BLUE [VXX:DBA14]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	42h	41h	49h	34h	3Dh	2Bh	*1	*3	*5
Character	D	B	A	I	4	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	30h	38h	31h
Character	0	0	0	8	0	0	0	0	8	1
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	34h
Character		V	X	X	:	D	B	A	I	4
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.225. 3D SETTINGS – 3D PICTURE BALANCE – BRIGHTNESS [VXX:DBA15]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	42h	41h	49h	35h	3Dh	*1	*3	*5	*7
Character	D	B	A	I	5	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11, \*12)

	-8						-7					
Hexadecimal	30h	30h	30h	30h	30h	38hh	30h	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	0	7
	+7						+8					
Hexadecimal	30h	30h	30h	30h	30h	37h	30h	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	0	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	35h
Character		V	X	X	:	D	B	A	I	5
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	03h		
Character	=	*2	*4	*6	*8	*10	*12			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.226. 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW RED [VXX:DBAI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	42h	41h	49h	36h	3Dh	*1	*3	*5	*7
Character	D	B	A	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-8						-7				
Hexadecimal	30h	30h	30h	30h	30h	38hh	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	7
	+7						+8				
Hexadecimal	30h	30h	30h	30h	30h	37h	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	8

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	36h
Character		V	X	X	:	D	B	A	I	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*10	03h		
Character	=	*2	*4	*6	*8	*10	*11			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.227. 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW GREEN [VXX:DBAI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	42h	41h	49h	37h	3Dh	*1	*3	*5	*7
Character	D	B	A	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-8						-7				
Hexadecimal	30h	30h	30h	30h	30h	38hh	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	7
	+7						+8				
Hexadecimal	30h	30h	30h	30h	30h	37h	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	8

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	37h
Character		V	X	X	:	D	B	A	I	7
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*10	03h		
Character	=	*2	*4	*6	*8	*10	*11			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.228. 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW BLUE [VXX:DBAI8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	42h	41h	49h	38h	3Dh	*1	*3	*5	*7
Character	D	B	A	I	8	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-8						-7				
Hexadecimal	30h	30h	30h	30h	30h	38h	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	7
	+7						+8				
Hexadecimal	30h	30h	30h	30h	30h	37h	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	38h
Character		V	X	X	:	D	B	A	I	8
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*10	03h		
Character	=	*2	*4	*6	*8	*10	*11			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.229. 3D SETTINGS – 3D PICTURE BALANCE – COLOR DBA19]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	42h	41h	49h	39h	3Dh	2Bh	*1	*3	*5
Character	D	B	A	I	9	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	30h	38h	31h
Character	0	0	0	8	0	0	0	0	8	1
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	39h
Character		V	X	X	:	D	B	A	I	9
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.230. 3D SETTINGS – 3D PICTURE BALANCE – TINT [VXX:DBAIA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	42h	41h	49h	41h	3Dh	*1	*3	*5	*7
Character	D	B	A	I	A	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11, \*12)

	-8						-7					
Hexadecimal	30h	30h	30h	30h	30h	38h	30h	30h	30h	30h	37h	
Character	-	0	0	0	0	8	-	0	0	0	0	7
	+7						+8					
Hexadecimal	30h	30h	30h	30h	30h	37h	30h	30h	30h	30h	38h	
Character	+	0	0	0	0	7	+	0	0	0	0	8

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	42h	41h	49h	49h
Character		V	X	X	:	D	B	A	I	A
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*10	03h		
Character	=	*2	*4	*6	*8	*10	*11			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· DZ10K is returned ER401.

## 2.231. 3D SETTINGS – DARK TIME SETTING [VXX:DDTS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	44h	54h	53h	31h	3Dh	2Bh	*1	*3	*5
Character	D	D	T	S	1	=	+	*2	*4	*6
Hexadecimal	03h									
Character										

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0.5 ms			1.0 ms			1.5 ms			
Hexadecimal	30h	2Eh	35h	31h	2Eh	30h	31h	2Eh	35h	
Character	0	.	5	1	.	0	1	.	5	
	2.0 ms			2.5 ms			2.7 ms			
Hexadecimal	32h	2Eh	30h	32h	2Eh	35h	32h	2Eh	37h	
Character	2	.	0	2	.	5	2	.	7	

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	44h	54h	53h	31h
Character		V	X	X	:	D	D	T	S	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.232. 3D SETTINGS – 3D FRAME DELAY [VXX:DFDI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	44h	46h	44h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	F	D	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0 us					25000 us					
Hexadecimal	30h	30h	30h	30h	30h	32h	35h	30h	30h	30h	
Character	0	0	0	0	0	2	5	0	0	0	

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	46h	44h	49h	31h
Character		V	X	X	:	D	F	D	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

·DZ10K is returned ER401.

## 2.233. 3D SETTINGS – 3D TEST MODE [VXX:DTSI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal				49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	T	S	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					SIDE BY SIDE					
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	0	1	
	LEFT/LEFT					RIGHT/RIGHT					
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h	
Character	0	0	0	0	2	0	0	0	0	3	
	LEFT/BLACK					BLACK/RIGHT					
Hexadecimal	30h	30h	30h	30h	35h	30h	30h	30h	30h	36h	
Character	0	0	0	0	4	0	0	0	0	5	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah				49h	31h
Character		V	X	X	:	D	T	S	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- DZ10K is returned ER401.
- During 3D PICTURE BALANCE adjustment, ER401 is returned.

## 2.234. 3D SETTINGS – SAFETY PRECAUTIONS MESSAGE [VXX:DMGI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	44h	4Dh	47h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	D	M	G	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	44h	4Dh	47h	49h	31h
Character		V	X	X	:	D	M	G	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- DZ10K is returned ER401.

## 2.235. NAME CHANGE – PICTURE MODE USER NAME [VXX:NCGSO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	3Ah	4Eh
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	43h	47h	53h	30h	3Dh	*1	*3	*5	*7	*9
Character	C	G	S	0	=	*2	*4	*6	*8	*10
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	03h
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30	

● Parameters(\*1,\*2,\*,\*29,\*30)

	Name						
Hexadecimal	n1h	n2h	n3h	...		n14h	n15h
Character	p1	p2	p3	...		p14	p15

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	30h
Character		V	X	X	:	N	C	G	S	0
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	03h			
Character	*20	*22	*24	*26	*28	*30				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

- Name can be set in undefined length.

2.236. NAME CHANGE – COLOR TEMPERATURE USER1 NAME [VXX:NCGS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character		A	D	Z	Z	:	V	X	X	:	N
Hexadecimal	43h	47h	53h	31h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	1	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	03h	
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30		

- Parameters(\*1,\*2,...,\*29,\*30)

		Name					
Hexadecimal	n1h	n2h	n3h	...		n14h	n15h
Character	p1	p2	p3	...		p14	p15

- ### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	31h
Character		V	X	X	:	N	C	G	S	1
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	03h			
Character	*20	*22	*24	*26	*28	*30				

### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

- Notes:

- Name can be set in undefined length.

2.237. NAME CHANGE – COLOR TEMPERATURE USER2 NAME [VXX:NCGS3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character	A	D	Z	Z	;	V	X	X	:	N	
Hexadecimal	43h	47h	53h	33h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	3	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	03h	
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30		

- ### ● Parameters(\*1,\*2,...,\*29,\*30)

Parameters (A, B, C, D, E)			Name				
Hexadecimal	n1h	n2h	n3h	...	n14h	n15h	
Character	p1	p2	p3	...	p14	p15	

- ### ● Response (Callback)

In the period when the command can be accepted

In the period when the command can be accepted										
Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	33h
Character		V	X	X	:	N	C	G	S	3
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	03h			
Character	*20	*22	*24	*26	*28	*30				

### Acceptability

Acceptability	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
X	X	X	O	O	X	O	O	O	X

- Notes:

- Name can be set in undefined length.

2.238. NAME CHANGE – GAMMA USER1 NAME [VXX:NCGS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character		A	D	Z	Z	;	V	X	X	:	N
Hexadecimal	43h	47h	53h	32h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	2	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	03h	
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30		

- ### ● Parameters(\*1,\*2,...,\*29,\*30)

		Name					
Hexadecimal	n1h	n2h	n3h	...		n14h	n15h
Character	p1	p2	p3	...		p14	p15

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	32h
Character		V	X	X	:	N	C	G	S	2
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	03h			
Character	*20	*22	*24	*26	*28	*30				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· Name can be set in undefined length..

### 2.239. NAME CHANGE – GAMMA USER2 NAME [VXX:NCGS4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character		A	D	Z	Z	:	V	X	X	:	N
Hexadecimal	43h	47h	53h	34h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	4	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	03h	
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30		

● Parameters(\*1,\*2,⋯,\*29,\*30)

Name						
Hexadecimal	n1h	n2h	n3h	...	n14h	n15h
Character	p1	p2	p3	...	p14	p15

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	34h
Character		V	X	X	:	N	C	G	S	4
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	03h			
Character	*20	*22	*24	*26	*28	*30				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

● Notes:

· Name can be set in undefined length..

### 2.240. NAME CHANGE – LENS MEMORY1 NAME [VXX:NCGS5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character		A	D	Z	Z	:	V	X	X	:	N
Hexadecimal	43h	47h	53h	35h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	5	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	*31	03h
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30	*32	

● Parameters(\*1,\*2,⋯,\*31,\*32)

Name						
Hexadecimal	n1h	n2h	n3h	...	n15h	n16h
Character	p1	p2	p3	...	p15	p16

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	35h
Character		V	X	X	:	N	C	G	S	5
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	*31	03h		
Character	*20	*22	*24	*26	*28	*30	*32			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

● Notes:

· Name can be set in undefined length..

2.241. NAME CHANGE – LENS MEMORY2 NAME [VXX:NCGS6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character	A	D	Z	Z	:	V	X	X	:	N	
Hexadecimal	43h	47h	53h	36h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	6	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	*31	03h
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30	*32	

- Parameters(\*1,\*2,⋯,\*31,\*32)

	Name					
Hexadecimal	n1h	n2h	n3h	...	n15h	n16h
Character	p1	p2	p3	...	p15	p16

- ### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	36h
Character		V	X	X	:	N	C	G	S	6
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	*31	03h		
Character	*20	*22	*24	*26	*28	*30	*32			

### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

- Notes:

- Name can be set in undefined length.◦

2.242. NAME CHANGE – LENS MEMORY3 NAME [VXX:NCGS7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character		A	D	Z	Z	;	V	X	X	:	N
Hexadecimal	43h	47h	53h	37h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	7	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	*25	*27	*29	*31	03h
Character	*14	*16	*18	*20	*22	*24	*26	*28	*30	*32	



	Name						
Hexadecimal Character	n1h	n2h	n3h	...	n15h	n16h	
p1	p2	p3	...		p15	p16	

- ### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	37h
Character	V	X	X	:	N	C	G	S	7	
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	*25	*27	*29	*31	03h		
Character	*20	*22	*24	*26	*28	*30	*32			

### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
X	X	X	O	X	O	O	O	O	X

- Notes:

- Name can be set in undefined length.

2.243. NAME CHANGE – PROJECTOR NAME [VXX:NCGS8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah	4Eh
Character		A	D	Z	Z	;	V	X	X	:	N
Hexadecimal	43h	47h	53h	38h	3Dh	*1	*3	*5	*7	*9	*11
Character	C	G	S	8	=	*2	*4	*6	*8	*10	*12
Hexadecimal	*13	*15	*17	*19	*21	*23	03h				
Character	*14	*16	*18	*20	*22	*24					

- ### ● Parameters(\*1.\*2.···.\*23.\*24)

	Name					
Hexadecimal	n1h	n2h	n3h	...	n11h	n12h
Character	p1	p2	p3	...	p11	p12

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	47h	53h	38h
Character		V	X	X	:	N	C	G	S	8
Hexadecimal	3Dh	*1	*3	*5	*7	*9	*11	*13	*15	*17
Character	=	*2	*4	*6	*8	*10	*12	*14	*16	*18
Hexadecimal	*19	*21	*23	03h						
Character	*20	*22	*24							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

● Notes:

- Name can be set in undefined length. (One or more Character necessity)

## 2.244. BRIGHTNESS CONTROL SETUP – CALIBRATION TIME [VXX:BTMI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	42h	54h	4Dh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	B	T	M	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					00:01				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	23:59					00:00				
Hexadecimal	30h	32h	33h	35h	39h	30h	32h	34h	30h	30h
Character	0	2	3	5	9	0	2	4	0	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	42h	54h	4Dh	49h	31h
Character		V	X	X	:	B	T	M	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.245. BRIGHTNESS CONTROL SETUP – CALIBRATION MESSAGE [VXX:BMGI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	42h	4Dh	47h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	B	M	G	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	42h	4Dh	47h	49h	31h
Character		V	X	X	:	B	M	G	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.246. SHUTTER SETTING – FADE IN [VXX:SEFS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	45h	46h	53h	31h	3Dh	*1	*3	*5	03h
Character	S	E	F	S	1	=	*2	*4	*6	

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,)

	OFF (0.0 s)			0.5 s		
Hexadecimal	30h	2Eh	35h	30h	2Eh	35h
Character	0	.	0	0	.	5
	3.5 s			4.0 s		
Hexadecimal	33h	2Eh	35h	34h	2Eh	30h
Character	3	.	5	4	.	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	45h	46h	53h	31h
Character		V	X	X	:	S	E	F	S	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	03h				
Character	=	+	*2	*4	*6					

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	×	○	○	○	×

## 2.247. SHUTTER SETTING – FADE OUT [VXX:SEFS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	45h	46h	53h	32h	3Dh	*1	*3	*5	03h
Character	S	E	F	S	2	=	*2	*4	*6	

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF (0.0 s)			0.5 s		
Hexadecimal	30h	2Eh	35h	30h	2Eh	35h
Character	0	.	0	0	.	5
	3.5 s			4.0 s		
Hexadecimal	33h	2Eh	35h	34h	2Eh	30h
Character	3	.	5	4	.	0

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	45h	46h	53h	32h
Character		V	X	X	:	S	E	F	S	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	03h				
Character	=	+	*2	*4	*6					

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	×	○	○	○	×

## 2.248. SHUTTER SETTING – STARTUP [VXX:SEFI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	45h	46h	49h	33h	3Dh	2Bh	*1	*3	*5
Character	S	E	F	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OPEN					CLOSE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	45h	46h	49h	33h
Character		V	X	X	:	S	E	F	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	×	○	○	○	×

## 2.249. SHUTTER SETTING – SHUT OFF [VXX:SEFI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	45h	46h	49h	34h	3Dh	2Bh	*1	*3	*5
Character	S	E	F	I	4	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OPEN					CLOSE				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	KEEP									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	45h	46h	49h	34h
Character		V	X	X	:	S	E	F	I	4
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	×	○	○	○	×

## 2.250. CUT OFF – RED [VXX:CUTI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	43h	55h	54h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	C	U	T	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	43h	55h	54h	49h	31h
Character		V	X	X	:	C	U	T	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.251. CUT OFF – GREEN [VXX:CUTI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	43h	55h	54h	49h	32h	3Dh	2Bh	*1	*3	*5
Character	C	U	T	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	43h	55h	54h	49h	32h
Character		V	X	X	:	C	U	T	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	×	○	○	○	×

## 2.252. CUT OFF – BLUE [VXX:CUTI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	43h	55h	54h	49h	33h	3Dh	2Bh	*1	*3	*5
Character	C	U	T	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	43h	55h	54h	49h	33h
Character		V	X	X	:	C	U	T	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	x	x	o	o	x	o	o	o	x

## 2.253. RGB IN – RGB1 INPUT SETTING [VXX:RYCI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	52h	59h	43h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	R	Y	C	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	RGB/YPBPR					Y/C				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	52h	59h	43h	49h	31h
Character		V	X	X	:	R	Y	C	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	o	x	o	o	o	o	o	o	x

## 2.254. RGB IN – RGB1 SYNC SLICE LEVEL [VXX:STRIO1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	54h	52h	49h	30h	3Dh	2Bh	*1	*3	*5
Character	S	T	R	I	0	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LOW					HIGH				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	52h	49h	30h
Character		V	X	X	:	S	T	R	I	0
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
x	o	x	o	o	o	o	o	o	x

## 2.255. RGB IN – RGB2 SYNC SLICE LEVEL [VXX:STRI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	54h	52h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	S	T	R	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LOW					HIGH				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	52h	49h	31h
Character		V	X	X	:	S	T	R	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	○	○	○	○	×

## 2.256. SDI IN – SDI1 SIGNAL LEVEL [VXX:SSL11]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	53h	4Ch	49h	31h	3Dh	2Bh	*1	*3	*5
Character	S	S	L	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	64-940					4-1019				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	53h	4Ch	49h	31h
Character		V	X	X	:	S	S	L	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Notes:

·DW11K is returned ER401.

## 2.257. SDI IN – SDI2 SIGNAL LEVEL [VXX:SSL12]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	:	V	X	X	:
Hexadecimal	53h	53h	4Ch	49h	32h	3Dh	2Bh	*1	*3	*5
Character	S	S	L	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	64-940					4-1019				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	53h	4Ch	49h	32h
Character		V	X	X	:	S	S	L	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

- Notes:

·DW11K/DZ10K is returned ER401.

## 2.258. SDI IN – SDI DUAL LINK SIGNAL LEVEL [VXX:SSLI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	53h	53h	4Ch	49h	33h	3Dh	2Bh	*1	*3	*5
Character	S	S	L	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	64-940					4-1019				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	53h	4Ch	49h	33h
Character		V	X	X	:	S	S	L	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	○	×	○	○	×	○	○	○	×

● Notes:

- DW11K/DZ10K is returned ER401.

## 2.259. LENS MEMORY – LENS MEMORY LOAD [VXX:LNM1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	4Dh	49h	31h	3Dh	2Bh	*1	*3	*5
Character	L	N	M	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LENS MEMORY1					LENS MEMORY2				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	4Dh	49h	31h
Character		V	X	X	:	L	N	M	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	○	○	○	○	○	×

## 2.260. LENS MEMORY – LENS MEMORY SAVE [VXX:LNM2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	4Dh	49h	32h	3Dh	2Bh	*1	*3	*5
Character	L	N	M	I	2	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LENS MEMORY1					LENS MEMORY2				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	4Dh	49h	32h
Character		V	X	X	:	L	N	M	I	2
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.261. LENS MEMORY - LENS MEMORY DELETE [VXX:LNMI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Ch	4Eh	4Dh	49h	33h	3Dh	2Bh	*1	*3	*5
Character	L	N	M	I	3	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LENS MEMORY1					LENS MEMORY2				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	LENS MEMORY3									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Ch	4Eh	4Dh	49h	33h
Character		V	X	X	:	L	N	M	I	3
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.262. LENS MEMORY - LENS MEMORY1 NAME DEFAULT [VXX:NCLI5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Eh	43h	4Ch	49h	35h	3Dh	2Bh	*1	*3	*5
Character	N	C	L	I	5	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LENS MEMORY1				
Hexadecimal	30h	30h	30h	30h	32h
Character	0	0	0	0	0

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	4Ch	49h	35h
Character		V	X	X	:	N	C	L	I	5
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.263. LENS MEMORY - LENS MEMORY2 NAME DEFAULT [VXX:NCLI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Eh	43h	4Ch	49h	36h	3Dh	2Bh	*1	*3	*5
Character	N	C	L	I	6	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LENS MEMORY2				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	4Ch	49h	36h
Character		V	X	X	:	N	C	L	I	6
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.264. LENS MEMORY – LENS MEMORY3 NAME DEFAULT [VXX:NCLI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	4Eh	43h	4Ch	49h	37h	3Dh	2Bh	*1	*3	*5
Character	N	C	L	I	7	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

LENS MEMORY3				
Hexadecimal	30h	30h	30h	30h
Character	0	0	0	0

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	4Eh	43h	4Ch	49h	37h
Character		V	X	X	:	N	C	L	I	7
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
×	×	×	○	×	○	○	○	○	×

## 2.265. INITIALIZE – ALL USER DATA [VXX:RSTS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	56h	58h	58h	3Ah
Character		A	D	Z	Z	;	V	X	X	:
Hexadecimal	52h	53h	54h	53h	31h	3Dh	*1	*3	...	*5
Character	R	S	T	S	1	=	*2	*4	...	*6
Hexadecimal	03h									
Character										

- Parameters(\*1,\*2)

	USER INITILIZE	USER RESTORE
Hexadecimal	30h	31h
Character	0	1

- Parameters(\*3,\*4,\*5,\*6)

PASSWORD			
Hexadecimal	X1h	...	Xnh
Character		...	

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	52h	53h	54h	53h	31h
Character		V	X	X	:	R	S	T	S	1
Hexadecimal	3Dh	X1h	...	XnH						
Character	=		...							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	×

- Notes:

- The projector will go into the standby status to reflect the setting values.

## 2.266. QUERY POWER [QPW]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	57h	03h
Character		A	D	Z	Z	;	Q	P	W	
● Response (Callback)										
OFF										
Hexadecimal	02h	30h	30h	30h	03h					
Character		0	0	0						
ON										
Hexadecimal	02h	30h	30h	31h	03h					
Character		0	0	1						
Acceptability										
SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME	
○	○	○	○	○	○	○	○	○	○	○

## 2.267. QUERY FREEZE [QFZ]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	46h	5Ah	03h
Character		A	D	Z	Z	;	Q	F	Z	
● Response (Callback)										
OFF										
Hexadecimal	02h	30h	03h							
Character		0								
ON										
Hexadecimal	02h	31h	03h							
Character		1								
Acceptability										
SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME	
○	×	×	○	○	○	○	○	○	○	○

## 2.268. QUERY SHUTTER [QSH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	48h	03h
Character		A	D	Z	Z	;	Q	S	H	
● Response (Callback)										
OFF										
Hexadecimal	02h	30h	03h							
Character		0								
ON										
Hexadecimal	02h	31h	03h							
Character		1								
Acceptability										
SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME	
○	○	×	○	○	○	○	○	○	○	○

## 2.269. QUERY INPUT SELECT [QIN]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	4Eh	03h
Character		A	D	Z	Z	;	Q	I	N	
● Response (Callback)										
RGB1										
Hexadecimal	02h	52h	47h	31h	03h					
Character		R	G	1						
RGB2										
Hexadecimal	02h	52h	47h	32h	03h					
Character		R	G	2						
VIDEO										
Hexadecimal	02h	56h	49h	44h	03h					
Character		V	I	D						
DVI-D										
Hexadecimal	02h	44h	56h	49h	03h					
Character		D	V	I						
HDMI										
Hexadecimal	02h	48h	44h	31h	03h					
Character		H	D	1						
SDI1(PT-DZ13K/DS12K/DZ10K only)										
Hexadecimal	02h	53	44	31h	03h					
Character		S	D	1						

## SDI2(PT-DZ13K/DS12K only)

Hexadecimal	02h	53	44	32h	03h
Character	S	D		2	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.270. QUERY TEST PATTERN [QTS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	53h	03h
Character	A	D	Z	Z	;	Q	T	S		

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

## ● Parameters(\*1,\*2,\*3,\*4)

	OFF		White		Black		Flag		Reversed Flag	
Hexadecimal	30h	30h	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	0	0	1	0	2	0	3	0	4
	Window		Reversed Window		Focus		Color bar (vertical)		Lamp	
Hexadecimal	30h	35h	30h	36h	30h	37h	30h	38h	30h	39h
Character	0	5	0	6	0	7	0	8	0	9
	Red		Green		Blue		10%luminance (White)		5%luminance (White)	
Hexadecimal	32h	32h	32h	33h	32h	34h	32h	35h	32h	36h
Character	2	2	2	3	2	4	2	5	2	6
	Cyan		Magenta		Yellow		Color bar (Side)			
Hexadecimal	32h	38h	32h	39h	33h	30h	35h	31h		
Character	2	8	2	9	3	0	5	1		
	3D-1				3D-2					
Hexadecimal	38h		30h		38h		31h			
Character	8		0		8		1			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## 2.271. QUERY ON SCREEN [QOS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	53h	03h
Character	A	D	Z	Z	;	Q	O	S		

## ● Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## 2.272. QUERY INSTALLATION [QSP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	50h	03h
Character	A	D	Z	Z	;	Q	S	P		

## ● Response (Callback)

FRONT/FLOOR

Hexadecimal	02h	30h	03h
Character		0	

REAR/FLOOR

Hexadecimal	02h	31h	03h
Character		1	

FRONT/CEILING

Hexadecimal	02h	32h	03h
Character		2	

REAR/CEILING

Hexadecimal	02h	33h	03h
Character		3	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.273. QUERY COOLING CONDITION [QDR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	52h	03h
Character	A	D	Z	Z	;	Q	D	R		

● Response (Callback)

FLOOR

Hexadecimal	02h	30h	03h
Character	0		

CEILING

Hexadecimal	02h	31h	03h
Character	1		

VERTICAL UP

Hexadecimal	02h	32h	03h
Character	2		

VERTICAL DOWN

Hexadecimal	02h	33h	03h
Character	3		

PORTRAIT

Hexadecimal	02h	34h	03h
Character	4		

AUTO

Hexadecimal	02h	39h	03h
Character	9		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Notes:

·PORTRAIT:Only when using portrait lamp and software version corresponding.

## 2.274. QUERY AUTO COOLING CONDITION – STATUS [QVX:ADR1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	88h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	41h	44h	52h	49h	31h	03h				
Character	A	D	R	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	44h	52h	49h	31h	3Dh	2Bh
Character	A	D	R	I	1	=		+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	FLOOR					CEILING					VERTICAL UP				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
VERTICAL DOWN															
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h					
Character	0	0	0	0	4	0	0	0	0	5					

● Notes:

·PORTRAIT:Only when using portrait lamp and software version corresponding.

## 2.275. QUERY HIGH ALTITUDE MODE [QFM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	46h	4Dh	03h
Character	A	D	Z	Z	;	Q	F	M		

● Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character	0		

ON

Hexadecimal	02h	31h	03h
Character	1		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.276. QUERY PROJECTOR RUNTIME [QST]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	54h	03h
Character		A	D	Z	Z	;	Q	S	T	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	*9	03h
Character		*2	*4	*6	*8	*10	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0h				1h					
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	1	
	99998h					99999h				
Hexadecimal	39h	39h	39h	39h	38h	39h	39h	39h	39h	
Character	9	9	9	9	8	9	9	9	9	

## 2.277. QUERY LAMP1 RUNTIME [Q\$L:1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	24h	4Ch	3Ah
Character		A	D	Z	Z	;	Q	\$	L	:
Hexadecimal	31h	03h								
Character	1									

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0 h				1 h					
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	1	
	9998 h					9999 h				
Hexadecimal	39h	39h	39h	38h	39h	39h	39h	39h		
Character	9	9	9	8	9	9	9	9		

## 2.278. QUERY LAMP2 RUNTIME [Q\$L:2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	24h	4Ch	3Ah
Character		A	D	Z	Z	;	Q	\$	L	:
Hexadecimal	32h	03h								
Character	2									

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0 h				1 h					
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	1	
	9998 h					9999 h				
Hexadecimal	39h	39h	39h	38h	39h	39h	39h	39h		
Character	9	9	9	8	9	9	9	9		

## 2.279. QUERY LAMP SELECT [QSL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Ch	03h
Character		A	D	Z	Z	;	Q	S	L	

● Response (Callback)

DUAL

Hexadecimal	02h	30h	03h
Character		0	

SINGLE

Hexadecimal	02h	31h	03h
Character		1	

LAMP1

Hexadecimal	02h	32h	03h
Character		2	

LAMP2

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

## 2.280. QUERY LAMP CONTROL STATUS [Q\$S]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	24h	53h	03h
Character		A	D	Z	Z	;	Q	\$	S	

● Response (Callback)

Lamp OFF

Hexadecimal	02h	30h	03h
Character		0	

In turning ON

Hexadecimal	02h	31h	03h
Character		1	

Lamp ON

Hexadecimal	02h	32h	03h
Character		2	

Lamp cooling

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

## 2.281. QUERY LAMP STATUS [QLS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	53h	03h
Character		A	D	Z	Z	;	Q	L	S	

● Response (Callback)

Lamp all OFF

Hexadecimal	02h	30h	03h
Character		0	

Lamp1:ON, Lamp2:OFF

Hexadecimal	02h	31h	03h
Character		1	

Lamp1:OFF, Lamp2:ON

Hexadecimal	02h	32h	03h
Character		2	

Lamp all ON

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

## 2.282. QUERY LAMP RELAY [QVX:LRY10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	88h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Ch	52h	59h	49h	30h	03h				
Character	L	R	Y	I	0					

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Ch	52h	59h	49h	30h	3Dh	2Bh
Character		L	R	Y	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

### ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					00:01					00:02				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h	
Character	0	0	0	0	0	0	0	0	1	0	0	0	0	2	
	23:58					23:59					00:00				
Hexadecimal	30h	32h	33h	35h	38h	30h	32h	33h	35h	39h	30h	32h	34h	30h	30h
Character	0	2	3	5	8	0	2	3	5	9	0	2	4	0	0

## 2.283. QUERY LAMP RELAY – WEEK [QVX:LRY12]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	88h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Ch	52h	59h	49h	32h	03h				
Character	L	R	Y	I	2					

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Ch	52h	59h	49h	32h	3Dh	2Bh
Character		L	R	Y	I	2	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	○	○	○	○	○	○	○	○

### ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					EVERY DAY					SUN				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	MON					TUE					WED				
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	3	0	0	0	0	4	0	0	0	0	5
	THU					FRI					SAT				
Hexadecimal	30h	30h	30h	30h	36h	30h	30h	30h	30h	37h	30h	30h	30h	30h	38h
Character	0	0	0	0	6	0	0	0	0	7	0	0	0	0	8

## 2.284. QUERY LAMO POWER [QLP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	50h	03h
Character		A	D	Z	Z	;	Q	L	P	

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

### ● Parameters(\*1,\*2)

	HIGH	MIDDLE/NORMAL	ECO
Hexadecimal	30h	31h	38h
Character	0	1	8

## 2.285. QUERY LAMP POWER [QVX:LPW1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Ch	50h	57h	49h	31h	3Dh	2Bh	*1	*3	*5
Character	L	P	W	I	1	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	51h	56h	58h	3Ah	4Ch	50h	57h	49h	31h
Character		Q	V	X	:	L	P	W	I	1
Hexadecimal	3Dh	2Bh	*1	*3	*5	*7	*9	03h		
Character	=	+	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

### ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

·DZ13K, DS12K, DW11K

	ECO					HIGH					MIDDLE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

·DZ10K

	ECO					NORAML				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

## 2.286. QUERY RS232C – RESPONSE (ID ALL) [QVY]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	59h	03h
Character		A	D	Z	Z	;	Q	V	Y	

### ● Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.287. QUERY FUNCTION BUTTON [QFC]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	46h	43h	03h
Character		A	D	Z	Z	;	Q	F	C	

### ● Response (Callback)

DISABLE

Hexadecimal	02h	30h	03h
Character		0	

SYSTEM SELECTOR

Hexadecimal	02h	31h	03h
Character		1	

SYSTEM DAYLIGHT VIEW

Hexadecimal	02h	32h	03h
Character		2	

SUB MEMORY

Hexadecimal	02h	33h	03h
Character		3	

FREEZE

Hexadecimal	02h	34h	03h
Character		4	

P IN P

Hexadecimal	02h	35h	03h
Character		5	

WAVEFORM MONITOR

Hexadecimal	02h	36h	03h
Character		6	

## LENS MEMORY LOAD

Hexadecimal	02h	37h	03h
Character		7	

## LEFT/RIGHT SWAP

Hexadecimal	02h	38h	03h
Character		8	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.288. QUERY SUB MEMORY USAGE STATE [QSB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	42h	03h
Character		A	D	Z	Z	;	Q	S	B	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4)

Unused, it returns the ER401.

	01	02		03		04		
Hexadecimal	30h	31h	30h	32h	30h	33h	30h	34h
Character	0	1	0	2	0	3	0	4
	93		94		95		96	
Hexadecimal	39h	33h	39h	34h	39h	35h	39h	36h
Character	9	3	9	4	9	5	9	6

## 2.289. QUERY PICTURE MODE [QPM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	4Dh	03h
Character		A	D	Z	Z	;	Q	P	M	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	NATURAL			STANDARD			DYNAMIC			
	Hexadecimal	4Eh	41h	54h	53h	54h	44h	44h	59h	4Eh
Character	N	A	T	S	T	D	D	Y	N	
	CINEMA			GRAPHIC			DICOM SIM.			
Hexadecimal	43h	49h	4Eh	47h	52h	41h	44h	49h	43h	
Character	C	I	N	G	R	A	D	I	C	
	USER									
Hexadecimal	55h	53h	52h							
Character	U	S	R							

## 2.290. QUERY COLOR [QVC]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	43h	03h
Character		A	D	Z	Z	;	Q	V	C	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	+29			+30			+31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.291. QUERY TINT [QVT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	54h	03h
Character		A	D	Z	Z	;	Q	V	T	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	+29			+30			+31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.292. QUERY COLOR TEMPERATURE [QTE]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	45h	03h
Character		A	D	Z	Z	;	Q	T	E	

● Response (Callback)

DEFAULT

Hexadecimal	02h	31h	30h	03h
Character		1	0	

USER1

Hexadecimal	02h	34h	03h
Character		4	

USER2

Hexadecimal	02h	39h	03h
Character		9	

When the color temperature is set up

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	3200K				3300K			
Hexadecimal	33h	32h	30h	30h	33h	33h	30h	30h
Character	3	2	0	0	3	3	0	0
	9200K				9300K			
Hexadecimal	39h	32h	30h	30h	39h	33h	30h	30h
Character	9	2	0	0	9	3	0	0

2.293. QUERY WHITE BALANCE LOW – RED [QOR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	52h	03h
Character		A	D	Z	Z	;	Q	0	R	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
124			125			126			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

2.294. QUERY WHITE BALANCE LOW – GREEN [QOG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	47h	03h
Character	A	D	Z	Z	;	Q	O	G		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character	*	2	4	6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
124			125			126			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

2.295. QUERY WHITE BALANCE LOW – BLUE [QOB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	42h	03h
Character	A	D	Z	Z	;	Q	O	B		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character	*	2	4	6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
124			125			126			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

2.296. QUERY WHITE BALANCE HIGH – RED [QHR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	48h	52h	03h
Character	A	D	Z	Z	;	Q	H	R		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character	*	2	4	6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
253			254			255			
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

## 2.297. QUERY WHITE BALANCE HIGH - GREEN [QHG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	48h	47h	03h
Character		A	D	Z	Z	;	Q	H	G	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0	1	2
Hexadecimal	30h	30h	30h
Character	0	0	0
	253	254	255
Hexadecimal	32h	35h	33h
Character	2	5	3
	2	5	4
	32h	35h	35h
	2	5	5

## 2.298. QUERY WHITE BALANCE HIGH - BLUE [QHB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	48h	42h	03h
Character		A	D	Z	Z	;	Q	H	B	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0	1	2
Hexadecimal	30h	30h	30h
Character	0	0	0
	253	254	255
Hexadecimal	32h	35h	33h
Character	2	5	3
	2	5	4
	32h	35h	35h
	2	5	5

## 2.299. QUERY CONTRAST [QVR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	52h	03h
Character		A	D	Z	Z	;	Q	V	R	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31	-30	-29
Hexadecimal	30h	30h	31h
Character	0	0	1
	0	0	2
	+29	+30	+31
Hexadecimal	30h	36h	31h
Character	0	6	1
	0	6	2
	30h	36h	33h
	0	6	3

## 2.300. QUERY BRIGHTNESS [QVB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	42h	03h
Character		A	D	Z	Z	;	Q	V	B	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-31			-30			-29		
Hexadecimal	30h	30h	31h	30h	30h	32h	30h	30h	33h
Character	0	0	1	0	0	2	0	0	3
	+29			+30			+31		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.301. QUERY GAMMA [QGA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	42h	03h
Character		A	D	Z	Z	;	Q	G	A	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	1.0			1.8			2.0		
Hexadecimal	31h	2Eh	30h	31h	2Eh	38h	32h	2Eh	30h
Character	1	.	0	1	.	8	2	.	0
	2.1			2.2			2.3		
Hexadecimal	32h	2Eh	31h	32h	2Eh	32h	32h	2Eh	33h
Character	2	.	1	2	.	2	2	.	3
	2.4			2.5			2.6		
Hexadecimal	32h	2Eh	34h	32h	2Eh	35h	32h	2Eh	36h
Character	2	.	4	2	.	5	2	.	6
	2.7			2.8			USER1		
Hexadecimal	32h	2Eh	37h	32h	2Eh	38h	55h	53h	31h
Character	2	.	7	2	.	8	U	S	1
	USER2			DICOM SIM.			DEFAULT		
Hexadecimal	55h	53h	32h	44h	49h	43h	44h	45h	46h
Character	U	S	2	D	I	C	D	E	F

2.302. QUERY SYSTEM DAYLIGHT VIEW [QVX:DLV10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	88h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	4Ch	56h	49h	30h	03h				
Character	D	L	V	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	4Ch	56h	49h	30h	3Dh	2Bh
Character	D	L	V	I	0		=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					1					2				
Hexadecimal	30h	31h	30h	30h	30h	30h	32h								
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	3														
Hexadecimal	30h	30h	30h	30h	33h										
Character	0	0	0	0	3										

2.303. QUERY SHARPNESS [QVS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	53h	03h
Character		A	D	Z	Z	;	Q	V	S	:

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal	30h	31h	33h	30h	31h	34h	30h	31h	35h
Character	0	1	3	0	1	4	0	1	5

2.304. QUERY NOISE REDUCTION [QNS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Eh	53h	03h
Character		A	D	Z	Z	;	Q	N	S	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF	1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

2.305. QUERY DYNAMIC IRIS [QAI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	49h	03h
Character		A	D	Z	Z	;	Q	A	I	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF	1	2	3
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

2.306. QUERY DYNAMIC IRIS - AUTO IRIS [QAI:A]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	49h	3Ah
Character		A	D	Z	Z	;	Q	A	I	:
Hexadecimal	41h	*1	*3	*5	03h					
Character	A	*2	*4	*6						

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF				1				2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h		
Character	0	0	0	0	0	1	0	0	2		
	253				254				255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h		
Character	2	5	3	2	5	4	2	5	5		

### 2.307. QUERY DYNAMIC IRIS - MANUAL IRIS [QAI:M]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	49h	3Ah
Character		A	D	Z	Z	;	Q	A	I	:
Hexadecimal	4Dh	*1	*3	*5	03h					
Character	M	*2	*4	*6						

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	253			254			255		
Hexadecimal	32h	35h	33h	32h	35h	34h	32h	35h	35h
Character	2	5	3	2	5	4	2	5	5

### 2.308. QUERY DYNAMIC IRIS - DYNAMIC GAMMA [QAI:D]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	49h	3Ah
Character		A	D	Z	Z	;	Q	A	I	:
Hexadecimal	44h	*1	03h							
Character	D	*2								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF		1	2	3
Hexadecimal	30h		31h	32h	33h
Character	0		1	2	3

### 2.309. QUERY DIGITAL CINEMA REALITY [QPD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	44h	03h
Character		A	D	Z	Z	;	Q	P	D	:

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	AUTO		OFF	30p/25p FIXED
Hexadecimal	30h		31h	32h
Character	0		1	2

### 2.310. QUERY TV-SYSTEM [QSG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	47h	03h
Character		A	D	Z	Z	;	Q	S	G	:

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	AUTO			NTSC					
Hexadecimal	41h	54h	31h	4Eh	54h	53h			
Character	A	T	1	N	T	S			
	NTSC4.43			PAL			PAL-M		
Hexadecimal	4Eh	34h	34h	50h	41h	4Ch	50h	41h	4Dh
Character	N	4	4	P	A	L	P	A	M
	PAL-N			SECAM			PAL60		
Hexadecimal	50h	41h	4Eh	53h	45h	43h	50h	36h	30h
Character	P	A	N	S	E	C	P	6	0

### 2.311. QUERY SHIFT – HORIZONTAL [QTH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	48h	03h
Character		A	D	Z	Z	;	Q	T	H	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	x	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0				1				2			
Hexadecimal	30h	31h	30h	30h	30h	32h						
Character	0	0	0	0	0	0	0	1	0	0	0	2
4093												
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	3	4	0	9	4	4	0	9	5

### 2.312. QUERY SHIFT – VERTICAL [QTV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	56h	03h
Character		A	D	Z	Z	;	Q	T	V	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	x	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0				1				2			
Hexadecimal	30h	31h	30h	30h	30h	32h						
Character	0	0	0	0	0	0	0	1	0	0	0	2
4093												
Hexadecimal	34h	30h	39h	33h	34h	30h	39h	34h	34h	30h	39h	35h
Character	4	0	9	3	4	0	9	4	4	0	9	5

### 2.313. QUERY RASTER POSITION – HORIZONTAL [QRH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	52h	48h	03h
Character		A	D	Z	Z	;	Q	R	H	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	x	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	-2048				-2047			
Hexadecimal	32h	39h	35h	32h	32h	39h	35h	33h
Character	2	9	5	2	2	9	5	3
+2046								
Hexadecimal	37h	30h	34h	36h	37h	30h	34h	37h
Character	7	0	4	6	7	0	4	7

### 2.314. QUERY RASTER POSITION – VERTICAL [QRV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	52h	56h	03h
Character		A	D	Z	Z	;	Q	R	V	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	-2048				-2047			
Hexadecimal	32h	39h	35h	32h	32h	39h	35h	33h
Character	2	9	5	2	2	9	5	3
	+2046				+2047			
Hexadecimal	37h	30h	34h	36h	37h	30h	34h	37h
Character	7	0	4	6	7	0	4	7

### 2.315. QUERY EDGE BLENDING [QVX:EDB10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	44h	42h	49h	30h	03h				
Character	E	D	B	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	44h	42h	49h	30h	3Dh	2Bh	*1	*3
Character		E	D	B	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON					USER				
Hexadecimal	30h	31h	30h	30h	30h	30h	32h								
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

### 2.316. QUERY EDGE BLENDING – UPPER ON/OFF [QGU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	55h	03h
Character		A	D	Z	Z	;	Q	G	U	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF			ON		
Hexadecimal		30h			31h	
Character		0			1	

### 2.317. QUERY EDGE BLENDING – LOWER ON/OFF [QGB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	42h	03h
Character		A	D	Z	Z	;	Q	G	B	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.318. QUERY EDGE BLENDING – LEFT ON/OFF [QGL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	4Ch	03h
Character	A	D	Z	Z	;	Q	G	L		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.319. QUERY EDGE BLENDING – RIGHT ON/OFF [QGR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	52h	03h
Character	A	D	Z	Z	;	Q	G	R		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.320. QUERY EDGE BLENDING – RIGHT ON/OFF [QEJ]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	55h	03h
Character	A	D	Z	Z	;	Q	E	U		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1199
Hexadecimal	30h	31h 31h 39h 39h
Character	0	1 1 9 9

2.321. QUERY EDGE BLENDING – START – LOWER [QEB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	42h	03h
Character	A	D	Z	Z	;	Q	E	B		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1199
Hexadecimal	30h	31h 31h 39h 39h
Character	0	1 1 9 9

### 2.322. QUERY EDGE BLENDING – START – LEFT [QEL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	4Ch	03h
Character		A	D	Z	Z	;	Q	E	L	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	31h 39h 31h 39h
Character	0	1 9 1 9

### 2.323. QUERY EDGE BLENDING – START – RIGHT [QER]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	52h	03h
Character		A	D	Z	Z	;	Q	E	R	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	31h 39h 31h 39h
Character	0	1 9 1 9

### 2.324. QUERY EDGE BLENDING – WIDTH – UPPER [QVX:EUW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	55h	57h	49h	30h	03h				
Character	E	U	W	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	55h	57h	49h	30h	3Dh	2Bh	*1	*3
Character		E	U	W	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8,\*9,\*10)

	0	1199
Hexadecimal	30h 30h 30h 30h 30h	30h 31h 31h 39h 39h
Character	0 0 0 0 0	0 1 1 9 9

### 2.325. QUERY EDGE BLENDING – WIDTH – LOWER [QVX:EBW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	57h	49h	30h	03h				
Character	E	B	W	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	57h	49h	30h	3Dh	2Bh	*1	*3
Character		E	B	W	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1199				
Hexadecimal	30h	30h	30h	30h	30h	30h	31h	31h	39h	39h
Character	0	0	0	0	0	0	1	1	9	9

2.326. QUERY EDGE BLENDING – WIDTH – LEFT [QVX:ELW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	4Ch	57h	49h	30h	03h				
Character	E	L	W	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	4Ch	57h	49h	30h	3Dh	2Bh	*1	*3
Character	E	L	W	I	0	=	+		*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1919				
Hexadecimal	30h	30h	30h	30h	30h	30h	31h	39h	31h	39h
Character	0	0	0	0	0	0	1	9	1	9

2.327. QUERY EDGE BLENDING – WIDTH – RIGHT [QVX:ERW10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	52h	57h	49h	30h	03h				
Character	E	R	W	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	52h	57h	49h	30h	3Dh	2Bh	*1	*3
Character	E	R	W	W	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1919				
Hexadecimal	30h	30h	30h	30h	30h	30h	31h	39h	31h	39h
Character	0	0	0	0	0	0	1	9	1	9

2.328. QUERY EDGE BLENDING – MARKER ON/OFF [QGM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	4Dh	03h
Character	A	D	Z	Z	;	Q	G	M		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

### 2.329. QUERY EDGE BLENDING – NON-OVERLAPPED BLACK LEVEL [QJI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ah	49h	03h
Character		A	D	Z	Z	;	Q	J	I	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	2Ch	*7	*9	*11	2Ch
Character		*2	*4	*6	,	*8	*10	*12	,
Hexadecimal	*13	*15	*17	2Ch	*19	*21	*23	03h	
Character	*14	*16	*18	,	*20	*22	*24		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6): White

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12): Red

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18): Green

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24): Blue

	0	255				
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

### 2.330. QUERY EDGE BLENDING – NON-OVERLAPPED BLACK LEVEL – INTERLOCKED [QVX:EBII1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	49h	31h	03h				
Character	E	B	B	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	49h	31h	3Dh	2Bh	*1	*3
Character		E	B	B	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF	ON							
Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	1

### 2.331. QUERY EDGE BLENDING – BLACK BORDER LEVEL [QJO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ah	4Fh	03h
Character		A	D	Z	Z	;	Q	J	0	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	2Ch	*7	*9	*11	2Ch
Character		*2	*4	*6	,	*8	*10	*12	,
Hexadecimal	*13	*15	*17	2Ch	*19	*21	*23	03h	
Character	*14	*16	*18	,	*20	*22	*24		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6): White

	0		255		
Hexadecimal	30h	30h	30h	32h	35h
Character	0	0	0	2	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12): Red

	0		255		
Hexadecimal	30h	30h	30h	32h	35h
Character	0	0	0	2	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18): Green

	0		255		
Hexadecimal	30h	30h	30h	32h	35h
Character	0	0	0	2	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24): Blue

	0		255		
Hexadecimal	30h	30h	30h	32h	35h
Character	0	0	0	2	5

## 2.332. QUERY EDGE BLENDING – BLACK BORDER LEVEL – INTERLOCKED [QVX:EBII2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	49h	32h	03h				
Character	E	B	B	I	2					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	49h	32h	3Dh	2Bh	*1	*3
Character		E	B	B	I	2	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## 2.333. QUERY EDGE BLENDING – BLACK BORDER WIDTH – UPPER [QJU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ah	55h	03h
Character		A	D	Z	Z	;	Q	J	U	

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0				1199			
Hexadecimal	30h				31h	31h	39h	39h
Character	0				1	1	9	9

## 2.334. QUERY EDGE BLENDING – BLACK BORDER WIDTH – LOWER [QJB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ah	4Bh	03h
Character		A	D	Z	Z	;	Q	J	B	

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0				1199			
Hexadecimal	30h				31h	31h	39h	39h
Character	0				1	1	9	9

### 2.335. QUERY EDGE BLENDING – BLACK BORDER WIDTH – LEFT [QJL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ah	4Ch	03h
Character		A	D	Z	Z	;	Q	J	L	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	31h 39h 31h 39h
Character	0	1 9 1 9

### 2.336. QUERY EDGE BLENDING – BLACK BORDER WIDTH – RIGHT [QJR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ah	52h	03h
Character		A	D	Z	Z	;	Q	J	R	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8)

	0	1919
Hexadecimal	30h	31h 39h 31h 39h
Character	0	1 9 1 9

### 2.337. QUERY EDGE BLENDING – BLACK BORDER WIDTH – UPPER KEYSTONE AREA [QVX:EBBI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	49h	34h	03h				
Character	E	B	B	I	4					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	49h	34h	3Dh	*1	*3	*5
Character		E	B	B	I	4	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1199	+1199
Hexadecimal	2Dh	30h 31h 31h 39h 39h
Character	-	0 1 1 9 9

### 2.338. QUERY EDGE BLENDING – BLACK BORDER WIDTH – LOWER KEYSTONE AREA [QVX:EBBI5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	49h	35h	03h				
Character	E	B	B	I	5					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	49h	35h	3Dh	*1	*3	*5
Character		E	B	B	I	5	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1199						+1199					
Hexadecimal	2Dh	30h	31h	31h	39h	39h	2Bh	30h	31h	31h	39h	39h
Character	-	0	1	1	9	9	+	0	1	1	9	9

### 2.339. QUERY EDGE BLENDING – BLACK BORDER WIDTH – LEFT KEYSTONE AREA [QVX:EBBI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	42h	42h	49h	36h	03h				
Character	E	B	B	I	6					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	49h	36h	3Dh	*1	*3	*5
Character	E	B	B	I	6	=	*	2	4	6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1919						+1919					
Hexadecimal	2Dh	30h	31h	39h	31h	39h	2Bh	30h	30h	30h	30h	31h
Character	-	0	1	9	1	9	+	0	1	9	1	9

### 2.340. QUERY EDGE BLENDING – BLACK BORDER WIDTH – RIGHT KEYSTONE AREA [QVX:EBBI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	42h	42h	49h	37h	03h				
Character	E	B	B	I	7					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	49h	37h	3Dh	*1	*3	*5
Character	E	B	B	B	I	7	=	*	2	4
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-1919						+1919					
Hexadecimal	2Dh	30h	31h	39h	31h	39h	2Bh	30h	30h	30h	30h	31h
Character	-	0	1	9	1	9	+	0	1	9	1	9

### 2.341. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – UPPER [QVX:EBBS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	42h	42h	53h	30h	03h				
Character	E	B	B	S	0					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	53h	30h	3Dh	*1	*3	*5	2Ch
Character	E	B	B	B	S	0	=	*	2	4	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21	*23
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22	*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4, \*5, \*6): White

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12): Red

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

## 2.342. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LOWER [QVX:EBBS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	53h	31h	03h				
Character	E	B	B	S	1					

### ● Response (Callback)

Hexadecimal	02h	45h	42h	42h	53h	31h	3Dh	*1	*3	*5	2Ch
Character		E	B	B	S	1	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21	*23
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22	*24

In the period when the command can be accepted

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

### ● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

## 2.343. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LEFT [QVX:EBBS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	53h	32h	03h				
Character	E	B	B	S	2					

### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	53h	32h	3Dh	*1	*3	*5	2Ch
Character		E	B	B	S	2	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21	*23
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22	*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

### ● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

#### 2.344. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – RIGHT [QVX:EBBS3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	42h	53h	33h	03h				
Character	E	B	B	S	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	42h	53h	33h	3Dh	*1	*3	*5	2Ch
Character		E	B	B	S	3	=	*2	*4	*6	,
Hexadecimal	*7	*9	*11	2Ch	*13	*15	*17	2Ch	*19	*21	*23
Character	*8	*10	*12	,	*14	*16	*18	,	*20	*22	*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4, \*5, \*6):White

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*7,\*8,\*9,\*10, \*11, \*12):Red

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*13,\*14,\*15,\*16, \*17, \*18):Green

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

Parameters(\*19,\*20,\*21,\*22, \*23, \*24):Blue

	0			255		
Hexadecimal	30h	30h	30h	32h	35h	35h
Character	0	0	0	2	5	5

#### 2.345. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – UPPER INTERLOCKED [QVX:EBII3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	49h	49h	33h	03h				
Character	E	B	I	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	49h	49h	33h	3Dh	2Bh	*1	*3
Character		E	B	I	I	3	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	1	

#### 2.346. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LOWER INTERLOCKED [QVX:EBII4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	45h	42h	49h	49h	34h	03h				
Character	E	B	I	I	4					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	49h	49h	34h	3Dh	2Bh	*1	*3
Character		E	B	I	I	4	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

## 2.347. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – LEFT INTERLOCKED [QVX:EBI|5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	42h	49h	49h	35h	03h				
Character	E	B	I	I	5					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	49h	49h	35h	3Dh	2Bh	*1	*3
Character	E	B	I	I	I	5	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

## 2.348. QUERY EDGE BLENDING – OVERLAPPED BLACK LEVEL – RIGHT INTERLOCKED [QVX:EBI|6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	42h	49h	49h	36h	03h				
Character	E	B	I	I	6					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	42h	49h	49h	36h	3Dh	2Bh	*1	*3
Character	E	B	I	I	I	6	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

## 2.349. QUERY ASPECT [QSE]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	45h	03h
Character	A	D	Z	Z	;	Q	S	E		

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4)

· Input terminal : VIDEO, Input signal: NTSC

VID AUTO	4.3	16.9	THROUGH	HV FIT
Hexadecimal	30h	31h	32h	36h
Character	0	1	2	6
H FIT		V FIT		
Hexadecimal	39h	31h	30h	
Character	9	1	0	

• Input terminal : VIDEO0, Input signal: Other than NTSC

	DEFAULT	4:3	16:9	THROUGH	HV FIT
Hexadecimal	30h	31h	32h	35h	36h
Character	0	1	2	5	6
	H FIT	V FIT			
Hexadecimal	39h	31h	30h		
Character	9	1	0		

• Input terminal : Other than VIDEO

	DEFAULT	4:3	16:9	THROUGH	HV FIT
Hexadecimal	30h	31h	32h	35h	36h
Character	0	1	2	5	6
	H FIT	V FIT			
Hexadecimal	39h	31h	30h		
Character	9	1	0		

### 2.350. QUERY ZOOM - HORIZONTAL [QZH]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	48h	03h
Character		A	D	Z	Z	;	Q	Z	H	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	×	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

### 2.351. QUERY ZOOM - VERTICAL [QZV]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	56h	03h
Character		A	D	Z	Z	;	Q	Z	V	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	×	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

### 2.352. QUERY ZOOM - BOTH [QZO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	4Fh	03h
Character		A	D	Z	Z	;	Q	Z	O	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	×	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	50			51			52		
Hexadecimal	30h	35h	30h	30h	35h	31h	30h	35h	32h
Character	0	5	0	0	5	1	0	5	2
	997			998			999		
Hexadecimal	39h	39h	37h	39h	39h	38h	39h	39h	39h
Character	9	9	7	9	9	8	9	9	9

2.353. QUERY ZOOM - INTERLOCKED [QZS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	53h	03h
Character		A	D	Z	Z	;	Q	Z	S	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	×	○	○	○

● Parameters(\*1,\*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.354. QUERY ZOOM - MODE [QZT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	5Ah	54h	03h
Character		A	D	Z	Z	;	Q	Z	T	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	×	○	○	○

● Parameters(\*1,\*2)

	INTERNAL	FULL
Hexadecimal	30h	31h
Character	0	1

● Note:

· When [ASPECT] is not set to [DEFAULT], ER401 returned.

2.355. QUERY CLOCK PHASE [QCP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	43h	50h	03h
Character		A	D	Z	Z	;	Q	C	P	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

Acceptability is possible only if it is selected or RGB2 or RGB1.

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

### 2.356. QUERY INPUT RESOLUTION – TOTAL DOTS [QTD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	44h	03h
Character		A	D	Z	Z	;	Q	T	D	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

Acceptability is possible only if it is selected or RGB2 or RGB1.

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	330				331			
Hexadecimal	30h	33h	33h	30h	30h	33h	33h	31h
Character	0	3	3	0	0	3	3	1
	4095				4096			
Hexadecimal	34h	30h	39h	35h	34h	30h	39h	36h
Character	4	0	9	5	4	0	9	6

### 2.357. QUERY INPUT RESOLUTION – DISPLAY DOTS [QDD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	44h	03h
Character		A	D	Z	Z	;	Q	D	D	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

Acceptability is possible only if it is selected or RGB2 or RGB1.

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	300				301			
Hexadecimal	30h	33h	30h	30h	30h	33h	30h	31h
Character	0	3	0	0	0	3	0	1
	2065				2066			
Hexadecimal	32h	30h	36h	35h	32h	30h	36h	36h
Character	2	0	6	5	2	0	6	6

### 2.358. QUERY INPUT RESOLUTION – TOTAL LINES [QTL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	4Ch	03h
Character		A	D	Z	Z	;	Q	T	L	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	306				307			
Hexadecimal	30h	33h	30h	36h	30h	33h	30h	37h
Character	0	3	0	6	0	3	0	7
	2046				2047			
Hexadecimal	32h	30h	34h	36h	32h	30h	34h	37h
Character	2	0	4	6	2	0	4	7

### 2.359. QUERY INPUT RESOLUTION – DISPLAY LINES [QDL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	4Ch	03h
Character		A	D	Z	Z	;	Q	D	L	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

Acceptability is possible only if it is selected or RGB2 or RGB1.

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	300				301			
Hexadecimal	30h	33h	30h	30h	30h	33h	30h	31h
Character	0	3	0	0	0	3	0	1
	1199				1200			
Hexadecimal	31h	31h	39h	39h	31h	32h	30h	30h
Character	1	1	9	9	1	2	0	0

### 2.360. QUERY BLANKING – UPPER [QLU]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	55h	03h
Character		A	D	Z	Z	;	Q	L	U	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

PT-DZ13K/DZ10K

	597			598			599		
Hexadecimal	35h	39h	37h	35h	39h	38h	35h	39h	39h
Character	5	9	7	5	9	8	5	9	9

PT-DS12K

	522			523			524		
Hexadecimal	35h	32h	32h	35h	32h	33h	35h	32h	34h
Character	5	2	2	5	2	3	5	2	4

PT-DW11K

	381			382			383		
Hexadecimal	33h	38h	31h	33h	38h	32h	33h	38h	33h
Character	3	8	1	3	8	2	3	8	3

### 2.361. QUERY BLANKING – LOWER [QLB]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	42h	03h
Character		A	D	Z	Z	;	Q	L	B	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2

PT-DZ13K/DZ10K

	597			598			599		
Hexadecimal	35h	39h	37h	35h	39h	38h	35h	39h	39h
Character	5	9	7	5	9	8	5	9	9

## PT-DS12K

	522			523			524		
Hexadecimal	35h	32h	32h	35h	32h	33h	35h	32h	34h
Character	5	2	2	5	2	3	5	2	4

## PT-DW11K

	381			382			383		
Hexadecimal	33h	38h	31h	33h	38h	32h	33h	38h	33h
Character	3	8	1	3	8	2	3	8	3

## 2.362. QUERY BLANKING – RIGHT [QLR]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	52h	03h
Character		A	D	Z	Z	;	Q	L	R	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0		1		2
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

## PT-DZ13K/DZ10K

	957		958		959
Hexadecimal	39h	35h	37h	39h	35h
Character	9	5	7	9	5

## PT-DS12K

	697		698		699
Hexadecimal	36h	39h	37h	36h	39h
Character	6	9	7	6	9

## PT-DW11K

	680		681		682
Hexadecimal	36h	38h	30h	36h	38h
Character	6	8	0	6	8

## 2.363. QUERY BLANKING – LEFT [QLL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	4Ch	03h
Character		A	D	Z	Z	;	Q	L	L	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0		1		2
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

## PT-DZ13K/DZ10K

	957		958		959
Hexadecimal	39h	35h	37h	39h	35h
Character	9	5	7	9	5

## PT-DS12K

	697		698		699
Hexadecimal	36h	39h	37h	36h	39h
Character	6	9	7	6	9

## PT-DW11K

	680		681		682
Hexadecimal	36h	38h	30h	36h	38h
Character	6	8	0	6	8

## 2.364. QUERY FRAME RESPONSE [QVX:FDYI0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	46h	44h	59h	49h	30h	03h				
Character	F	D	Y	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	46h	44h	59h	49h	30h	3Dh	2Bh
Character	F	D	Y	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					FAST					FIXED				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	35h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	5

## 2.365. QUERY EDGE BLENDING [QVX:EDBIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	45h	44h	42h	49h	30h	03h				
Character	E	D	B	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	44h	42h	49h	30h	3Dh	2Bh
Character	E	D	B	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON					USER				
Hexadecimal	30h	31h	30h	30h	30h	30h	32h								
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

## 2.366. QUERY COLOR MATCHING [QVX:CMAI0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	43h	4Dh	41h	49h	30h	03h				
Character	C	M	A	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	43h	4Dh	41h	49h	30h	3Dh	2Bh
Character	C	M	A	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					3COLORS					7COLORS				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	709MODE										MEASURED				
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h					
Character	0	0	0	0	3	0	0	0	0	4					

### 2.367. QUERY CLAMP POSITION [QLT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	54h	03h
Character		A	D	Z	Z	;	Q	L	T	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

RGB1/RGB2 の場合のみ有効

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

Hexadecimal	1			2		
	30h	30h	31h	30h	30h	32h
Character	0	0	1	0	0	2
	254			255		
Hexadecimal	32h	35h	34h	32h	35h	35h
	2	5	4	2	5	5

● Note:

· It is available only when RGB1 or RGB2 is selected. In other case returns the ER401.

### 2.368. QUERY KYESTONE [QKS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Bh	53h	03h
Character		A	D	Z	Z	;	Q	K	S	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

Hexadecimal	-127			-126			-125		
	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	+125			+126			+127		
Hexadecimal	32h	35h	32h	32h	35h	33h	32h	35h	34h
	2	5	2	2	5	3	2	5	4

● Notes:

· Other than DW11K model, ER401 is returned.

### 2.369. QUERY KEYSTONE – SUB KEYSTONE [QSK]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Bh	03h
Character		A	D	Z	Z	;	Q	S	K	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

Hexadecimal	-63			-62			-61		
	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	+61			+62			+63		
Hexadecimal	31h	32h	34h	31h	32h	35h	31h	32h	36h
	1	2	4	1	2	5	1	2	6

● Notes:

· Other than DW11K model, ER401 is returned.

### 2.370. QUERY KEYSTONE - LINEARITY [QLI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	49h	03h
Character	A	D	Z	Z	;	Q	L	I		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character	*2	*4	*6		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	-127			-126			-125		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	+125			+126			+127		
Hexadecimal	32h	35h	32h	32h	35h	33h	32h	35h	34h
Character	2	5	2	2	5	3	2	5	4

● Notes:

- Other than DW11K model, ER401 is returned.

### 2.371. QUERY GEOMETRY [QVX:GMMIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	47h	4Dh	4Dh	49h	30h	03h				
Character	G	M	M	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Dh	49h	30h	3Dh	2Bh	*1	*3
Character	G	M	M	M	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					KEYSTONE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	CURVED					PC-1				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
	PC-2					PC-3				
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5
	CORNER-CORRECTION									
Hexadecimal	30h	30h	30h	31h	30h					
Character	0	0	0	1	0					

● Notes:

- DW11K is returned ER401..

### 2.372. QUERY GEOMETRY - KEYSTONE - LENS THROW RATIO [QVX:GMKS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	47h	4Dh	4Bh	53h	30h	03h				
Character	G	M	K	S	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	53h	30h	3Dh	2Bh	*1	*3
Character	G	M	K	S	0	=	+	*2	*4	
Hexadecimal	*5	*7	03h							
Character	*6	*8								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8)

	0.7				0.8			
Hexadecimal	30h	30h	2Eh	37h	30h	30h	2Eh	38h
Character	0	0	.	7	0	0	.	8
16.4				16.5				
Hexadecimal	31h	36h	2Eh	35h	31h	36h	2Eh	35h
Character	1	6	.	4	1	6	.	5

● Notes:

· DW11K is returned ER401..

### 2.373. QUERY GEOMETRY – KEYSTONE – VERTICAL BALANCE [QVX:GMKI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	34h	03h				
Character	G	M	K	I	4					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	34h	3Dh	*1	*3	*5
Character		G	M	K	I	4	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-60						-59					
Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h	39h
Character	—	0	0	0	6	0	—	0	0	0	5	9
+59						+60						
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	36h	30h
Character	+	0	0	0	5	9	+	0	0	0	6	0

● Notes:

· DW11K is returned ER401..

### 2.374. QUERY GEOMETRY – KEYSTONE – HORIZONTAL BALANCE [QVX:GMKI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	49h	37h	03h				
Character	G	M	K	I	7					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	49h	37h	3Dh	*1	*3	*5
Character		G	M	K	I	7	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>						

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-30						-29					
Hexadecimal	2Dh	30h	30h	30h	33h	30h	2Dh	30h	30h	30h	32h	39h
Character	—	0	0	0	3	0	—	0	0	0	2	9
+29						+30						
Hexadecimal	2Bh	30h	30h	30h	32h	39h	2Bh	30h	30h	30h	33h	30h
Character	+	0	0	0	2	9	+	0	0	0	3	0

● Notes:

· DW11K is returned ER401..

### 2.375. QUERY GEOMETRY - KEYSTONE - VERTICAL KEYSTONE [QVX:GMKS8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	53h	38h	03h				
Character	G	M	K	S	8					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	53h	38h	3Dh	*1	*3	*5
Character		G	M	K	S	8	=	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-40.0					-38.8				
Hexadecimal	2Dh	34h	30h	2Eh	30h	2Dh	33h	38h	2Eh	38h
Character	-	4	0	.	0	-	3	8	.	8
	-9.8					+00.0				
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	-	0	9	.	8	+	0	0	.	0
	+38.8					+40.0				
Hexadecimal	2Bh	33h	38h	2Eh	38h	2Bh	34h	30h	2Eh	30h
Character	+	3	8	.	8	+	4	0	.	0

● Notes:

· DW11K is returned ER401..

### 2.376. QUERY GEOMETRY - KEYSTONE - HORIZONTAL KEYSTONE [QVX:GMKS9]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	4Bh	53h	39h	03h				
Character	G	M	K	S	9					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	4Bh	53h	39h	3Dh	*1	*3	*5
Character		G	M	K	S	9	=	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-15.0					-14.8				
Hexadecimal	2Dh	31h	35h	2Eh	30h	2Dh	31h	34h	2Eh	38h
Character	-	1	5	.	0	-	1	4	.	8
	-9.8					+0.0				
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	-	0	9	.	8	+	0	0	.	0
	+14.8					+15.0				
Hexadecimal	2Bh	31h	34h	2Eh	38h	2Bh	31h	35h	2Eh	30h
Character	+	1	4	.	8	+	1	5	.	0

● Notes:

· DW11K is returned ER401..

### 2.377. QUERY GEOMETRY - CURVED - LENS THROW RATIO [QVX:GMCS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	53h	30h	03h				
Character	G	M	C	S	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	53h	30h	3Dh	2Bh	*1	*3
Character		G	M	C	S	0	=	+	*2	*4
Hexadecimal	*5	*7	03h							
Character	*6	*8								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,)

	0.7				0.8			
Hexadecimal	30h	30h	2Eh	37h	30h	30h	2Eh	38h
Character	0	0	.	7	0	0	.	8
16.4				16.5				
Hexadecimal	31h	36h	2Eh	34h	31h	36h	2Eh	35h
Character	1	6	.	4	1	6	.	5

● Notes:

· DW11K is returned ER401..

### 2.378. QUERY GEOMETRY – CURVED – VERTICAL ARC [QVX:GMCI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	33h	03h				
Character	G	M	C	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	33h	3Dh	*1	*3	*5
Character		G	M	C	I	3	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-50						-49				
Hexadecimal	2Dh	30h	30h	30h	35h	30h	2Dh	30h	30h	30h	39h
Character	—	0	0	0	5	0	—	0	0	0	9
+49						+50					
Hexadecimal	2Bh	30h	30h	30h	34h	39h	2Bh	30h	30h	30h	30h
Character	+	0	0	0	4	9	+	0	0	0	0

● Notes:

· DW11K is returned ER401..

### 2.379. QUERY GEOMETRY – CURVED – HORIZONTAL ARC [QVX:GMCI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	37h	03h				
Character	G	M	C	I	7					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	37h	3Dh	*1	*3	*5
Character		G	M	C	I	7	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-50						-49				
Hexadecimal	2Dh	30h	30h	30h	35h	30h	2Dh	30h	30h	30h	39h
Character	—	0	0	0	5	0	—	0	0	0	9
+49						+50					
Hexadecimal	2Bh	30h	30h	30h	34h	39h	2Bh	30h	30h	30h	30h
Character	+	0	0	0	4	9	+	0	0	0	0

● Notes:

· DW11K is returned ER401..

### 2.380. QUERY GEOMETRY - CURVED - VERTICAL BALANCE [QVX:GMCI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	32h	03h				
Character	G	M	C	I	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	32h	3Dh	*1	*3	*5
Character		G	M	C	I	2	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

Hexadecimal	-60						-59				
Character	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	39h
Hexadecimal	+59						+60				
Character	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	30h
Hexadecimal	-						-				
Character	-	0	0	0	6	0	-	0	0	0	9

● Notes:

· DW11K is returned ER401..

### 2.381. QUERY GEOMETRY - CURVED - HORIZONTAL BALANCE [QVX:GMCI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	36h	03h				
Character	G	M	C	I	6					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	36h	3Dh	*1	*3	*5
Character		G	M	C	I	6	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

Hexadecimal	-30						-29				
Character	2Dh	30h	30h	30h	33h	30h	2Dh	30h	30h	30h	39h
Hexadecimal	+29						+30				
Character	2Bh	30h	30h	30h	32h	39h	2Bh	30h	30h	30h	30h
Hexadecimal	-						-				
Character	-	0	0	0	2	9	-	0	0	0	9

● Notes:

· DW11K is returned ER401..

### 2.382. QUERY GEOMETRY - CURVED - VERTICAL KEYSTONE [QVX:GMCS8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	53h	38h	03h				
Character	G	M	C	S	8					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	53h	38h	3Dh	*1	*3	*5
Character		G	M	C	S	8	=	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-40.0					-38.8				
Hexadecimal	2Dh	34h	30h	2Eh	30h	2Dh	33h	38h	2Eh	38h
Character	-	4	0	.	0	-	3	8	.	8
-9.8										
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	-	0	9	.	8	+	0	0	.	0
+38.8										
Hexadecimal	2Bh	33h	38h	2Eh	38h	2Bh	34h	30h	2Eh	30h
Character	+	3	8	.	8	+	4	0	.	0

● Notes:

· DW11K is returned ER401..

### 2.383. QUERY GEOMETRY – CURVED – HORIZONTAL KEYSTONE [QVX:GMCS9]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	53h	39h	03h				
Character	G	M	C	S	9					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	53h	39h	3Dh	*1	*3	*5
Character		G	M	C	S	9	=	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	-15.0					-14.8				
Hexadecimal	2Dh	31h	35h	2Eh	30h	2Dh	31h	34h	2Eh	38h
Character	-	1	5	.	0	-	1	4	.	8
-9.8										
Hexadecimal	2Dh	30h	39h	2Eh	38h	2Bh	30h	30h	2Eh	30h
Character	-	0	9	.	8	+	0	0	.	0
+14.8										
Hexadecimal	2Bh	31h	34h	2Eh	38h	2Bh	31h	35h	2Eh	30h
Character	+	1	4	.	8	+	1	5	.	0

● Notes:

· DW11K is returned ER401..

### 2.384. QUERY GEOMETRY – CURVED – MAINTAIN ASPECT RATIO [QVX:GMCA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	43h	49h	41h	3Dh	2Bh	*1	*3	*5
Character	G	M	C	I	A	=	+	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	43h	49h	41h	3Dh	*1	*3	*5
Character		G	M	C	I	A	=	*2	*4	*6
Hexadecimal	*7	*9	03h							
Character	*8	*10								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Notes:

· DZ10K is returned ER401..

### 2.385. QUERY GEOMETRY - CORNER CORRECTION - UPPER LEFT (V) [QVX:GMFI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	31h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	1	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	31h	3Dh	*1	*3	*5
Character		G	M	F	I	1	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	+0						+300				
Hexadecimal	2Bh	30h	30h	30h	30h	30h	2Bh	30h	30h	33h	30h
Character	+	0	0	0	0	0	+	0	0	3	0

● Notes:

· DW11K is returned ER401..

### 2.386. QUERY GEOMETRY - CORNER CORRECTION - UPPER RIGHT (V) [QVX:GMFI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	32h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	2	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	32h	3Dh	*1	*3	*5
Character		G	M	F	I	2	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	+0						+300				
Hexadecimal	2Bh	30h	30h	30h	30h	30h	2Bh	30h	30h	33h	30h
Character	+	0	0	0	0	0	+	0	0	3	0

● Notes:

· DW11K is returned ER401..

### 2.387. QUERY GEOMETRY - CORNER CORRECTION - LOWER LEFT (V) [QVX:GMFI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	33h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	3	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	33h	3Dh	*1	*3	*5
Character		G	M	F	I	3	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-300						+0					
Hexadecimal	2Dh	30h	30h	30h	30h	30h	2Bh	30h	30h	30h	30h	30h
Character	—	0	0	0	0	0	+	0	0	0	0	0

- Notes:

· DW11K is returned ER401..

## 2.388. QUERY GEOMETRY – CORNER CORRECTION – LOWER RIGHT (V) [QVX:GMFI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	34h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	4	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	34h	3Dh	*1	*3	*5
Character		G	M	F	I	4	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-300						+0					
Hexadecimal	2Dh	30h	30h	33h	30h	30h	2Bh	30h	30h	30h	30h	30h
Character	—	0	0	3	0	0	+	0	0	0	0	0

- Notes:

· DW11K is returned ER401..

## 2.389. QUERY GEOMETRY – CORNER CORRECTION – LINEARITY (V) [QVX:GMFI5]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	35h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	5	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	35h	3Dh	*1	*3	*5
Character		G	M	F	I	5	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-127						+128					
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Bh	30h	30h	31h	32h	37h
Character	—	0	0	1	2	7	+	0	0	1	2	7

- Notes:

· DW11K is returned ER401..

## 2.390. QUERY GEOMETRY – CORNER CORRECTION – UPPER LEFT (H) [QVX:GMFI6]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	36h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	6	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	36h	3Dh	*1	*3	*5
Character		G	M	F	I	6	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	+0						+480					
Hexadecimal	2Bh	30h	30h	30h	30h	30h	2Bh	30h	30h	34h	38h	30h
Character	+	0	0	0	0	0	+	0	0	4	8	0

- Notes:

· DW11K is returned ER401..

## 2.391. QUERY GEOMETRY - CORNER CORRECTION - UPPER RIGHT (H) [QVX:GMFI7]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	37h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	7	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	37h	3Dh	*1	*3	*5
Character		G	M	F	I	7	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-480						+0					
Hexadecimal	2Dh	30h	30h	34h	38h	30h	2Bh	30h	30h	30h	30h	30h
Character	—	0	0	4	8	0	+	0	0	0	0	0

- Notes:

· DW11K is returned ER401..

## 2.392. QUERY GEOMETRY - CORNER CORRECTION - LOWER LEFT (H) [QVX:GMFI8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	38h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	8	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	38h	3Dh	*1	*3	*5
Character		G	M	F	I	8	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	+0						+480					
Hexadecimal	2Bh	30h	30h	30h	30h	30h	2Bh	30h	30h	34h	38h	30h
Character	+	0	0	0	0	0	+	0	0	4	8	0

- Notes:

· DW11K is returned ER401..

### 2.393. QUERY GEOMETRY - CORNER CORRECTION - LOWER RIGHT (H) [QVX:GMFI9]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	31h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	9	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	39h	3Dh	*1	*3	*5
Character		G	M	F	I	9	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-480						+0				
Hexadecimal	2Dh	30h	30h	34h	38h	30h	2Bh	30h	30h	30h	30h
Character	—	0	0	4	8	0	+	0	0	0	0

● Notes:

· DW11K is returned ER401..

### 2.394. QUERY GEOMETRY - CORNER CORRECTION - LINEARITY (H) [QVX:GMFIA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	47h	4Dh	46h	49h	41h	3Dh	*1	*3	*5	*7
Character	G	M	F	I	A	=	*2	*4	*6	*8
Hexadecimal	*9	*11	03h							
Character	*10	*12								

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	47h	4Dh	46h	49h	41h	3Dh	*1	*3	*5
Character		G	M	F	I	A	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	-127						+127				
Hexadecimal	2Dh	30h	30h	31h	32h	37h	2Bh	30h	30h	31h	32h
Character	—	0	0	1	2	7	+	0	0	1	2

● Notes:

· DW11K is returned ER401..

### 2.395. QUERY DISPLAY LANGUAGE [QLG]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	47h	03h
Character		A	D	Z	Z	;	Q	L	G	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	English			German			French		
Hexadecimal	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
Character	E	N	G	D	E	U	F	R	A
	Spanish			Italian			Portuguese		
Hexadecimal	45h	53h	50h	49h	54h	4Ch	50h	4Fh	52h
Character	E	S	P	I	T	L	P	O	R
	Japanese			Chinese			Russian		
Hexadecimal	4Ah	50h	4Eh	43h	48h	49h	52h	55h	53h
Character	J	P	N	C	H	I	R	U	S

Korean			
Hexadecimal	4Bh	4Fh	52h
Character	K	O	R

## 2.396. QUERY SCREEN SETTING – SCREEN FORMAT [QSF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	46h	03h
Character	A	D	Z	Z	;	Q	S	F		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	16:10 *1	16:9	4:3
Hexadecimal	30h	31h	32h
Character	0	1	2

\*1: DS12K is returned ER401.

● Notes:

· DW11K is returned ER401.

## 2.397. QUERY SCREEN SETTING – SCREEN POSITION – VERTICAL [QVX:VSPIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	56h	53h	50h	49h	30h	03h				
Character	V	S	P	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	50h	49h	30h	3Dh	*1	*3	*5
Character	V	S	P	I	0	=	*2	*4		*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

PT-DZ13K/DZ10K, SCREEN FORMAT 16:9

	-60						-59					
Hexadecimal	2Dh	30h	30h	30h	36h	30h	2Dh	30h	30h	30h	35h	39h
Character	—	0	0	0	6	0	—	0	0	0	5	9
	59						60					
Hexadecimal	2Bh	30h	30h	30h	35h	39h	2Bh	30h	30h	30h	30h	30h
Character	+	0	0	0	5	9	+	0	0	0	6	0

PT-DS12K, SCREEN FORMAT 16:9

	-132						-131					
Hexadecimal	2Dh	30h	30h	31h	33h	32h	2Dh	30h	30h	31h	33h	31h
Character	—	0	0	1	3	2	—	0	0	1	3	1
	130						131					
Hexadecimal	2Bh	30h	30h	31h	33h	30h	2Bh	30h	30h	31h	33h	31h
Character	+	0	0	1	3	0	+	0	0	1	3	1

● Notes:

· DW11K is returned ER401.

· DZ13K/DZ10K, when screen format is 4:3 or 16:10, ER401 is returned.

· DS12K, when screen format is 4:3, ER401 is returned.

## 2.398. QUERY SCREEN SETTING – SCREEN POSITION – HORIZONTAL [QVX:HSPIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	48h	53h	50h	49h	30h	03h				
Character	H	S	P	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	48h	53h	50h	49h	30h	3Dh	*1	*3	*5
Character	H	S	P	I	0	=	*2	*4		*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

PT-DZ13K/DZ10K, SCREEN FORMAT 4:3

	-160						-159					
Hexadecimal	2Dh	30h	30h	31h	36h	30h	2Dh	30h	30h	31h	35h	39h
Character	—	0	0	1	6	0	—	0	0	1	5	9
	159						160					
Hexadecimal	2Bh	30h	30h	31h	35h	39h	2Bh	30h	30h	31h	36h	30h
Character	+	0	0	1	5	9	+	0	0	1	6	0

- Notes:

- DW11K is returned ER401.
- DZ13K/DZ10K, when screen format is 4:3 or 16:10, ER401 is returned.
- DS12K, when screen format is 4:3, ER401 is returned.

## 2.399. QUERY TEMPERATURE [QTM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	54h	4Dh	3Ah
Character		A	D	Z	Z	;	Q	T	M	:
Hexadecimal	*1	03h								
Character	*2									

- Parameters(\*1,\*2)

	INTAKE AIR TEMP.	AROUND LAMP TEMP.	OPTICS MODULE TEMP.
Hexadecimal	30h	31h	32h
Character	0	1	2

- Response (Callback)

Case of -20 degrees Celsius

	Celsius					Fahrenheit				
Hexadecimal	02h	2Dh	30h	32h	30h	2Fh	2Dh	30h	30h	34h
Character	—	0	2	0	/	—	0	0	0	4

Case of 120 degrees Celsius

	Celsius					Fahrenheit				
Hexadecimal	02h	30h	31h	32h	30h	2Fh	30h	32h	34h	38h
Character	0	1	2	0	/	0	2	4	8	03h

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## 2.400. QUERY DATE AND TIME – DATE [QGD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	44h	03h
Character		A	D	Z	Z	;	Q	G	D	

- Response (Callback)

Hexadecimal	02h	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*d2	*w	03h
Character											

- Parameters

\*y1~\*y4 : Year (4 digits)

\*m1~\*m2 : Month (2 digits)

\*d1~\*d2 : Day (2 digits)

\*w : Day of the week(Mon=1, Tue=2, Wed=3, Thu=4, Fri=5, Sat=6, Sun=7)

Example: Tuesday, August 17, 2010

	*y1	*y2	*y3	*y4	*m1	*m2	*d1	*d2	*w
Hexadecimal	32h	30h	31h	30h	30h	38h	31h	37h	32h
Character	2	0	1	0	0	8	1	7	2

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.401. QUERY DATE AND TIME – TIME [QGT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	54h	03h
Character		A	D	Z	Z	;	Q	G	T	

- Response (Callback)

Hexadecimal	02h	*h1	*h2	*m1	*m2	*s1	*s2			
Character										

- Parameters

\*h1~\*h2 : Hour (2 digits)

\*m1~\*m2 : Minute (2 digits)

\*s1~\*s2 : Second (2 digits)

Example: 3 seconds at p.m. 3:45

	*h1	*h2	*m1	*m2	*s1	*s2
Hexadecimal	31h	35h	34h	35h	30h	33h
Character	1	5	4	5	0	3

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## 2.402. QUERY PROJECTOR TYPE [QID]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	44h	03h
Character		A	D	Z	Z	;	Q	I	D	

● Response (Callback)

In the period when the command can be accepted

PT-DZ13K

Hexadecimal	02h	44h	5Ah	31h	33h	4Bh	03h
Character		D	Z	1	3	K	

PT-DS12K

Hexadecimal	02h	44h	53h	31h	32h	4Bh	03h
Character		D	S	1	2	K	

PT-DW11K

Hexadecimal	02h	44h	57h	31h	31h	4Bh	03h
Character		D	W	1	1	K	

PT-DZ10K

Hexadecimal	02h	44h	5Ah	31h	30h	4Bh	03h
Character		D	Z	1	0	K	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

## 2.403. QUERY SYSTEM SELECTOR [QRF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	52h	46h	03h
Character		A	D	Z	Z	;	Q	R	F	

● Response (Callback)

VGA60

Hexadecimal	02h		30h		03h
Character			0		

YPbPr/YCbCr

Hexadecimal	02h		31h		03h
Character			1		

AUTO

Hexadecimal	02h		32h		03h
Character			2		

480pRGB

Hexadecimal	02h		33h		03h
Character			3		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	×	○	○	○	○	○	○

## 2.404. QUERY SYSTEM SELECTOR - SDI [QSD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	44h	03h
Character		A	D	Z	Z	;	Q	S	D	

● Response (Callback)

SDI1(SINGLE LINK)

	AUTO			480i			576i		
Hexadecimal	02h	30h	03h	02h	31h	03h	02h	33h	03h
Character		0			1			3	
	1080/60i			1035/60i			720/60p		
Hexadecimal	02h	34h	03h	02h	35h	03h	02h	36h	03h
Character		4			5			6	
	1080/24p			1080/50i			1080/30p		
Hexadecimal	02h	37h	03h	02h	38h	03h	02h	39h	03h
Character		7			8			9	
	1080/25p			1080/24sF			720/50p		
Hexadecimal	02h	31h	30h	02h	31h	31h	02h	31h	32h
Character		1	0		1	1		1	2

	1080/50p YpbPr				1080/60p YpbPr				1080/24p RGB			
Hexadecimal	02h	31h	35h	03h	02h	31h	36h	03h	02h	32h	31h	03h
Character		1	5			1	6		2	1		
	1080/24sF RGB				1080/25p RGB				1080/30p RGB			
Hexadecimal	02h	32h	32h	03h	02h	32h	33h	03h	02h	32h	34h	03h
Character	2	2				2	3		2	4		
	1080/50i RGB				1080/60i RGB							
Hexadecimal	02h	32h	35h	03h	02h	32h	36h	03h				
Character	2	5				2	6					

#### SDI2(SINGLE LINK)

	AUTO			480i			576i		
Hexadecimal	02h	30h	03h	02h	31h	03h	02h	33h	03h
Character	0				1		3		
	1080/60i			1035/60i			720/60p		
Hexadecimal	02h	34h	03h	02h	35h	03h	02h	36h	03h
Character	4				5		6		
	1080/24p			1080/50i			1080/30p		
Hexadecimal	02h	37h	03h	02h	38h	03h	02h	39h	03h
Character	7				8		9		
	1080/25p			1080/24sF			720/50p		
Hexadecimal	02h	31h	30h	03h	02h	31h	31h	03h	02h
Character	1	0			1	1			1
								2	

#### DUAL LINK

	AUTO			1080/24p RGB							
Hexadecimal	02h	30h	03h	02h	32h	31h					
Character	0			2	1						
	1080/24sF RGB			1080/25p RGB							
Hexadecimal	02h	32h	32h	03h	02h	32h					
Character	2	2			2	3					
	1080/50i RGB			1080/60i RGB							
Hexadecimal	02h	32h	35h	03h	02h	32h					
Character	2	5			2	6					
	2K/24sF RGB			2K/24p XYZ							
Hexadecimal	02h	33h	32h	03h	02h	34h					
Character	3	2			4	1					

#### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

#### 2.405. QUERY WAVEFORM MONITOR [QWM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	47h	4Dh	03h
Character	A	D	Z	Z	Z	;	Q	W	M	

#### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

#### Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	×	○

#### ● Parameters(\*1,\*2)

	OFF	Select line (luminance)	Select line (red)	Select line (green)	Select line (blue)
Hexadecimal	30h	35h	36h	37h	38h
Character	0	5	6	7	8

#### 2.406. QUERY WAVEFORM MONITOR - LINE ADJUSTMENT [QVX:WMLIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	Z	;	Q	V	X	:
Hexadecimal	57h	4Dh	4Ch	49h	30h	03h				
Character	W	M	L	I	O					

#### ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	57h	4Dh	4Ch	49h	30h	3Dh	2Bh
Character	W	M	L	I	O	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	×	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
1198					1199					
Hexadecimal	30h	31h	31h	39h	38h	30h	31h	31h	39h	39h
Character	0	1	1	9	8	0	1	1	9	9

## 2.407. QUERY AUTO SIGNAL [QVX:AASIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	41h	41h	53h	49h	30h	03h				
Character	A	A	S	I	0					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	41h	53h	49h	30h	3Dh	2Bh
Character	A	A	S	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## 2.408. QUERY AUTO SETUP - MODE [QAM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	4Dh	03h
Character	A	D	Z	Z	;	Q	V	A	M	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2)

	USER	DEFAULT	WIDE
Hexadecimal	30h	31h	32h
Character	0	1	2

## 2.409. QUERY AUTO SETUP - POSITION ADJUST [QVX:APA10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	41h	50h	41h	49h	30h	03h				
Character	A	P	A	I	0					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	50h	41h	49h	30h	3Dh	2Bh
Character	A	P	A	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

#### 2.410. QUERY AUTO SETUP - SIGNAL LEVEL ADJUST [QVX:ASLIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	41h	53h	4Ch	49h	30h	03h				
Character	A	S	L	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	53h	4Ch	49h	30h	3Dh	2Bh
Character		A	S	L	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

#### 2.411. QUERY DVI-D IN - EDID [QED]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	44h	03h
Character		A	D	Z	Z	;	Q	E	D	:

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	EDID1	EDID2(PC)	EDID3
Hexadecimal	31h	32h	33h
Character	1	2	3

#### 2.412. QUERY DVI-D IN - SIGNAL LEVEL [QVX:DVIIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	56h	49h	49h	30h	03h				
Character	D	V	I	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	56h	49h	49h	30h	3Dh	2Bh
Character		D	V	I	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0-255:PC					16-235					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

#### 2.413. QUERY HDMI IN - SIGNAL LEVEL [QVX:HSLIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	48h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	48h	53h	4Ch	49h	30h	03h				
Character	H	S	L	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	48h	53h	4Ch	49h	30h	3Dh	2Bh
Character		H	S	L	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0-1023					64-940					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2

## 2.414. QUERY SDI IN - SIGNAL LEVEL [QED:SDI-LEVEL]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	44h	3Ah
Character	A	D	Z	Z	;	Q	E	D	:	
Hexadecimal	53h	44h	49h	2Dh	4Ch	45h	56h	45h	4Ch	03h
Character	S	D	I	-	L	E	V	E	L	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2)

	64-940		4-1019	
Hexadecimal	30h		31h	
Character	0		1	

## 2.415. QUERY P IN P - MODE [QPP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	50h	03h
Character	A	D	Z	Z	;	Q	P	P	P	

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	×	○	○	○	×

## ● Parameters(\*1,\*2)

	OFF		USER1		USER2		USER3	
Hexadecimal	30h		31h		32h		33h	
Character	0		1		2		3	

## 2.416. QUERY P IN P - MAIN WINDOW [QIM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	4Dh	03h
Character	A	D	Z	Z	;	Q	I	M		

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	RGB1			RGB2			Video		
Hexadecimal	52h	47h	31h	52h	47h	32h	56h	49h	44h
Character	R	G	1	R	G	2	V	I	D
	DVI			HDMI			SDI1		
Hexadecimal	44h	56h	49h	48h	44h	31h	53h	44h	31h
Character	D	V	I	H	D	1	S	D	1
	SDI2								
Hexadecimal	53h	44h	32h						
Character	S	D	2						

## 2.417. QUERY P IN P - MAIN WINDOW - SIZE [QSM]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Dh	03h
Character		A	D	Z	Z	;	Q	S	M	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	2Ch	56h	*5	*7	*9	2Ch	48h
Character		*2	*4	,	V	*6	*8	*10	,	H
Hexadecimal	*11	*13	*15	2Ch	56h	48h	*17	*19	*21	03h
Character	*12	*14	*16	,	H	V	*18	*20	*22	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,\*3,\*4)

· INTERLOCKED

	OFF	ON		
Hexadecimal	4Fh	46h	4Fh	4Eh
Character	0	F	0	N

● Parameters(\*5, \*6, \*7, \*8, \*9, \*10)

· VERTICAL SIZE

	10		11		12		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h
Character	0	1	0	0	1	1	0
	98		99		100		
Hexadecimal	30h	39h	38h	30h	39h	39h	31h
Character	0	9	8	0	9	9	1
							0

● Parameters(\*11, \*12, \*13, \*14, \*15, \*16)

· HORIZONTAL SIZE

	10		11		12		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h
Character	0	1	0	0	1	1	0
	98		99		100		
Hexadecimal	30h	39h	38h	30h	39h	39h	31h
Character	0	9	8	0	9	9	1
							0

● Parameters(\*17, \*18, \*19, \*20, \*21, \*22)

· HORIZONTAL/VERTICAL SIZE

	10		11		12		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h
Character	0	1	0	0	1	1	0
	98		99		100		
Hexadecimal	30h	39h	38h	30h	39h	39h	31h
Character	0	9	8	0	9	9	1
							0

## 2.418. QUERY P IN P - MAIN WINDOW - POSITION [QPA]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	41h	03h
Character		A	D	Z	Z	;	Q	P	A	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	*1	*3	*5	*7	2Ch
Character		V	*2	*4	*6	*8	,
Hexadecimal	48h	*9	*11	*13	*15	03h	
Character	H	*10	*12	*14	*16		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1, \*2, \*3, \*4, \*5, \*6, \*7, \*8,)

· VERTICAL POSITION

PT-DZ13K/DZ10K

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8
	+578				+579				+580			

Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

PT-DS12K

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3
	+503				+504				+505			

Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	5
PT-DW11K												
	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2
	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

● Parameters(\*9, \*10, \*11, \*12, \*13, \*14, \*15, \*16)

· HORIZONTAL POSITION

PT-DZ13K/DZ10K

	-928				-927				-926			
Hexadecimal	2Dh	39h	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
+926												
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

PT-DS12K

	-668				-667				-666			
Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
+666												
Hexadecimal	2Bh	36h	36h	36h	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	6	6	+	6	6	7	+	6	6	8

PT-DW11K

	-651				-650				-649			
Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
+649												
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

## 2.419. QUERY P IN P - SUB WINDOW [QIS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	49h	53h	03h		
Character	A	D	Z	Z	;	Q	I	S	S			

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	RGB1			RGB2			Video		
Hexadecimal	52h	47h	31h	52h	47h	32h	56h	49h	44h
Character	R	G	1	R	G	2	V	I	D
DVI									
Hexadecimal	44h	56h	49h	48h	44h	31h	53h	44h	31h
Character	D	V	I	H	D	1	S	D	1
	SDI2								
Hexadecimal	53h	44h	32h						
Character	S	D	2						

## 2.420. QUERY P IN P - SUB WINDOW - SIZE [QSS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	53h	03h		
Character	A	D	Z	Z	;	Q	S	S	S			

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	2Ch	56h	*5	*7	*9	2Ch	48h		
Character		*2	*4	.	V	*6	*8	*10	.	H		
Hexadecimal	*11	*13	*15	2Ch	56h	48h	*17	*19	*21	03h		
Character	*12	*14	*16	.	H	V	*18	*20	*22			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,\*3,\*4)

· INTERLOCKED

	OFF		ON	
Hexadecimal	4Fh	46h	4Fh	4Eh
Character	O	F	O	N

● Parameters(\*5, \*6, \*7, \*8, \*9, \*10)

· VERTICAL SIZE

	10			11			12		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h
Character	0	1	0	0	1	1	0	1	2

  

Hexadecimal	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	8	0	9	9	1	0	0

● Parameters(\*11, \*12, \*13, \*14, \*15, \*16)

· HORIZONTAL SIZE

	10			11			12		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h
Character	0	1	0	0	1	1	0	1	2

  

Hexadecimal	30h	39h	38h	30h	39h	39h	31h	30h	30h
Character	0	9	8	0	9	9	1	0	0

● Parameters(\*17, \*18, \*19, \*20, \*21, \*22)

· HORIZONTAL/VERTICAL SIZE

	10			11			12		
Hexadecimal	30h	31h	30h	30h	31h	31h	30h	31h	32h
Character	0	1	0	0	1	1	0	1	2

  

Hexadecimal	30h	56h	*1	*3	*5	*7	2Ch
Character		V	*2	*4	*6	*8	,
Hexadecimal	48h	*9	*11	*13	*15	03h	
Character	H	*10	*12	*14	*16		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	*1	*3	*5	*7	2Ch
Character		V	*2	*4	*6	*8	,
Hexadecimal	48h	*9	*11	*13	*15	03h	
Character	H	*10	*12	*14	*16		

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1, \*2, \*3, \*4, \*5, \*6, \*7, \*8,)

· VERTICAL POSITION

PT-DZ13K/DZ10K

	-580				-579				-578			
Hexadecimal	2Dh	35h	38h	30h	2Dh	35h	37h	39h	2Dh	35h	37h	38h
Character	-	5	8	0	-	5	7	9	-	5	7	8

  

	+578				+579				+580			
Hexadecimal	2Bh	35h	37h	38h	2Bh	35h	37h	39h	2Bh	35h	38h	30h
Character	+	5	7	8	+	5	7	9	+	5	8	0

PT-DS12K

	-505				-504				-503			
Hexadecimal	2Dh	35h	30h	35h	2Dh	35h	30h	34h	2Dh	35h	30h	33h
Character	-	5	0	5	-	5	0	4	-	5	0	3

  

	+503				+504				+505			
Hexadecimal	2Bh	35h	30h	33h	2Bh	35h	30h	34h	2Bh	35h	30h	35h
Character	+	5	0	3	+	5	0	4	+	5	0	5

PT-DW11K

	-364				-363				-362			
Hexadecimal	2Dh	33h	36h	34h	2Dh	33h	36h	33h	2Dh	33h	36h	32h
Character	-	3	6	4	-	3	6	3	-	3	6	2

  

	+362				+363				+364			
Hexadecimal	2Bh	33h	36h	32h	2Bh	33h	36h	33h	2Bh	33h	36h	34h
Character	+	3	6	2	+	3	6	3	+	3	6	4

● Parameters(\*9, \*10, \*11, \*12, \*13, \*14, \*15, \*16)

· HORIZONTAL POSITION

PT-DZ13K/DZ10K

	-928				-927				-926			
Hexadecimal	2Dh	39h	32h	38h	2Dh	39h	32h	37h	2Dh	39h	32h	36h
Character	-	9	2	8	-	9	2	7	-	9	2	6
+926				+927				+928				
Hexadecimal	2Bh	39h	32h	36h	2Bh	39h	32h	37h	2Bh	39h	32h	38h
Character	+	9	2	6	+	9	2	7	+	9	2	8

PT-DS12K

	-668				-667				-666			
Hexadecimal	2Dh	36h	36h	38h	2Dh	36h	36h	37h	2Dh	36h	36h	36h
Character	-	6	6	8	-	6	6	7	-	6	6	6
+666				+667				+668				
Hexadecimal	2Bh	36h	36h	36h	2Bh	36h	36h	37h	2Bh	36h	36h	38h
Character	+	6	6	6	+	6	6	7	+	6	6	8

PT-DW11K

	-651				-650				-649			
Hexadecimal	2Dh	36h	35h	31h	2Dh	36h	35h	30h	2Dh	36h	34h	39h
Character	-	6	5	1	-	6	5	0	-	6	4	9
+649				+650				+651				
Hexadecimal	2Bh	36h	34h	39h	2Bh	36h	35h	30h	2Bh	36h	35h	31h
Character	+	6	4	9	+	6	5	0	+	6	5	1

## 2.422. QUERY P IN P - SUB WINDOW - CLOCK PHASE [QVX:SCPIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah	
Character	A	D	Z	Z	:	;	Q	V	X	:	
Hexadecimal	53h	43h	50h	49h	30h	03h					
Character	S	C	P	I	0						

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	43h	50h	49h	30h	3Dh	2Bh	*1	*3
Character	S	C	P	I	0	=	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					1				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1
	30					31				
Hexadecimal	30h	30h	30h	33h	30h	30h	30h	33h	31h	
Character	0	0	0	3	0	0	0	3	1	

## 2.423. QUERY P IN P - FRAME LOCK [QPF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	46h	03h
Character	A	D	Z	Z	:	;	Q	P	F	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

## 2.424. QUERY P IN P – TYPE [QPT]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	50h	54h	03h
Character		A	D	Z	Z	;	Q	P	T	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2)

	MAIN WINDOW	SUB WINDOW
Hexadecimal	30h	31h
Character	0	1

## 2.425. QUERY BRIGHTNESS CONTROL – GAIN [QVX:TGAIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	54h	47h	41h	49h	30h	03h				
Character	T	G	A	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	54h	47h	41h	49h	30h	3Dh	2Bh	*1	*3
Character		T	G	A	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	20%					21%				
Hexadecimal	30h	30h	30h	32h	30h	30h	30h	30h	32h	31h
Character	0	0	0	2	0	0	0	0	2	1
99%										
Hexadecimal	30h	30h	30h	39h	39h	30h	30h	31h	30h	30h
Character	0	0	0	9	9	0	0	1	0	0

## 2.426. QUERY BRIGHTNESS CONTROL – SETUP – MODE [QVX:BCMIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	42h	43h	4Dh	49h	30h	03h				
Character	B	C	M	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	42h	43h	4Dh	49h	30h	3Dh	2Bh	*1	*3
Character		B	C	M	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	1	
PC										
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

## 2.427. QUERY BRIGHTNESS CONTROL – SETUP – LINK [QVX:BCLI0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	42h	43h	4Ch	49h	30h	03h				
Character	B	C	L	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	42h	43h	4Ch	49h	30h	3Dh	2Bh	*1	*3
Character		B	C	L	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					GROUP A				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	1	
	GROUP B					GROUP C				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	33h	
Character	0	0	0	0	2	0	0	0	3	
	GROUP D									
Hexadecimal	30h	30h	30h	30h	34h					
Character	0	0	0	0	4					

## 2.428. QUERY SCHEDULE [QVX:SCHIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	43h	48h	49h	30h	03h				
Character	S	C	H	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	43h	48h	49h	30h	3Dh	2Bh	*1	*3
Character		S	C	H	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	1	

## 2.429. QUERY SCHEDULE – PROGRAM ASSIGN [QVX:SPGI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	50h	47h	49h	*1	03h				
Character	S	P	G	I	*2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	50h	47h	49h	*1	3Dh	2Bh	*3	*5
Character		S	P	G	I	*2	=	+	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	Sun	Mon	Tue	Wed	Thu	Fri	Sat
Hexadecimal	30h	31h	32h	33h	34h	35h	36h
Character	0	1	2	3	4	5	6

● Parameters(\*3, \*4, \*5, \*6, \*7, \*8, \*9, \*10, \*11, \*12)

	OFF					PROGRAM 1					PROGRAM 2				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	1	0	0	0	0	2
	PROGRAM 3					PROGRAM 4					PROGRAM 5				
Hexadecimal	30h	30h	30h	30h	33h	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	3	0	0	0	0	4	0	0	0	0	5
	PROGRAM 6					PROGRAM 7									
Hexadecimal	30h	30h	30h	30h	36h	30h	30h	30h	30h	37h					
Character	0	0	0	0	6	0	0	0	0	7					

2.430. QUERY SCHEDULE – COMMAND SETTING [QVX:SCCS]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	43h	43h	53h	*1	3Dh	*3	*5	03h	
Character	S	C	C	S	*2	=	*4	*6		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	43h	43h	53h	*1	3Dh	2Bh	*3	*5
Character		S	C	C	S	*2	=	+	*4	*6
Hexadecimal	*7	*9	*11	*13	*15	*17	03h			
Character	*8	*10	*12	*14	*16	*18				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	PROGRAM 1	PROGRAM 2	PROGRAM 3	PROGRAM 4
Hexadecimal	31h	32h	33h	34h
Character	1	2	3	4
	PROGRAM 5	PROGRAM 6	PROGRAM 7	
Hexadecimal	35h	36h	37h	
Character	5	6	7	

● Parameters(\*3, \*4, \*5, \*6)

	COMMAND 1	COMMAND 2	COMMAND 3	COMMAND 4
Hexadecimal	30h	31h	30h	32h
Character	0	1	0	2
	COMMAND 13	COMMAND 14	COMMAND 15	COMMAND 16
Hexadecimal	31h	33h	31h	34h
Character	1	3	1	4

● Parameters(\*7, \*8, \*9, \*10)

	COMMAND Del	STANDBY	POWER ON	SHUTTER OPEN	SHUTTER CLOSE
Hexadecimal	30h	30h	31h	30h	32h
Character	0	0	1	0	2
	RGB1 INPUT	RGB2 INPUT	Video INPUT	DVI-D INPUT	SDI1 INPUT
Hexadecimal	33h	31h	33h	32h	34h
Character	3	1	3	2	4
	HDMI INPUT	SDI2 INPUT	LAMP POWER HIGH	LAMP POWER MIDDLE	LAMP POWER ECO
Hexadecimal	35h	33h	35h	36h	37h
Character	5	3	5	6	7
	LAMP SELECT SINGLE	LAMP SELECT DUAL			
Hexadecimal	38h	31h	38h	32h	
Character	8	1	8	2	
	P IN POFF	P IN PUSER1	P IN PUSER2	P IN PUSER3	
Hexadecimal	39h	39h	39h	39h	39h
Character	9	9	9	9	1

2.431. QUERY NO SIGNAL SHUT-OFF [QAF]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	41h	46h	03h
Character		A	D	Z	Z	;	Q	A	F	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4)

	DISABLE		10 MIN.		20 MIN.		30 MIN.		40 MIN.	
Hexadecimal	30h	30h	31h	30h	32h	30h	33h	30h	34h	30h
Character	0	0	1	0	2	0	3	0	4	0
	50 MIN.		60 MIN.		70 MIN.		80 MIN.		90 MIN.	
Hexadecimal	35h	30h	36h	30h	37h	30h	38h	30h	39h	30h
Character	5	0	6	0	7	0	8	0	9	0

2.432. QUERY ON-SCREEN DISPLAY – INPUT GUIDE [QDI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	49h	03h
Character		A	D	Z	Z	;	Q	D	I	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	OFF		ON	
Hexadecimal	30h		31h	
Character	0		1	

2.433. QUERY ON-SCREEN DISPLAY – WARNING MESSAGE [QVX:WMDIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	57h	4Dh	44h	49h	30h	03h				
Character	W	M	D	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	57h	4Dh	44h	49h	30h	3Dh	2Bh	*1	*3
Character		W	M	D	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

2.434. QUERY ON-SCREEN DISPLAY – OSD DESIGN [QOD]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Fh	44h	03h
Character		A	D	Z	Z	;	Q	O	D	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	1 (yellow)	2 (blue)	3 (white)	4 (green)	5 (peach)	6 (brown)
Hexadecimal	30h	31h	32h	33h	34h	35h
Character	0	1	2	3	4	5

## 2.435. QUERY ON-SCREEN DISPLAY - OSD POSITION [QDP]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	44h	50h	03h
Character		A	D	Z	Z	;	Q	D	P	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	Upper left	Center left	Bottom left	Top center	Center	Bottom center
Hexadecimal	31h	32h	33h	34h	35h	36h
Character	1	2	3	4	5	6
	Upper right	Center right	Bottom right			
Hexadecimal	37h	38h	39h			
Character	7	8	9			

## 2.436. QUERY ON-SCREEN DISPLAY - OSD MEMORY [QVX:OMYI0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Fh	4Dh	59h	49h	30h	03h				
Character	0	M	Y	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Dh	59h	49h	30h	3Dh	2Bh	*1	*3
Character		0	M	Y	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## 2.437. QUERY STARTUP LOGO [QLO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	4Ch	4Fh	03h
Character		A	D	Z	Z	;	Q	L	O	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

Parameters(\*1,\*2)

	NONE	USER LOGO	DEFAULT LOGO
Hexadecimal	30h	31h	32h
Character	0	1	2

## 2.438. QUERY BACK COLOR [QBC]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	42h	43h	03h
Character		A	D	Z	Z	;	Q	B	C	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2)

	BLUE	BLACK	USER LOGO	DEFAULT LOGO
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

2.439. QUERY SERIAL NUMBER [QSN]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	53h	4Eh	03h
Character	A	D	Z	Z	;	Q	S	N		

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	~	*21	*23	03h
Character		*2	*4		*22	*24	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4 ~\*21,\*22,\*23,\*24)

- The setting data (serial number) is returned.

Example: Serial number unconfigured.

Hexadecimal	02h	03h
Character		

Example: When serial number is SW0101234.

Hexadecimal	02h	53h	57h	30h	31h	30h	31h	32h	33h	34h	03h
Character		S	W	0	1	0	1	2	3	4	

2.440. QUERY LAMP UNIT MODEL No. [QVX:LMNS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	4Ch	4Dh	4Eh	53h	30h	03h				
Character	L	M	N	S	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Ch	4Dh	4Eh	53h	30h	3Dh	*1	*3	*5
Character	L	M	N	S	0	=	*2	*4	*6	
Hexadecimal	*7	*9	*11	*13	*15	*17	*19	03h		
Character	*8	*10	*12	*14	*16	*18	*20			

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4 ~\*17,\*18,\*19,\*20)

- The model number of lamp unit that has been set is returned.

PT-DZ13K/DS12K/DW11K/DZ10K : Normal lamp

Hexadecimal	45h	54h	2Dh	4C	41	44	33	31	30	41
Character	E	T	—	L	A	D	3	1	0	A

PT-DZ13K/DS12K/DW11K/DZ10K : Portrait lamp

Hexadecimal	45h	54h	2Dh	4C	41	44	33	32	30	50
Character	E	T	—	L	A	D	3	2	0	P

2.441. QUERY AIR FILTER UNIT MODEL No. [QVX:FMNS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	46h	4Dh	4Eh	53h	30h	03h				
Character	F	M	N	S	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	46h	4Dh	4Eh	53h	30h	3Dh	*1	*3	*5
Character	F	M	N	S	0	=	*2	*4	*6	
Hexadecimal	*7	*9	*11	*13	*15	*17	03h			
Character	*8	*10	*12	*14	*16	*18				

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4 ~\*15,\*16,\*17,\*18)

· Model number of filter unit that has been set is returned.

PT-DZ13K/DS12K/DW11K/DZ10K : Normal filter

Hexadecimal	45h	54h	2Dh	45h	4Dh	46h	33h	32h	30h
Character	E	T	-	E	M	F	3	2	0

PT-DZ13K/DS12K/DW11K/DZ10K : Smoke cut filter

Hexadecimal	45h	54h	2Dh	53h	46h	44h	33h	32h	30h
Character	E	T	-	S	F	D	3	2	0

## 2.442. QUERY AIR FILTER TYPE [QFI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	45h	49h	3Ah
Character		A	D	Z	Z	;	Q	F	I	:
Hexadecimal	32h	03h								
Character	2									

● Response (Callback)

In the period when the command can be accepted

The case of query filter type (QFI:2).

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,)

	NORMAL	SPECIAL
Hexadecimal	30h	31h
Character	0	1

● Note:

During standby, and notifies the filter information acquired in the power ON during the previous.

## 2.443. QUERY STANDBY MODE [QVX:STM10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	54h	4Dh	49h	30h	03h				
Character	S	T	M	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	54h	4Dh	49h	30h	3Dh	2Bh	*1	*3
Character		S	T	M	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					ECO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	33h
Character	0	0	0	0	0	0	0	0	0	3

## 2.444. QUERY SDI IN - SDI LINK [QVX:SLKI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	4Ch	4Bh	49h	31h	03h				
Character	S	L	K	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	4Ch	4Bh	49h	31h	3Dh	2Bh	*1	*3
Character		S	L	K	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	SINGLE LINK					DUAL LINK				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Note:

· DW11K/DZ10K is returned ER401.

#### 2.445. QUERY SDI IN - BIT DEPTH [QVX:SBT11]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	42h	54h	49h	31h	03h				
Character	S	B	T	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	42h	54h	49h	31h	3Dh	2Bh	*1	*3
Character		S	B	T	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					12-bit				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	10-bit									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

● Note:

·DW11K is returned ER401.

#### 2.446. QUERY SDI IN - BIT DEPTH (DUAL) [QVX:SBT13]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	42h	54h	49h	33h	03h				
Character	S	B	T	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	42h	54h	49h	33h	3Dh	2Bh	*1	*3
Character		S	B	T	I	3	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					12-bit				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	10-bit									
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

● Note:

·DW11K/DZ10K is returned ER401.

#### 2.447. QUERY SDI IN - 3G-SDI MAPPING [QVX:SGM11]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	47h	4Dh	49h	31h	03h				
Character	S	G	M	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	47h	4Dh	49h	31h	3Dh	2Bh	*1	*3
Character		S	G	M	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					LEVEL A				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
LEVEL B										
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

- Note:

·DW11K is returned ER401.

## 2.448. QUERY 3D SETTINGS – 3D SYSTEM SETTING [QVX:DSYI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	53h	59h	49h	31h	03h				
Character	D	S	Y	I	1					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	53h	59h	49h	31h	3Dh	2Bh	*1	*3
Character		D	S	Y	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	SINGLE					DUAL (LEFT)				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
DUAL (RIGHT)										
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

- Note:

·DZ10K is returned ER401.

## 2.449. QUERY 3D SETTINGS – 3D FILTER [QVX:DFTI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	46h	54h	49h	31h	03h				
Character	D	F	T	I	1					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	46h	54h	49h	31h	3Dh	2Bh	*1	*3
Character		D	F	T	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					OFF				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
ON										
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

- Note:

·DZ10K is returned ER401.

## 2.450. QUERY 3D SETTINGS – 3D SYNC SETTING – 3D SYNC MODE [QVX:DSN1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44	53	4E	49h	31h	03h				
Character	D	S	N	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44	53	4E	49h	31h	3Dh	2Bh	*1	*3
Character		D	S	N	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					1				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1
	2					3				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
	4					5				
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5
	6					7				
Hexadecimal	30h	30h	30h	30h	36h	30h	30h	30h	30h	37h
Character	0	0	0	0	6	0	0	0	0	7
	8					9				
Hexadecimal	30h	30h	30h	30h	38h	30h	30h	30h	30h	39h
Character	0	0	0	0	8	0	0	0	0	9
	10					11				
Hexadecimal	30h	30h	30h	31h	30h	30h	30h	30h	31h	31h
Character	0	0	0	1	0	0	0	0	1	1

● Note:

• DZ10K is returned ER401.

## 2.451. QUERY 3D SETTINGS – 3D SYNC SETTING – STEREO SYNC OUTPUT DELAY [QVX:DSN12]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44	53	4E	49h	32h	03h				
Character	D	S	N	I	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44	53	4E	49h	32h	3Dh	2Bh	*1	*3
Character		D	S	N	I	2	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0					10				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h
Character	0	0	0	0	0	0	0	0	1	0
	24990					25000				
Hexadecimal	32h	34h	39h	39h	30h	32h	35h	30h	30h	30h
Character	2	4	9	9	0	2	5	0	0	0

● Note:

• DZ10K is returned ER401.

#### 2.452. QUERY 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:RGB1 RIGHT:RGB2 [QVX:DSM1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	53h	4Dh	49h	31h	03h				
Character	D	S	M	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	53h	4Dh	49h	31h	3Dh	2Bh	*1	*3
Character		D	S	M	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

● Note:

· DZ10K is returned ER401.

#### 2.453. QUERY 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:HDMI RIGHT:DVI-D [QVX:DSM2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	53h	4Dh	49h	32h	03h				
Character	D	S	M	I	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	53h	4Dh	49h	32h	3Dh	2Bh	*1	*3
Character		D	S	M	I	2	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>							

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

● Note:

· DZ10K is returned ER401.

#### 2.454. QUERY 3D SETTINGS – 3D SIMUL INPUT SETTING – LEFT:SDI1 RIGHT:SDI2 [QVX:DSM3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	53h	4Dh	49h	33h	03h				
Character	D	S	M	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	53h	4Dh	49h	33h	3Dh	2Bh	*1	*3
Character		D	S	M	I	3	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>							

Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					AUTO				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	32h
Character	0	0	0	0	0	0	0	0	0	2

● Note:

· DW11K/DZ10K is returned ER401.

## 2.455. QUERY 3D SETTINGS – 3D INPUT FORMAT [QVX:DIFI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	49h	46h	49h	31h	03h				
Character	D	I	F	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	49h	46h	49h	31h	3Dh	2Bh	*1	*3
Character		D	I	F	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	AUTO					NATIVE (2D)				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	SIMULTANEOUS					SIDE BY SIDE				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
	TOP AND BOTTOM					LINE BY LINE				
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5
	FRAME SEQUENTIAL									
Hexadecimal	30h	30h	30h	30h	36h					
Character	0	0	0	0	6					

● Note:

· DZ10K is returned ER401.

## 2.456. QUERY 3D SETTINGS – LEFT/RIGHT SWAP [QVX:DSWI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	53h	57h	49h	31h	03h				
Character	D	S	W	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	53h	57h	49h	31h	3Dh	2Bh	*1	*3
Character		D	S	W	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					SWAPPED				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Note:

· DZ10K is returned ER401.

## 2.457. QUERY 3D SETTINGS – 3D COLOR MATCHING [QVX:DCMI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	43h	4Dh	49h	31h	03h				
Character	D	C	M	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	43h	4Dh	49h	31h	3Dh	2Bh	*1	*3
Character		D	C	M	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	SHARED 2D/3D					SEPARATE 2D/3D				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

- Notes:

· DZ10K is returned ER401.

## 2.458. QUERY 3D SETTINGS – 3D PICTURE BALANCE – CONTRAST [QVX:DBA11]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	:	Q	V	X	:	
Hexadecimal	44h	42h	41h	49h	31h	03h				
Character	D	B	A	I	1					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	31h	3Dh	2Bh	*1	*3
Character	D	B	A	I	1	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	30h	38h	31h
Character	0	0	0	8	0	0	0	0	8	1
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

- Note:

· DZ10K is returned ER401.

## 2.459. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH RED [QVX:DBA12]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	:	Q	V	X	:	
Hexadecimal	44h	42h	41h	49h	32h	03h				
Character	D	B	A	I	2					

- Response (Callback 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH RED )

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	32h	3Dh	2Bh	*1	*3
Character	D	B	A	I	2	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	30h	38h	31h
Character	0	0	0	8	0	0	0	0	8	1
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

- Note:

· DZ10K is returned ER401.

## 2.460. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH GREEN [QVX:DBA13]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	:	Q	V	X	:	
Hexadecimal	44h	42h	41h	49h	33h	03h				
Character	D	B	A	I	3					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	33h	3Dh	2Bh	*1	*3
Character	D	B	A	I	3	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	38h	31h	
Character	0	0	0	8	0	0	0	8	1	
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

## ● Note:

·DZ10K is returned ER401.

## 2.461. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE HIGH BLUE [QVX:DBA14]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	44h	42h	41h	49h	34h	03h				
Character	D	B	A	I	4					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	34h	3Dh	2Bh	*1	*3
Character	D	B	A	I	4	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	38h	31h	
Character	0	0	0	8	0	0	0	8	1	
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

## ● Note:

·DZ10K is returned ER401.

## 2.462. QUERY 3D SETTINGS – 3D PICTURE BALANCE – BRIGHTNESS [QVX:DBA15]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	54h	47h	41h	49h	35h	03h				
Character	D	B	A	I	5					

## ● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	54h	47h	41h	49h	35h	3Dh	*1	*3	*5
Character		D	B	A	I	5	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

## Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

## ● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11, \*12)

	-8						-7					
Hexadecimal	2Dh	30h	30h	30h	30h	38h	2Dh	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	0	7
	+7						+8					
Hexadecimal	2Bh	30h	30h	30h	30h	37h	2Bh	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	0	8

## ● Note:

·DZ10K is returned ER401.

### 2.463. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW RED [QVX:DBA16]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	42h	41h	49h	36h	03h				
Character	D	B	A	I	6					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	36h	3Dh	*1	*3	*5
Character		D	B	A	I	6	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11, \*12)

						-8				-7
Hexadecimal	2Dh	30h	30h	30h	30h	38h	2Dh	30h	30h	30h
Character	-	0	0	0	0	8	-	0	0	0
						+7				+8
Hexadecimal	2Bh	30h	30h	30h	30h	37h	2Bh	30h	30h	30h
Character	+	0	0	0	0	7	+	0	0	0
										38h

● Note:

· DZ10K is returned ER401.

### 2.464. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW GREEN [QVX:DBA17]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	42h	41h	49h	37h	03h				
Character	D	B	A	I	7					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	37h	3Dh	*1	*3	*5
Character		D	B	A	I	7	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11, \*12)

						-8				-7
Hexadecimal	2Dh	30h	30h	30h	30h	38h	2Dh	30h	30h	30h
Character	-	0	0	0	0	8	-	0	0	0
						+7				+8
Hexadecimal	2Bh	30h	30h	30h	30h	37h	2Bh	30h	30h	30h
Character	+	0	0	0	0	7	+	0	0	0
										38h

● Note:

· DZ10K is returned ER401.

### 2.465. QUERY 3D SETTINGS – 3D PICTURE BALANCE – WHITE BALANCE LOW BLUE [QVX:DBA18]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	42h	41h	49h	38h	03h				
Character	D	B	A	I	8					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	38h	3Dh	*1	*3	*5
Character		D	B	A	I	8	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11, \*12)

	-8						-7					
Hexadecimal	2Dh	30h	30h	30h	30h	38h	2Dh	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	0	7
	+7						+8					
Hexadecimal	2Bh	30h	30h	30h	30h	37h	2Bh	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	0	8

- Note:

·DZ10K is returned ER401.

## 2.466. QUERY 3D SETTINGS – 3D PICTURE BALANCE – COLOR [QVX:DBA19]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	44h	42h	41h	49h	39h	03h				
Character	D	B	A	I	9					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	39h	3Dh	2Bh	*1	*3
Character		D	B	A	I	9	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	80					81				
Hexadecimal	30h	30h	30h	38h	30h	30h	30h	38h	31h	
Character	0	0	0	8	0	0	0	8	1	
	119					120				
Hexadecimal	30h	30h	31h	31h	39h	30h	30h	31h	32h	30h
Character	0	0	1	1	9	0	0	1	2	0

- Note:

·DZ10K is returned ER401.

## 2.467. QUERY 3D SETTINGS – 3D PICTURE BALANCE – TINT [QVX:DBA1A]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	44h	42h	41h	49h	41h	03h				
Character	D	B	A	I	A					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	42h	41h	49h	41h	3Dh	*1	*3	*5
Character		D	B	A	I	A	=	*2	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	x	x	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11)

	-8						-7					
Hexadecimal	2Dh	30h	30h	30h	30h	38h	2Dh	30h	30h	30h	30h	37h
Character	-	0	0	0	0	8	-	0	0	0	0	7
	+7						+8					
Hexadecimal	2Bh	30h	30h	30h	30h	37h	2Bh	30h	30h	30h	30h	38h
Character	+	0	0	0	0	7	+	0	0	0	0	8

- Note:

·DZ10K is returned ER401.

## 2.468. QUERY 3D SETTINGS – DARK TIME SETTING [QVX:DDTS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	44h	54h	53h	31h	03h				
Character	D	D	T	S	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	44h	54h	53h	31h	3Dh	*1	*3
Character		D	D	T	S	1	=	*2	*4
Hexadecimal	*5	03h							
Character	*6								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	0.5 ms			1.0 ms			1.5 ms		
Hexadecimal	30h	2Eh	30h	31h	2Eh	30h	31h	2Eh	35h
Character	0	.	0	1	.	0	1	.	5
	2.0 ms			2.5 ms			2.7 ms		
Hexadecimal	32h	2Eh	30h	32h	2Eh	35h	32h	2Eh	37h
Character	2	.	0	2	.	5	2	.	7

● Note:

· DZ10K is returned ER401.

## 2.469. QUERY 3D SETTINGS – 3D FRAME DELAY [QVX:DFDI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	46h	44h	49h	31h	03h				
Character	D	F	D	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	46h	44h	49h	31h	3Dh	2Bh	*1	*3
Character		D	F	D	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	0 us					10 us				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	31h	30h
Character	0	0	0	0	0	0	0	0	1	0
	24090 us					25000 us				
Hexadecimal	32h	34h	30h	39h	30h	32h	35h	30h	30h	30h
Character	2	4	0	9	0	2	5	0	0	0

● Note:

· DZ10K is returned ER401.

## 2.470. QUERY 3D SETTINGS – 3D TEST MODE [QVX:DTSI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	44h	54h	53h	49h	31h	03h				
Character	D	T	S	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	54h	53h	49h	31h	3Dh	2Bh	*1	*3
Character		D	T	S	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	NORMAL					SIDE BY SIDE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	LEFT/LEFT					RIGHT/RIGHT				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3
	LEFT/BLACK					BLACK/RIGHT				
Hexadecimal	30h	30h	30h	30h	34h	30h	30h	30h	30h	35h
Character	0	0	0	0	4	0	0	0	0	5

● Note:

· DZ10K is returned ER401.

## 2.471. QUERY 3D SETTINGS – SAFETY PRECAUTIONS MESSAGE [QVX:DMGI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	44h	4Dh	47h	49h	31h	03h				
Character	D	M	G	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	4Dh	47h	49h	31h	3Dh	2Bh	*1	*3
Character		D	M	G	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Note:

· DZ10K is returned ER401.

## 2.472. QUERY CUT OFF – RED [QVX:CUTI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	43h	55h	54h	49h	31h	03h				
Character	C	U	T	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	43h	55h	54h	49h	31h	3Dh	2Bh	*1	*3
Character		C	U	T	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## 2.473. QUERY CUT OFF – GREEN [QVX:CUTI2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	43h	55h	54h	49h	32h	03h				
Character	C	U	T	I	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	43h	55h	54h	49h	32h	3Dh	2Bh	*1	*3
Character		C	U	T	I	2	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

2.474. QUERY CUT OFF – BLUE [QVX:CUTI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	43h	55h	54h	49h	33h	03h				
Character	C	U	T	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	43h	55h	54h	49h	33h	3Dh	2Bh	*1	*3
Character	C	U	T	I	3	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

2.475. QUERY RGB IN – RGB1 INPUT SETTING [QVX:RYCI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	52h	59h	43	49h	31h	03h				
Character	R	Y	C	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	52h	59h	43	49h	31h	3Dh	2Bh	*1	*3
Character	R	Y	C	I	1	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	RGB/YPBPR					Y/C				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

2.476. QUERY RGB IN – RGB1 SYNC SLICE LEVEL [QVX:STRIO]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character	A	D	Z	Z	;	Q	V	X	:	
Hexadecimal	53h	54h	52h	49h	30h	03h				
Character	S	T	R	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	54h	52h	49h	30h	3Dh	2Bh	*1	*3
Character	S	T	R	I	0	=	+	*2	*4	
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LOW					HIGH				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

## 2.477. QUERY RGB IN – RGB2 SYNC SLICE LEVEL [QVX:STRI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	54h	52h	49h	31h	03h				
Character	S	T	R	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	54h	52h	49h	31h	3Dh	2Bh	*1	*3
Character		S	T	R	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	LOW					HIGH				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

## 2.478. QUERY SDI IN – SDI1 SIGNAL LEVEL [QVX:SSL1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	53h	4C	49h	31h	03h				
Character	S	S	L	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	4C	49h	31h	3Dh	2Bh	*1	*3
Character		S	S	L	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	64-940					4-1019				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Note:

·DW11K is returned ER401.

## 2.479. QUERY SDI IN – SDI2 SIGNAL LEVEL [QVX:SSL12]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	53h	4C	49h	32h	03h				
Character	S	S	L	I	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	4C	49h	32h	3Dh	2Bh	*1	*3
Character		S	S	L	I	2	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	64-940					4-1019				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Note:

·DW11K/DZ10K is returned ER401.

## 2.480. QUERY SDI IN – SDI DUAL LINK SIGNAL LEVEL [QVX:SSLI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	53h	53h	4C	49h	33h	03h				
Character	S	S	L	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	53h	4C	49h	33h	3Dh	2Bh	*1	*3
Character		S	S	L	I	3	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	64-940					4-1019				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

● Note:

· DW11K/DZ10K is returned ER401.

## 2.481. QUERY BRIGHTNESS SETUP – CALIBRATION TIME [QVX:BTMI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	42h	54h	4Dh	49h	31h	03h				
Character	B	T	M	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	42h	54h	4Dh	49h	31h	3Dh	2Bh	*1	*3
Character		B	T	M	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					00:01				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	23:59					00:00				
Hexadecimal	30h	32h	33h	35h	39h	30h	32h	34h	30h	30h
Character	0	2	3	5	9	0	2	4	0	0

## 2.482. QUERY BRIGHTNESS SETUP – CALIBRATION MESSAGE [QVX:BMGI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	42h	4Dh	47h	49h	31h	03h				
Character	B	M	G	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	42h	4Dh	47h	49h	31h	3Dh	2Bh	*1	*3
Character		B	M	G	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

#### 2.483. QUERY SHUTTER SETTING – FADE IN [[QVX:SEFS1]]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	45h	46h	53h	31h	03h				
Character	S	E	F	S	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	45h	46h	53h	31h	3Dh	*1	*3
Character		S	E	F	S	1	=	*2	*4
Hexadecimal	*5	03h							
Character	*6								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF (0.0 s)			0.5 s		
Hexadecimal	30h	2Eh	30h	31h	2Eh	35h
Character	0	.	0	1	.	5
	3.5 s			4.0 s		
Hexadecimal	33h	2Eh	35h	34h	2Eh	30h
Character	3	.	5	4	.	0

#### 2.484. QUERY SHUTTER SETTING – FADE OUT [QVX:SEFS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	45h	46h	53h	32h	03h				
Character	S	E	F	S	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	45h	46h	53h	32h	3Dh	*1	*3
Character		S	E	F	S	2	=	*2	*4
Hexadecimal	*5	03h							
Character	*6								

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6)

	OFF (0.0 s)			0.5 s		
Hexadecimal	30h	2Eh	30h	30h	2Eh	35h
Character	0	.	0	0	.	5
	3.5 s			4.0 s		
Hexadecimal	33h	2Eh	35h	34h	2Eh	30h
Character	3	.	5	4	.	0

#### 2.485. QUERY SHUTTER SETTING – STARTUP [QVX:SEFI3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	45h	46h	49h	33h	03h				
Character	S	E	F	I	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	45h	46h	49h	33h	3Dh	*1	*3
Character		S	E	F	I	3	=	+	*2
Hexadecimal	*5	*7	*9	03h					
Character	*6	*8	*10						

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OPEN					CLOSE				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1

## 2.486. QUERY SHUTTER SETTING - SHUT OFF [QVX:SEFI4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	45h	46h	49h	34h	03h				
Character	S	E	F	I	4					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	45h	46h	49h	34h	3Dh	2Bh	*1	*3
Character		S	E	F	I	4	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OPEN					CLOSE				
	Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h	
Character	0	0	0	0	0	0	0	0	1	
KEEP										
Hexadecimal	30h	30h	30h	30h	32h					
Character	0	0	0	0	2					

## 2.487. QUERY DATE AND TIME - NTP SYNCHRONIZATION [QVX:NTP10]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Eh	54h	50h	49h	30h	03h				
Character	N	T	P	I	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	54h	50h	49h	30h	3Dh	2Bh	*1	*3
Character		N	T	P	I	0	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
	Hexadecimal	30h	31h							
Character	0	0	0	0	0	0	0	0	0	1

## 2.488. QUERY NAME - PICTURE MODE USER NAME [QVX:NCGS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Eh	43h	47h	53h	30h	03h				
Character	N	C	G	S	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	43h	47h	53h	30h	3Dh	*1	*3	
Character		N	C	G	S	0	=	*2	*4	
Hexadecimal	*5	*7	*9	*11	*13	*15	17	*19	*21	*23
Character	*6	*8	*10	*12	*14	*16	*18	*20	*22	*24
Hexadecimal	*25	*27	*29	03h						
Character	*26	*28	*30							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,⋯,\*29,\*30)

Example:PICTURE001

PICTURE001										
Hexadecimal	50h	49h	43h	55h	54h	52h	45h	30h	30h	31h
Character	P	I	C	T	U	R	E	0	0	I

● Note:

· Response (Callback) by undefined length.

## 2.489. QUERY NAME - COLOR TEMPERATURE USER1 NAME [QVX:NCGS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Eh	43h	47h	53h	31h	03h				
Character	N	C	G	S	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	43h	47h	53h	31h	3Dh	*1	*3
Character		N	C	G	S	1	=	*2	*4
Hexadecimal	*5	*7	*9	*11	*13	*15	17	*19	*21
Character	*6	*8	*10	*12	*14	*16	*18	*20	*22
Hexadecimal	*25	*27	*29	03h					*23
Character	*26	*28	*30						*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,⋯,\*29,\*30)

Example: COLORTEMP1 の場合

COLORTEMP1										
Hexadecimal	43h	4Fh	4Ch	4Fh	52h	54h	45h	4Dh	50h	31h
Character	C	O	L	O	R	T	E	M	P	1

● Note:

- Response (Callback) by undefined length.

## 2.490. QUERY NAME - COLOR TEMPERATURE USER2 NAME [QVX:NCGS3]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Eh	43h	47h	53h	33h	03h				
Character	N	C	G	S	3					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	43h	47h	53h	33h	3Dh	*1	*3
Character		N	C	G	S	3	=	*2	*4
Hexadecimal	*5	*7	*9	*11	*13	*15	17	*19	*21
Character	*6	*8	*10	*12	*14	*16	*18	*20	*22
Hexadecimal	*25	*27	*29	03h					*23
Character	*26	*28	*30						*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

● Parameters(\*1,\*2,⋯,\*29,\*30)

Example: COLORTEMP2

COLORTEMP2										
Hexadecimal	43h	4Fh	4Ch	4Fh	52h	54h	45h	4Dh	50h	32h
Character	C	O	L	O	R	T	E	M	P	2

● Note:

- Response (Callback) by undefined length.

## 2.491. QUERY NAME - GAMMA USER1 NAME [QVX:NCGS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Eh	43h	47h	53h	32h	03h				
Character	N	C	G	S	2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	43h	47h	53h	32h	3Dh	*1	*3
Character		N	C	G	S	2	=	*2	*4
Hexadecimal	*5	*7	*9	*11	*13	*15	17	*19	*21
Character	*6	*8	*10	*12	*14	*16	*18	*20	*22
Hexadecimal	*25	*27	*29	03h					*23
Character	*26	*28	*30						*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

- Parameters(\*1,\*2,⋯,\*29,\*30)  
Example: GAMMA1

GAMMA1						
Hexadecimal	43h	4Fh	4Ch	4Fh	52h	54h
Character	G	A	M	M	A	1

- Note:
  - Response (Callback) by undefined length.

## 2.492. QUERY NAME – GAMMA USER2 NAME [QVX:NCGS4]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	4Eh	43h	47h	53h	34	03h				
Character	N	C	G	S	4					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	43h	47h	53h	34h	3Dh	*1	*3
Character		N	C	G	S	4	=	*2	*4
Hexadecimal	*5	*7	*9	*11	*13	*15	17	*19	*21
Character	*6	*8	*10	*12	*14	*16	*18	*20	*22
Hexadecimal	*25	*27	*29	03h					*23
Character	*26	*28	*30						*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	×	○	○	○	×

- Parameters(\*1,\*2,⋯,\*29,\*30)

Example: GAMMA1234567890

GAMMA1234567890												
Hexadecimal	47h	41h	4Dh	4Dh	41h	31h	32h	33h	34h	35h	36h	37h
Character	G	A	M	M	A	1	2	3	4	5	6	7
Hexadecimal	38h	39h	30h									
Character	8	9	0									

- Note:

· Response (Callback) by undefined length.

## 2.493. QUERY NAME – PROJECTOR NAME [QVX:NCGS8]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	:	Q	V	X	:
Hexadecimal	4Eh	43h	47h	53h	38h	03h				
Character	N	C	G	S	8					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Eh	43h	47h	53h	38h	3Dh	*1	*3
Character		N	C	G	S	8	=	*2	*4
Hexadecimal	*5	*7	*9	*11	*13	*15	*17	*19	*21
Character	*6	*8	*10	*12	*14	*16	*18	*20	*22
Hexadecimal	03h								*23
Character									*24

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12,\*13,\*14,\*15,\*16,\*17,\*18,\*19,\*20,\*21,\*22,\*23,\*24)

Example: PROJECTOR1

PROJECTOR1										
Hexadecimal	50h	52h	4Fh	4Ah	45h	43h	54h	4Fh	52h	31h
Character	P	R	O	J	E	C	T	O	R	1

- Note:

· Response (Callback) by undefined length.

## 2.494. QUERY MASKING – MODE [QVX:MSK1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	4Dh	53h	4Bh	49h	31h	03h				
Character	M	S	K	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	53h	4Bh	49h	31h	3Dh	2Bh	*1	*3
Character		M	S	K	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					PC-1				
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	0	0	1
	PC-2					PC-3				
Hexadecimal	30h	30h	30h	30h	32h	30h	30h	30h	30h	33h
Character	0	0	0	0	2	0	0	0	0	3

● Note:

- When activation has not been complete, ER401 is returned.

## 2.495. QUERY UNIFORMITY – FLEXIBLE CORRECTION [QVX:UFI1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	55h	46h	4Dh	49h	31h	03h				
Character	U	F	M	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	55h	46h	4Dh	49h	31h	3Dh	2Bh	*1	*3
Character		U	F	M	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

● Note:

- When activation has not been complete, ER401 is returned.

## 2.496. QUERY – SECURITY SETTING [QVX:SPW1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	50h	57h	49h	31h	03h				
Character	S	P	W	I	1					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	50h	57h	49h	31h	3Dh	2Bh	*1	*3
Character		S	P	W	I	1	=	+	*2	*4
Hexadecimal	*5	*7	*9	03h						
Character	*6	*8	*10							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10)

	OFF					ON				
Hexadecimal	30h	31h								
Character	0	0	0	0	0	0	0	0	0	1

## 2.497. QUERY – FAN VOLTAGE [QVX:FNVI]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	46	4E	56	49h	*1	03h				
Character	F	N	V	I	*2					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	46	4E	56	49h	*1	3Dh	2Bh	*3	*5
Character		F	N	V	I	*2	=	+	*4	*6
Hexadecimal	*7	*9	*11	03h						
Character	*8	*10	*12							

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	×	○	○	○	○	○	○	○

● \*1,\*2 (FAN voltage select)

	Exhaust (R) Fan	Exhaust (C) Fan	Exhaust (L) Fan
Hexadecimal	31h	32h	33h
Character	1	2	3
	Intake 1 Fan	Intake 2 Fan	LAMP 1 Fan
Hexadecimal	34h	35h	36h
Character	4	5	6
	LAMP 2 Fan	Power Fan	Ballast Fan
Hexadecimal	37h	38h	39h
Character	7	8	9
	Composition Mirror Fan	DMD Exhaust Fan	Color Prism Fan
Hexadecimal	41h	42h	43h
Character	A	B	C
	DMD(1) Fan	DMD(2) Fan	
Hexadecimal	44h	45h	
Character	D	E	

● Parameters(\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

	0 V				99999 V				
Hexadecimal	30h	30h	30h	30h	30h	39h	39h	39h	39h
Character	0	0	0	0	0	9	9	9	9

● Note:

- Parameters: 00000–99999, hundredfold value of FAN voltage.  
(three-digit integer part, fractional part of the remaining two digits)

## 2.498. QUERY SOFTWARE VERSION – MAIN MICROPROCESSOR [QVX:SVRS0]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	56h	52h	53h	30h	03h				
Character	S	V	R	S	0					

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	56h	52h	53h	30h	3Dh	*1	*3	*5
Character		S	V	R	S	0	=	*2	*4	*6
Hexadecimal	*7	*9	*11	*13	*15	03h				
Character	*8	*10	*12	*14	*16					

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12,\*13,\*14,\*15,\*16)

Example: Ver 1.00

Hexadecimal	31h	2Eh	30h	30h
Character	1	.	0	0

Example: Ver 1.00.01

Hexadecimal	31h	2Eh	30h	30h	2Eh	30h	31h
Character	1	.	0	0	.	0	1

● Note:

- Response (Callback) by undefined length.

## 2.499. QUERY SOFTWARE VERSION – NETWORK MICROPROCESSOR [QVX:SVRS1]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	56h	52h	53h	31h	03h				
Character	S	V	R	S	1					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	56h	52h	53h	31h	3Dh	*1	*3	*5
Character		S	V	R	S	1	=	*2	*4	*6
Hexadecimal	*7	*9	*11	*13	*15	03h				
Character	*8	*10	*12	*14	*16					

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

Example: Ver 1.00

Hexadecimal	31h	2Eh	30h	30h						
Character	1	.	0	0						

## 2.500. QUERY SOFTWARE VERSION – SUB MICROPROCESSOR [QVX:SVRS2]

Hexadecimal	02h	41h	44h	5Ah	5Ah	3Bh	51h	56h	58h	3Ah
Character		A	D	Z	Z	;	Q	V	X	:
Hexadecimal	53h	56h	52h	53h	32h	03h				
Character	S	V	R	S	2					

- Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	56h	52h	53h	32h	3Dh	*1	*3	*5
Character		S	V	R	S	2	=	*2	*4	*6
Hexadecimal	*7	*9	*11	*13	*15	03h				
Character	*8	*10	*12	*14	*16					

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

- Parameters(\*1,\*2,\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12)

Example: Ver 1.00

Hexadecimal	31h	2Eh	30h	30h						
Character	1	.	0	0						

Example: Ver 1.00.01

Hexadecimal	31h	2Eh	30h	30h	2Eh	30h	31h			
Character	1	.	0	0	.	0	1			

- Note:

- Response (Callback) by undefined length.

### 3. Extended Control Command

Start (STX)	ID	Command	Parameters			END (ETX)
1 byte	1 byte	1 byte or 2 byte	Undefined length			1 byte

ID of the extended control command

ID	Hexadecimal (1 byte)	ID	Hexadecimal (1 byte)	ID	Hexadecimal (1 byte)	ID	Hexadecimal (1 byte)
ID All	00	ID23	17	ID46	2E	Group E	84
ID1	01	ID24	18	ID47	2F	Group F	85
ID2	02	ID25	19	ID48	30	Group G	86
ID3	03	ID26	1A	ID49	31	Group H	87
ID4	04	ID27	1B	ID50	32	Group I	88
ID5	05	ID28	1C	ID51	33	Group J	89
ID6	06	ID29	1D	ID52	34	Group K	8A
ID7	07	ID30	1E	ID53	35	Group L	8B
ID8	08	ID31	1F	ID54	36	Group M	8C
ID9	09	ID32	20	ID55	37	Group N	8D
ID10	0A	ID33	21	ID56	38	Group O	8E
ID11	0B	ID34	22	ID57	39	Group P	8F
ID12	0C	ID35	23	ID58	3A	Group Q	90
ID13	0D	ID36	24	ID59	3B	Group R	91
ID14	0E	ID37	25	ID60	3C	Group S	92
ID15	0F	ID38	26	ID61	3D	Group T	93
ID16	10	ID39	27	ID62	3E	Group U	94
ID17	11	ID40	28	ID63	3F	Group V	95
ID18	12	ID41	29	ID64	40	Group W	96
ID19	13	ID42	2A	Group A	80	Group X	97
ID20	14	ID43	2B	Group B	81	Group Y	98
ID21	15	ID44	2C	Group C	82	Group Z	99
ID22	16	ID45	2D	Group D	83		

#### 3.1. LENS CONTROL

■ There is a command of the same function to 2.200~2.205.

Hexadecimal	02h	*1	B1h	7Ch	*2	*3	*4	03h
Remarks	STX	ID	Command		Parameters			ETX

● Parameters(\*2)

Hexadecimal	LENS SHIFT - H	LENS SHIFT - V	LENS FOCUS	LENS ZOOM
Hexadecimal	00h	01h	02h	03h

● Parameters(\*3)

Hexadecimal	Slowly	Normal	Fast	HOME POSITION *
Hexadecimal	00h	01h	02h	80h

● Parameters(\*4)

Hexadecimal	Right / Up / Forward / In / Cancel	Left / Down / Backward / Out / Start
Hexadecimal	00h	01h

● Note:

· HOME POSITION is available only when parameters (2\*) is LENS SHIFT H (00h) or LENS SHIFT V (01h).

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*5	B3h	7Ch	*2	*3	*4	03h
	STX	ID	コマンド Response (Callback)		Parameters			ETX

Acceptability 不可期間の場合

Hexadecimal	02h	*5	FFh	03h
	STX	ID	Error	ETX

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	×	×	○	×	○	○	○	○	○

### 3.2. SELF CHECK INFORMATION

Hexadecimal	02h	*1	FEh	FEh	03h
Remarks	STX	ID	Command	ETX	

● Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*2	FEh	*3	*4	*5	*6	*7	*8
	STX	ID	Command response			Parameters			
Hexadecimal	*9	*10	*11	*12	*13	*14	*15	*16	*17
						Parameters		*18	03h

Acceptability

SECURITY	STANDBY	ECO STANDBY	NO SIGNAL	SHUTTER	FREEZE	TEST PATTERN	REMOTE2	P IN P	LENS HOME
○	○	○	○	○	○	○	○	○	○

● Parameters(\*3,\*4,\*5,\*6,\*7,\*8,\*9,\*10,\*11,\*12,\*13,\*14,\*15,\*16,\*17,\*18)

	*3						*4					
bit	127						120	119				112
		*5										*6
bit	111						104	103				96
		*7										*8
bit	95						88	87				80
		*9										*10
bit	79						72	71				64
		*11										*12
bit	63						56	55				48
		*13										*14
bit	47						40	39				32
		*15										*16
bit	31						24	23				16
		*17										*18
bit	15						8	7				0

Bit	Factor	Description
127	Internal error	Main microcomputer circuit is abnormal
126	Unused	-
125	Lamp type is mixed warning	Lamps of different types have been mounted.
124	Unused	-
123	WF-P.C.B(GEOMETRY) communication error	GEOMETRY IC abnormal
122	FM-P.C.B communication error	Formatter communication error
121	Unused	-
120	Unused	-
119	Unused	-
118	Unused	-
117	Unused	-
116	Unused	-
115	Unused	-
114	Unused	-
113	Unused	-
112	Unused	-
111	Unused	-
110	IIC communication error 12(OPTICAL SENSOR)	Luminance sensor error, Connector disconnection(M31/RL14).
109	IIC communication error 11(ACCELERATION SENSOR)	Appropriate device malfunction of signal unit.
108	IIC communication error 10(ADC2)	
107	IIC communication error 9(ADC1)	
106	IIC communication error 8(EDID ANALOG)	
105	IIC communication error 7(EDID DIGITAL)	Appropriate device malfunction of signal unit.
104	Unused	
103	Unused	
102	IIC communication error 4(LAMP2 EEPROM)	
101	IIC communication error 3(LAMP1 EEPROM)	Appropriate device malfunction of signal unit.
100	IIC communication error 2(EEPROM)	
99	IIC communication error 1(RTC)	
98	Sub microcomputer (R8) communication error	Sub microcomputer no response.
97	Network microcomputer communication error	Network microcomputer no response.
96	Unused	-

95	Installation angle warning	Tilted at an angle that exceeds $\pm 15^\circ$ from the horizontal.
94	Unused	-
93	Unused	-
92	Unused	-
91	Unused	-
90	Unused	-
89	Unused	-
88	Ballast2 communication error	
87	Ballast1 communication error	Ballast1 communication error.
86	Lens mount error	Stepping-motor is failure. Limit position detection sensor is failure.
85	Unused	-
84	Unused	-
83	Unused	-
82	Unused	-
81	FPGA 3 configuration error	Signal unit is failure.
80	FPGA 1/2 configuration error	
79	Unused	-
78	Unused	-
77	Unused	-
76	Unused	-
75	Unused	-
74	Unused	-
73	Lamp 2 memory error	Lamp memory has not been initialized.
72	Lamp 1 memory error	
71	Unused	-
70	Unused	-
69	Unused	-
68	Unused	-
67	Dynamic iris error	Iris abnormal operation.
66	Unused	-
65	Unused	-
64	Portrait lamp warning	Portrait mode only lamp is not in use.
63	Unused	-
62	Unused	-
61	Unused	-
60	Unused	-
59	Unused	-
58	Unused	-
57	Unused	-
56	Unused	-
55	FAN14 (DMD2) error/warning	
54	FAN13 (DMD1) error/warning	
53	FAN12 (Color prism) error/warning	
52	FAN11 (DMD Exhaust) error/warning	
51	FAN10 (Composition Mirror) error/warning	
50	FAN9 (Ballast) error/warning	
49	FAN8 (Power) error/warning	Fan or fan drive circuit is failure.
48	FAN7 (Lamp2) error/warning	Fan replacement time.
47	FAN6 (Lamp1) error/warning	
46	FAN5 (Intake2) error/warning	
45	FAN4 (Intake1) error/warning	
44	FAN3 (Exhaust-L) error/warning	
43	FAN2 (Exhaust-C) error/warning	
42	FAN1 (Exhaust-R) error/warning	
41	Filter clogged error	Air filter is clogged.
40	Air filter unit warning	Air filter unit not installed.
39	Portrait installation warning	Installed the connecting terminals surface is not downward.
38	Angle sensor error	Angle sensor is failure (IC3517).
37	Battery replacement for the internal clock	Remaining battery level is low.
36	Filter clogged warning	Filter may accumulate dust.
35	Airflow sensor disconnected	Airflow sensor has breaking of wire, or connector (M21/RL9) is disconnected.

34	Exhaust air temperature sensor disconnected	Exhaust air temperature sensor has breaking of wire, or connector (M11/R34) is disconnected.
33	Optical module temperature sensor disconnected	DMD temperature sensor has breaking of wire, or connector (G16) is disconnected.
32	Intake air temperature sensor disconnected	Intake air temperature sensor has breaking of wire, or connector (M11/RL10) is disconnected.
31	Luminance sensor error	Luminance sensor proportion is abnormal. Luminance is abnormal.
30	Special filter setting	Air filter setting is a Special.
29	Cover open error	Lamp cover is not installed.
28	Low AC voltage warning	Low AC voltage.
27	Unused	-
26	Unused	-
25	Lamp2 not installed	Lamp is not installed.
24	Lamp1 not installed	(Lamp memory can not be read)
23	Unused	-
22	Unused	-
21	Lamp2 failed to light	Failure to Start Lamp. - There is a possibility that has restarted in hot state.
20	Lamp1 failed to light	
19	Unused	-
18	Unused	-
17	Unexpected Lamp2 OFF	
16	Unexpected Lamp1 OFF	Lamp is failure.
15	Unused	-
14	Unused	-
13	Lamp2 runtime is over	The lamp unit's available time has been exceeded. (Over 2500 hours, DZ10K is over 3500 hours)
12	Lamp1 runtime is over	
11	Unused	-
10	Unused	-
9	LAMP2 runtime warning	Time to replace the lamp unit. (Over 2300 hours, DZ10K is over 3300 hours)
8	LAMP1 runtime warning	
7	Optical module low temperature error	
6	Exhaust air high temperature error	
5	Optical module high temperature error	
4	Intake air temperature error	
3	Optical module low temperature warning	The temperature inside this projector has become high or ambient temperature is too low. - The ventilation holes may be closed.
2	Exhaust air high temperature warning	- The ambient temperature in the place of use may be too high or low.
1	Optical module high temperature warning	- The air filter may accumulate dust.
0	Intake air temperature warning	